

PHILIPS

LPL19

Professional

High Quality LED x 6

130 lm +20 lm pointer

Up to 11h Autonomy / AAA x 3

Water & Dust Protected IP54



LPL19B1



See better, work better

Professional portable inspection tool

Philips LED Penlight Inspection Lamp is the perfect tool for quick inspection work, combining high quality LEDs, water and dust resistance (IP54) with a small, easy-to-use, form.

Brighter and longer lasting

- Defeat darkness with soft natural light
- Focus light: 20 lm
- High quality LED light up to 130 lumens

High resistance

- Strong impact resistance -IK07
- Water & dust protected -IP54
- Resistant to chemicals and workshop solvents

Highlights

Focus light: 20 lm

The focus light will enable you to see what remains hidden for others; thanks to its ultra-slim design the lamp can be manoeuvred into very small cavities and the strong LED source will illuminate all.

Water & dust protected -IP54



The LED inspection lamp is water resistant, and conforms to IP54.

Strong impact resistance -IK07



Strong impact resistance -IK07

Resistant to chemicals

As well as resisting knocks, the inspection lamp cases are resistant to water, chemicals and workshop solvents.

High quality LED light 130 lm

As the international market leader in car lighting, we have years of experience and know-how in light. Philips LED inspection lamps are equipped with high quality LEDs. Our LEDs combine strong light performance with a natural colour rendering for fatigue-free work.

Defeat darkness

Philips professional workshop lamps feature powerful LEDs for an intense white light and a bright wide beam to defeat darkness. Designed to optimize clarity and vision, the 6000 K white light also improves visual comfort for fatigue-free working.

Specifications

Outer Carton

Number of consumer packagings: 6
Outer carton (L x W x H): 26 x 13 x 11.1 cm
Gross weight: 0.6 kg
GTIN: 1 87 27900 38820 3

Ordering information

Order entry: LPL19B1
Ordering code: 38819031

Electrical characteristics

Battery run time: Up to 11 hours
Battery type: 3 x Philips AAA
Power source: AAA Battery
Voltage: 4.5 V
Wattage: 1.3 W

Light characteristics

Beam angle: 35-44 degree
Color temperature: 6000 K
LED lifetime: 10000 hrs
Light output: 130 lumen
Light output (pointer): 20 lumen

Outerpack information

Gross weight per piece: 640 g
Height: 11 cm
Length: 25.8 cm
Width: 15.1 cm

Packaging Data

EAN1: 8727900388190
EAN3: 8727900388206

Packed product information

Height: 3.1 cm
Length: 17.2 cm
Weight with batteries: 70 g
Width: 1.8 cm
Weight without batteries: 38 g
Size: Compact

Product description

Hook: Standard clip
Ingress protection rating (IP): IP54
Magnet: No
Number of LED's: 7
Operating Temperature: 0 to 40 °C
Resistant to: grease, oil, workshop solvents
Technology: LED
Range: Penlight, Professional

