

PHILIPS

Motorcycle
headlights

WhiteVision ultra
moto

H4

Pack of: 1

12 V, 60/55 W

Irresistible white style

12342WVUBW



Sharp irresistible look

Sharp white look

The Philips WhiteVision ultra moto H4, featuring the latest coating formula, delivers stunning 4200 Kelvin. These are the whitest road-legal halogen lights in our portfolio and the perfect choice if you're looking for a cool, stylish look.

Stylish white look with up to 4200 Kelvin

- Up to 4200 Kelvin sharp white light
- Halogen upgrade headlights that offer a highly stylish look

Road-legal performance

- Stunning white road-legal headlights for a stylish look

Comfort with up to 60% more vision

- White light to enhance visibility and comfort
- Up to 60% more vision to maximise clarity

Enhanced safety

- Our whitest bulbs for stylish performance on the road

Philips quality

- Philips is the choice of major car manufacturers

Highlights

4200 Kelvin sharp white light

With up to 4200 Kelvin, Philips WhiteVision ultra moto headlight bulbs revolutionise the look of your motorcycle with a sharp white light. The right choice for a bright and stylish driving experience!

Cool white effect

Philips WhiteVision ultra moto is designed for drivers who are looking for an upgrade with the style and appearance of LED lighting, but who drive a vehicle with halogen technology. Thanks to the advanced coating formula on the glass, Philips WhiteVision ultra moto bulbs are our whitest road-legal lights, providing a stunning look in the headlamp's reflector.

Stunning road-legal headlights

Philips WhiteVision ultra moto upgrade headlight bulbs are ECE certified for bright white light on the road. Drivers enjoy a vibrant look and a street-legal bulb compliant with relevant regulations. Without compromising safety by dazzling oncoming drivers, it gives you great visibility.

Comfort light for visibility

The Philips WhiteVision ultra moto coating formula, along with its cool white light, significantly improves visibility at night and enhances driver comfort by reducing eye fatigue. When design meets functionality, you enjoy a great look and enhanced driving comfort.

Up to 60% more vision

A longer beam pattern, with up to 60% more vision compared to the legal minimum standard, enables you to not only see other road users more clearly but also be better seen by them. It improves safety and gives you more time to react to potential hazards on the road ahead.

Engineered for stylish vision

Better and brighter lights allow for increased performance on the road. With their optimised high-precision filament geometry, high-pressure gas filling, high-precision coating and high-quality anti-UV quartz glass, Philips WhiteVision ultra moto headlight bulbs set a new standard for road-legal white light. Engineered for great style and visibility, these headlights provide a more relaxed and fun driving experience.

Highest quality car lighting

Technologically advanced Philips lighting is renowned in the automotive industry, and has been for over 100 years. The Philips Original Equipment Quality products are designed and developed following strict quality control processes (including applicable ISO norms), leading to consistently high production standards. Philips WhiteVision ultra moto is compatible with motorcycle models of major brands.

Specifications

Electrical characteristics

Rated voltage: 12 V

Wattage: 60/55 W

Lifetime

Life time: 540 h

Light characteristics

Colour temperature: 4200 K

Lumens: 1,650 ±15% / 1,000 ±15%

Marketing specifications

Expected Benefits: Up to 4200 K

Product highlight: Irresistible white style

Ordering information

Order entry: 12342WVUBW

Ordering code: 2385830

Outer pack information

Height: 14.0 cm

Length: 26.1 cm

Width: 19.6 cm

Gross weight per piece: 0.474 kg

Packaging Data

EAN1: 8719018023858

EAN3: 8719018023865

Packaging type: BW

Packing: Blister

Quantity in box: 1

Packed product information

Gross weight per piece: 35.8 g

Height: 12.9 cm

Length: 9.5 cm

Width: 4.8 cm

MOQ (for professionals): 10 pcs

Pack Quantity: 1 pc

Product description

Technology: Halogen

Type: H4

Range: WhiteVision ultra

Application: High beam, Low beam

Homologation ECE

Designation: H4 12342 WVU 12 V 60/55 W BW

Base: P43t-38

