



4 inch LED light bar

- Road-legal ECE R149-12.5
- 1150 lm, 240 m beam length
- Dual-colour position light
- All terrain, all weather

LUMUD5101LX1

Powerful brightness driving safety at the wheel

Bright, durable gear for overland journeys

The Philips Ultinon Drive 5101L LED light bar has the power to keep you safer, wherever you're heading. Spot hazards up to 240 metres away with lighting that performs in the most hostile environments and gives your vehicle a touch of style.

Benefits

Brilliance that makes you a safer driver

- Intense, far and wide illumination for superior visibility

Dual-color position lights that get you noticed

- Choose your position-light colour

Designed to handle hostile environments

- IP68 and IP69K-rated to master the elements
- Corrosion-free body, stainless-steel mounting brackets

Road-legal auxiliary lights

- Powerful road-legal LED lightbars

Easy to install with flexible mounting options

- Low-profile design for simpler fitting

Features

Up to 240-metre visibility

The Philips Ultinon Drive 5101L LED light bar provides a brilliant light beam that illuminates the road ahead for up to 240 metres*. Its effective 1150 lumens are homogeneously distributed in an optimised indirect beam, generating intense illumination far and wide with reduced glare for everyday

use. This enables drivers to react faster on dark, rural and dirt roads. Its cool, 6500 Kelvin light colour produces daylight conditions, improving contrast and helping drivers stay focused.

PHILIPS

Ultinon Drive 5100

Brilliant white or amber LED

Never go unnoticed on side roads or in parking areas with the extra LED position lights of our Philips Ultinon Drive 5101L. Express your style and personality by choosing your light colour, either intense amber or cool white.

Waterproof for durable light

With its ingenious screwless design, the Philips Ultinon Drive 5101L LED light bar can withstand the wettest conditions. Its IP69K certification means it will perform, wherever your road leads and whatever the weather. And it will be more than a match for any power washer you use to clean your car afterwards.

Corrosion-free

With its anodised pre-treated and automotive-grade powder-top-coat body, the Philips Ultinon Drive 5101L LED light bar offers ultimate corrosion protection. Its mounting brackets are made of stainless steel, which is corrosion-free. It can withstand snow, ice and even salt. Built from durable,

high-quality materials, your Philips auxiliary LED lights will provide years of reliable service.

Road-legal lights

The Philips Ultinon Drive 5101L LED light bar meets ECE standards and is 100% road-legal for high-beam and position-light functions. For added safety, Philips LED light bars are tested to EMC R10 specification to ensure that they will function smoothly with your vehicle's electrical systems. The Philips Ultinon Drive 5101L LED light bar meets ECE standards and is 100% road-legal for high-beam and position-light functions. For added safety, Philips LED light bars are tested to EMC R10 specification to ensure that they will function smoothly with your vehicle's electrical systems.

Easy and flexible installation

The sleek, low-profile design makes installation easier, and flexible fitting options are possible with side-mounting brackets (included) and back-mounting brackets (UD1001M optional). Supplied with a pre-wired male/female 3-pin superseal DT connector, it is voltage-overload and reverse-polarity protected to make installation secure and easy.

Specifications

Please note that this is a pre-sales leaflet. The contents of this leaflet reflect the best of our knowledge per date and country mentioned above. The contents of this leaflet are subject to change without notice. Philips does not accept any liability as to the contents of this leaflet.

Electrical characteristics

Voltage	9-30 Volt DC
---------	--------------

Product description

Accessories (optional)	LUMUD1001M, LUMUD1003W, LUMUD1004W
Boost function installation	No
Boost mode activation	No
Break resistance	Yes
corrosion-free brackets	U-shaped mounting bracket
ECE R10	Yes
ECE R148	Yes
ECE R149	Yes
ECE reference number	12.5
Impact protection rating (IK)	IK07
Ingress protection rating (IP)	IP68 and IP69K
Installation angle	360°
Material	Aluminium extruded
Off-road boost	No
One-piece body design	Yes
Operating temperature	-40° C to 80° C
Parking position light	Yes, white or amber
Range	Ultinon Drive 51000
Plug type	4-pin DT Connector with 0.5 m cable
Scratch-resistant lens	Yes
Technology	LED
Width	150 mm/4 inch

Light characteristics

Beam length 1 lux-m	240
Colour temperature	6500 K K
Effective lumen output	1150 lumens
Raw lumen output	4950 lumens

Packed product information

Box dimensions-L (mm)	350
Box dimensions-W (mm)	90
Box dimensions-H (mm)	90
MOQ (for professionals)	8
Number of products in the box	1 lamp

Ordering information

GOC	01842750
Order entry	UD5101LX1

Packaging Data

EAN1	8719018018427
EAN3	8719018018434

Outer pack information

Height	200 cm
Length	370 cm
Width	200 cm

* Beam length measured on 1 lux.



data subject to change
2022, June 26

Version: 1.0.1
EAN:

© 2022 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com