

PHILIPS

20 inch LED lightbar

Ultinon Drive 5100

Road-legal ECE R149 - 30+30

4000 lm, 500 m beam length

Dual-colour position light

All terrain, all weather

LUMUD5103LX1



Powerful brightness driving safety at the wheel

Bright, durable gear for overland journeys

The Philips Ultinon Drive 5103L LED light bar has the power to keep you safer, wherever you're heading. Spot hazards up to 500 metres away with lighting that performs in the most hostile environments and gives your vehicle a touch of style.

Designed to handle hostile environments

- Corrosion-free body, stainless-steel mounting brackets
- Sturdy one-piece body for tough environments
- IP68 and IP69K waterproof to master the elements

Road-legal auxiliary lights

- Powerful road-legal LED lightbars

Easy to install with flexible mounting options

- Low-profile design for simpler fitting

Dual-color position lights that get you noticed

- Choose your position-light colour

Brilliance that makes you a safer driver

- Intense, far and wide illumination for superior visibility

Ultinon Drive 5100

20 inch LED lightbar

LUMUD5103LX1/10

Highlights

Up to 500-metre visibility

The Philips Ultinon Drive 5103L LED light bar provides a brilliant light beam that illuminates the road ahead for up to 500 metres*. Its effective 4000 lumens are homogeneously distributed in an optimised indirect beam, generating intense illumination far and wide with reduced glare for everyday use. This enables drivers to react faster on dark, rural and dirt roads. Its cool, 6500 Kelvin light colour produces daylight conditions, improving contrast and helping drivers stay focused.

Brilliant white or amber LED

Never go unnoticed on side roads or in parking areas with the extra LED position lights of our Philips Ultinon Drive 5103L. Express your style and personality by choosing your light colour, either intense amber or cool white.

Sturdy one-piece body

The Philips Ultinon Drive 5103L LED light bar is built in a single piece to withstand the toughest conditions. Its design provides excellent heat management and consistently high light output throughout your journey. Rated IK07, it is shock-resistant to ensure faultless performance on and off the road. Its unbreakable polycarbonate lens can take any hit without damage or scratches.

Waterproof for durable light

With its ingenious screwless design, the Philips Ultinon Drive 5103L LED light bar can withstand the wettest conditions. Its IP69K certification

means it will perform, wherever your road leads and whatever the weather. And it will be more than a match for any power washer that you use to clean your car afterwards.

Corrosion-free

With its anodised pre-treated and automotive-grade powder-top-coat body, the Philips Ultinon Drive 5103L LED light bar offers ultimate corrosion protection. Its mounting brackets are made of stainless steel, which is corrosion-free. It can withstand snow, ice and even salt. Built from durable, high-quality materials, your Philips auxiliary LED lights will provide years of reliable service.

Road-legal lights

The Philips Ultinon Drive 5103L LED light bar meets ECE standards and is 100% road-legal for high-beam and position-light functions. It can be installed individually and centrally on vehicles, and still be ECE-compliant thanks to its twin light-module design in a single bar.

Easy and flexible installation

The sleek, low-profile design makes installation easier, and flexible fitting options are possible with side-mounting brackets (included) and back-mounting brackets (UD1001M optional). Supplied with a pre-wired male/female 4-pin superseal DT connector, it is voltage-overload and reverse-polarity protected to make installation secure and easy.

Specifications

Product description

Boost mode activation: No
Break resistance
ECE R10
ECE R149
ECE reference number: 30
Impact protection rating (IK): IK07
Ingress protection rating (IP): IP68 and IP69K
Installation angle: 360°
Material: Aluminium extruded
Off-road boost: No
One-piece body design
Operating temperature: -40° C to 80°C
Range: Ultinon Drive 51000
Scratch-resistant lens
Technology: LED
Width: 558 mm/20 inch
Boost function installation: No
Accessories (optional): LUMUD1001M, LUMUD1003W, LUMUD1004W
corrosion-free brackets: Side mounting brackets
ECE R148
Parking position light: Yes, white or amber
Plug type: 4-pin DT Connector with 0.5 m cable

Light characteristics

Colour temperature: 6500 K K
Beam length 1 lux-m: 500
Effective lumen output: 4000 lumens
Raw lumen output: 19800 lumens

Electrical characteristics

Voltage: 9-30 Volt DC

Ordering information

Order entry: UD5103LX1
GOC: 01846594

Packaging Data

EAN1: 8719018018465
EAN3: 8719018018472

Packed product information

MOQ (for professionals): 4
Box dimensions-L (mm): 610
Box dimensions-W (mm): 105
Box dimensions-H (mm): 90
Number of products in the box: 1 lamp

Outer pack information

Length: 630 cm
Width: 200 cm
Height: 230 cm

