

Philips 5000 series
LCD TV

81 cm (32")
HD Ready

32PFL5637



Refined living, pure performance

with leading picture and connectivity

Ultimate performance on a picture perfect flat screen. This Philips TV provides a premium elegant design to set the scene for you to experience the brilliance of technology. Enjoy the show !

See brilliant picture quality

- "Dynamic contrast 75000:1 for incredible rich black details
- HD LCD Display 1366x768p
- Pixel Plus HD for better details, depth and clarity

Hear crisp and clear sound

- Incredible Surround for enhanced audio enjoyment
- Feel the power of 20 W(2x 10W) RMS

Easy to connect and enjoy

- Seamless connectivity with 3 HDMI inputs
- Enjoy video, photo & music playback via USB

PHILIPS

LCD TV
81 cm (32") HD Ready

Highlights

HD LCD Display 1366x768p



This WXGA display with state-of-the-art LCD screen technology gives you widescreen HD resolution of 1366 x 768p pixels. It produces brilliant flicker-free progressive scan pictures with optimum brightness and superb colors. This vibrant and sharp image will provide you with an enhanced viewing experience..

Pixel Plus HD



Pixel Plus HD offers the unique combination of ultimate sharpness, natural detail, vivid colours and smooth natural motion on all qualities of HD, standard TV signals and multimedia content, for high definition displays. Artefacts and noise in all sources from multimedia to standard TV and also in highly compressed HD are detected and reduced ensuring that the picture is clear and razor sharp

Dynamic contrast 75000:1



"You want the LCD flat display with the highest contrast and most vibrant images. Philips advanced video processing combined with unique extreme dimming and backlight-boosting technology results in vibrant images. Dynamic Contrast will increase the contrast with excellent black level and accurate rendition of dark shades and colours. It gives a bright, lifelike picture with high contrast and vibrant colours.."

Incredible Surround



"Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.."

32PFL5637/V7

Rich & clear sound experience



"Feel the power of the music beat and the atmosphere of the movies. The powerful 20 W RMS (2 x 10 W RMS) amplifiers create a lifelike soundstage. It gives a clear and spacious sound stage complementary to the rich viewing experience.."

3 HDMI inputs



"HDMI makes an uncompressed digital RGB connection from the source to the screen for the ultimate picture quality. HDMI uses HDCP copy protection. With 2 HDMI inputs on the back of the TV you can connect multiple HD sources, for instance an HD settop box, a Blu-ray player, and Game Console or Digital Camcorder.."

USB with video playback



The USB connector allows access to jpeg photos & music files of most USB-sticks (USB memory-class device).



Specifications

Picture/Display

- Diagonal screen size (inch): 32 inch
- Panel resolution: 1366 x 768p
- Picture enhancement: Pixel Plus HD, 3/2 - 2/2 motion pull down, 3D Combfilter, Digital Noise Reduction

Supported Display Resolution

- Computer formats: 1024 x 768, 60, 70, 75Hz, 1280 x 1024, 60, 70, 75Hz, 640 x 480, 60, 72, 75Hz, 720 x 400, 70Hz, 800 x 600, 56, 60Hz, Via HDMI/DVI input,
- Video formats: 1080i, 50, 60Hz, 1080p, 50Hz, 1080p, 60Hz, 480i, 60Hz, 480p, 60Hz, 576i, 50Hz, 576p, 50Hz, 720p, 50, 60Hz

Convenience

- Ease of Installation: Autostore, Fine Tuning
- Ease of Use: Graphical User Interface, On Screen Display
- On-Screen Display languages: English

USB - File Extension

- Video: *.avi, *.mkv, *.mov, *.mp4, *.mpeg, *.mpg, *.wmv

USB - Container

- Video: ASF, AVI, MKV, MP4, PS

USB - Video Decoder

- Compression Format: MPEG 1, MPEG 2, H.264, MPEG 4, VC-1

Sound

- Output power (RMS): 20 Watts
- Sound System: Stereo
- Sound Enhancement: Auto Volume Leveler,

Incredible Surround

Loudspeakers

- Built-in speakers: 2

Connectivity

- USB: USB
- HDMI 1: HDMI
- HDMI 2: HDMI
- Other connections: Antenna F-type, Component Video (YPbPr) input, Composite video (CVBS) input
- HDMI 3: HDMI

Power

- Power supply: 100-240VAC, 50/60Hz
- Power consumption: 150 W
- Standby power consumption: Less than 1 Watt

Accessories

- Included accessories: 2 x AAA Batteries, Quick start guide, Remote Control, Software declaration, Tabletop swivel stand, User Manual, Warranty certificate

Dimensions

- Set Width: 784 mm
- Set Height: 498 mm
- Set Depth: 89 mm
- Product weight: 8.9 kg
- Set width (with stand): 784 mm
- Set height (with stand): 544 mm
- Set depth (with stand): 240 mm
- Product weight (+stand): 10.9 kg
- Stand width: 400 mm
- Stand depth: 240 mm



Issue date 2023-10-15

Version: 2.0.1

EAN: 87 12581 65413 9

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com