



Professional TV

- EasySuite

24HFL3014P/12

Take control

Powered by CMND

Show more with a budget-friendly standalone professional TV. The intuitive CMND solution makes it simple to deploy and manage connected displays. Benefit from simple, fast installation and an on-screen welcome page that's easy to program.

Benefits

Simple set up. ADVANCED performance

- CMND and Control: effortless maintenance of your TVs
- MyChoice compatible. Built-in pay-to-view solution
- Be seen. Brand the TV's UI with your logo
- Mixed channel map to combine analogue and digital channels
- Instant initial USB cloning. Rapidly configure Pro TVs

Cost-effective solution

- 3 years warranty, extendable to 5 years
- Multilingual customer support
- Translucent backcover to uncover hidden materials
- Low power consumption for long battery life

Features

CMND&Control

CMND and Control allows for remote configuration and installation of your TVs from a central location, without the need to visit any rooms. Update and manage all your displays, with minimal effort, all without having to disturb your guests.

Built-in pay-to-view solution

Offer pay-to-view content in any situation-from a complete pay-to-access-all-channels model to selected premium content. MyChoice is an integrated solution that allows viewers to access pay-per-view channels via a code or a card.

PHILIPS

UI branding

Your Philips Professional TV offers a clear, easy-to-navigate user interface (UI), which you can customize with your own branding. Easily add your logo or custom background to the menu to increase the visibility of your brand.

Translucent backcover

Translucent backcover will uncover hidden materials within the TV set. Ideally suited for installations within prisons and detention centers.

Instant initial USB cloning.

Provides the ability to easily copy all programming and channel programming settings from one TV into other TV sets in less than a minute. The feature ensures uniformity between TV sets and significantly reduces installation time and costs.

Specifications

[field not found 'disclaimer_text']

Picture/Display

Display	LED HD TV E-LED
Diagonal screen size (metric)	60 cm
Diagonal screen size (inch)	24 inch
Panel resolution	1366 x 768p
Brightness	250 cd/m ²
Viewing angle	178° (H) / 178° (V)

Audio

Sound output Power	6 (2x3) W
Speakers	2.0
Sound Features	Down Firing AVL Dynamic Bass Incredible surround Dolby MS10

Design

Colour	Black
Features	Translucent backcover

Tuner/Reception/Transmission

Digital TV	DVB-T/T2/C HEVC FHD (up to 1080p60)
Analog TV	PAL SECAM
Video Playback	NTSC PAL SECAM

Connectivity Rear

Antenna	IEC-75
HDMI1	ARC HDMI 1.4
HDMI2	HDMI 1.4
Digital Audio out	Optical
DVI audio in	Mini-Jack
VGA input	15 pin D-sub
Scart	CVBS RGB

Connectivity Side

Common Interface Slot	CI+ 1.3.2
Headphone out	Mini-Jack
USB1	USB 2.0

Connectivity Enhancements

HDMI	ARC (HDMI1)
EasyLink (HDMI CEC)	One touch play System Standby RC pass through system audio control
Scart	Power on scart

Features

Digital services	8d EPG
------------------	--------

Ease of use	Now&Next MHEG Teletext Subtitles Picture Style Sound Style Picture Format Independent volume control On/Off switch (side)
Local control	
Hospitality Features	
Hotel mode	Menu lock Installation Menu Lock Volume limitation Joystick Control Lock high security mode TXT/MHEG/USB/EPG/Subtitle Lock
Prison mode	Remote Management over RF
CMND&Control	TV Group management Off-Line Settings Editor Off-Line Channel Editor Welcome Logo Customizable Home Screen
Your brand	MyChoice Instant Initial Cloning Via USB/RF
Revenue generation	Sleep Timer Wake Up Alarm Wake Up On Channel Wake up Sounds Glow-in-the-Dark RC button
Cloning and Firm-ware update	On-screen Clock Combined List Off-Line Channel Editor Block Automatic Channel Update
Timer	Green/fast startup Channel Feature Picture Style Picture Format Sound Style Volume Menu language
Clock	Cable Strap Ready Low Battery Detection RC Battery Door Lock Glow-in-the-Dark Clock button
Channels	Battery Anti-theft Protection Kensington Lock Guest language control
Control	
Power control	
Switch On control	
Remote Control	
Anti-Theft	
Languages	

Healthcare features

Control	Multi-Remote Control Healthcare RC compatible
Convenience	Headphone out Independent main speaker mute Headphone Detection
Safety	Double isolation class II Flame retardant

Multimedia

Multimedia connections	USB
Video playback supported	Formats: H.264/MPEG4 AVC MPEG1 MPEG2 MPEG4 WMV9/VC1 MP4 MPG TS WMV HEVC Containers: AVI, MKV
Subtitle formats supported	SRT ASS SMI SSA SUB TXT
Music formats supported	MP3 AAC WAV WMA (v2 up to v9.2)
Picture formats supported	BMP JPG PNG GIF
Supp. Video Resolution on USB	up to 1920x1080p@60Hz

Accessories

Included	Edge Stand 2x AAA batteries Power Cord Warranty Leaflet Legal and Safety brochure
----------	---

Optional

Remote Control 22AV1903A/12
Easy RC 22AV1601B/12
Healthcare RC 22AV1604B/12
Setup RC 22AV9574A/12

Power

Mains power	AC 220-240V; 50-60Hz
Energy Label Class	E
EPREL registration number	1069369
Eu Energy Label power	17 W
Standby power consumption	<0.3W
Power Saving Features	Eco mode Auto switch-off timer
Ambient temperature	0 °C to 40 °C

Dimensions

Set Width	560 mm
Set Height	336 mm
Set Depth	35/45 mm
Set width (with stand)	560 mm
Set height (with stand)	336 mm
Set depth (with stand)	124 mm
Product weight	3.1 kg
Product weight (+stand)	3.2 kg
Wall mount compatible	M4 75 x 75 mm

* Availability of features will depend on implementation chosen by integrator.

* Typical on-mode power consumption measured according to IEC62087 Ed 2. The actual energy consumption will depend on how the television is used.

* This television contains lead only in certain parts or components where no technology alternatives exist in accordance with existing exemption clauses under the RoHS Directive.

* Design and specifications are subject to change without notice



data subject to change
2022, October 12

Version: 1.0.1
EAN: 8718863029473

© 2022 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com