



Professional TV

- 43" MediaSuite
- powered by Android™

43HFL6114U/12

## Smarter connectivity

with Chromecast built-in and Netflix

Designed for a fast-paced world, MediaSuite features advanced connectivity and versatile configuration settings. Chromecast built-in makes streaming fast and easy, whilst Android™ and Google Play Store unleash infinite possibilities.

### Benefits

#### Ready for anything

- Android updates provide the latest functionality
- Chromecast™ built-in for easy content sharing
- Google Play Store access for apps and media
- Customisable UI for custom logos and colours
- Integrated Netflix with dedicated remote button
- Google Assistant™ enables faster, smarter control
- Analogue clock display in off mode

#### Powered for more

- Analytics on-board provides usage stats
- Install and manage apps remotely with AppControl
- Operate, monitor and maintain via CMND & Control
- Create custom experiences with CMND & Check-in
- Instant initial cloning for faster installation

**PHILIPS**

## Features

### Powered by Android

Android-powered Philips Professional Displays are fast, versatile and easy to navigate. The displays are optimised for native Android apps and you can install web apps directly to the display too. Automatic updates ensure apps stay up to date.

### Chromecast built-in

Enable instant, secure wireless casting of movies, presentations, and more from smart devices (mobiles, laptops, tablets) in up to 4K resolution. Chromecast is cost-effective, requires no extra hardware, and is secure for professional use. Users simply tap the Chromecast icon on their smart device to start streaming content from thousands of cast-enabled apps-their smart device becomes the remote.

### Google Play Store access

Full access to the entire Google Play Store makes it easy to add apps, games, music, movies, and more to your Philips Professional Display. New business tools and extra entertainment options are added to the catalogue daily, ensuring that you always have access to the latest global trends.

### Customisable UI

Philips MediaSuite features a clear, easy-to-navigate user interface (UI) that can be customised with your own branding. Easily add your logo and colours to the search bar to increase the presence of your brand.

### Analytics on-board

From hotel chain to sports bar, monitor how each Android-powered Philips MediaSuite TV in your fleet is being used. Find out how often specific channels are watched. Test the effectiveness of your advertising. Get the information you need to manage costs effectively, with easy access to screen-time data. Launch instant customer satisfaction surveys for valuable feedback from guests on the spot.

### AppControl

Take full, centralised control of the apps installed on your Philips Professional Displays. AppControl lets you install, delete, and manage apps on selected Displays or your entire network so that you can offer personalized experiences to your guests and customers-no matter how many displays you are managing.

### CMND & Control

Run your display network over a local (LAN or RF) connection. CMND & Control allows you to perform vital functions like updating software and settings, as well as monitoring display status. Whether you're in charge of one TV or more, CMND & Control makes managing your fleet easy.

### CMND & Check-in

Make visitors feel welcome. CMND & Check-in lets you use individual information-such as name and language spoken-to create a personalized experience. Whether you're adding special touches for hotel guests, streamlining the billing process, or offering multiple channel packages.

### Integrated Netflix

Integrated Netflix access makes watching the latest movies and shows from your account easier, faster and more convenient. There's no need for any external players or satellite TV, which helps keep operational costs down and installations neat, whilst maintaining a modern look for your establishment. A dedicated Netflix button on the remote provides instant access for efficient usability. Terms and conditions apply for Netflix activation.

### Google Assistant™

Voice control and faster answers are here with the optional Google Assistant™ enabled remote control (22AV2025B/00). Open YouTube. Turn the volume up. Play your favourite songs, and get all the info you need such as weather updates, things to do, and even spoken translations in an instant. With Google Assistant™, the possibilities are endless.

## Specifications

[field not found 'disclaimer\_text']

### Picture/Display

Display	4K Ultra HD LED
Diagonal screen size (metric)	108 cm
Diagonal screen size (inch)	43 inch
Panel resolution	3840x2160p
Brightness	350 cd/m <sup>2</sup>

### Audio

Sound output Power Speakers	20 (2x10) W 2.0 Down Firing
Bathroom speaker out	1.5W Mono 8Ohm
Sound Features	DTS-HD Dolby Atmos Compatible Dolby MS12D AC-4 DTS Studio Sound

### Design

Colour	Silver
--------	--------

### Android TV

Memory size(Flash)	16GB*
OS	Android TV™ 9 (Pie)
Pre-installed apps	Netflix* YouTube Google Play Store* Google Play Movies

Google Play Games  
YouTube Music

### Tuner/Reception/Transmission

Digital TV	DVB-T/T2/C HEVC UHD (up to 2160p60)
Analog TV	PAL
IP Playback	Multicast Unicast HLS OTT App Channels

### Wireless Connectivity

Wireless LAN	802.11 ac Wifi-Direct
--------------	--------------------------

### Connectivity Side

Common Interface Slot	CI+ 1.3.2
USB1	USB 3.0
Headphone out	Mini-Jack
HDMI1	HDMI 2.0 with HDCP 2.2

### Connectivity Bottom

External power	12V, max 1.5A
Ethernet (LAN)	RJ-45
Antenna	IEC-75
Bathroom speaker out	Mini-Jack
External Control	RJ-48
USB2	USB 2.0

HDMI3 HDMI 2.0 with HDCP 2.2  
HDMI2 HDMI 2.0 with HDCP 2.2

**Connectivity Enhancements**

HDMI ARC (all ports)  
Auto Input Selection  
EasyLink (HDMI CEC) One touch play  
System Standby  
RC pass through  
system audio control  
RJ48 IR-In/Out  
Serial Xpress interface

**Hospitality Features**

Sharing Chromecast Ultra built-in  
Secure Sharing  
Your brand Network-managed Sharing  
Customizable Home Screen  
Customizable Welcome App  
Location Name (Geonames ID)  
CMND&Create  
Custom Dashboard (HTML&APK)  
Convenience Google Assistant\*  
Google Account Login  
Weather Forecast  
>40 Supported Menu Languages  
Clock in OFF mode  
Theme TV  
Wake Up Alarm  
Sleep Timer  
CMND&Control Off-Line Channel Editor  
Off-Line Settings Editor  
Remote Management over IP/RF  
TV Group management  
Local Updates via USB  
Instant Initial Cloning  
CMND&Check-In Guest Name  
Guest Language  
Messages  
Bill on TV  
Express Checkout  
Remote Control Low Battery Detection  
RC Battery Door Lock  
Glow-in-the-Dark Clock button  
Control AppControl  
JEDI Native Android TV Control  
JSON API for TV Control-JAPIT  
Serial Xpress Protocol  
Crestron Connected  
Joystick  
Interactive DRM VSecure  
Playready Smoothstreaming  
Securemedia  
Power control Quick Start Mode  
Auto Power ON  
Auto Power OFF  
Revenue generation MyChoice  
Hotel mode Switch-ON Settings Control  
Volume limitation  
Installation Menu Lock  
Menu lock  
Joystick Control Lock  
Prison mode

**Healthcare features**

Control Multi-Remote Control  
Nurse call system compatible  
Convenience TalkBack  
Independent main speaker mute  
Safety Double isolation class II  
Flame retardant

**Multimedia**

Video playback supported Formats: H.264/MPEG4 AVC  
MPEG1  
MPEG2  
MPEG4  
WMV9/VC1  
HEVC  
Containers: AVI, MKV  
VP9  
Subtitle formats supported SRT  
SMI  
TXT  
Music formats supported MP3  
AAC  
WAV  
WMA (v2 up to v9.2)  
WMA-PRO (v9 and v10)  
Picture formats supported JPG  
PNG  
BMP  
GIF

**Supported Display Resolution**

HDMI 1/2 Up to 3840x2160p @60Hz  
HDMI 3 Up to 3840x2160p @30Hz  
Tuner Others: up to 1920x1080p@60Hz  
T2 HEVC: up to 3840x2160@60Hz  
HEVC: up to 3840x2160@60Hz  
Others: up to 1920x1080p@60Hz

**Accessories**

Included Tabletop Swivel stand  
Remote Control 22AV1905B/00  
2x AAA batteries  
Power Cord  
Warranty Leaflet  
Optional Legal and Safety brochure  
Voice RC 22AV2025B/00  
Digit RC 22AV2005B/00  
Easy RC 22AV1601B/12  
Healthcare RC 22AV1604B/12  
External Clock 22AV1860A/12  
DOCSIS Cable Modem 22AV1970A  
Setup RC 22AV9574A/12

**Power**

Mains power AC 220-240V; 50-60Hz  
Energy Label Class G  
EPREL registration number 341921  
Eu Energy Label power 60 W  
Standby power consumption <0.3W  
Power Saving Features Eco mode  
Ambient temperature 0 °C to 40 °C

**Dimensions**

Set Width 964 mm  
Set Height 561 mm  
Set Depth 60/75 mm  
Set width (with stand) 964 mm  
Set height (with stand) 594 mm  
Set depth (with stand) 190 mm  
Product weight 9.5 kg  
Product weight (+stand) 11.5 kg  
Wall mount compatible M6  
200 x 200 mm

- \* Netflix: specific terms and conditions apply which have to be approved and applied in order to enable the app.
- \* Availability of Google Assistant is depending on Country and Language settings. To use Google Assistant, an optional remote control with voice function must be used.
- \* Availability of features will depend on implementation chosen by integrator.
- \* Philips does not guarantee the availability or continuity of correct functioning of apps.
- \* Actual free memory may be less due to device pre-configuration
- \* Typical on-mode power consumption measured according to IEC62087 Ed 2. The actual energy consumption will depend on how the television is used.
- \* This television contains lead only in certain parts or components where no technology alternatives exist in accordance with existing exemption clauses under the RoHS Directive.
- \* Android, Google Play and Chromecast are trademarks of Google LLC



data subject to change  
2022, December 28

Version: 3.0.1  
EAN: 8718863023877

© 2022 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)