

### **Professional TV**

50" B-Line

powered by Android™



50BFL2214

# **Professional productivity**

### with Chromecast built-in and HDMI hotplug

Boost productivity. Philips B-Line seamlessly integrates into corporate systems for efficient control. Chromecast built-in ensures presentations run smoothly with instant wireless media sharing from Windows, Apple and Android™ devices.

#### **Smart control features**

- Compatible with Extron and Neets systems
- Crestron Connected certified system integration
- Install and manage apps remotely with AppControl
- Operate, monitor and maintain via CMND & Control
- Scheduler for content playback at selected times
- Create, control and schedule with Philips Publisher
- Can tune TV channels, including ATSC, QAM and IPTV

#### **Vibrant and efficient**

- · Android updates provide the latest functionality
- Google Play Store access for apps and media
- HDMI hotplug detection with auto on/off function
- Supports Pro:Idiom™ encrypted content
- UHD resolution for attention grabbing content
- · Chromecast built-in for wireless content sharing

Professional TV 50BFL2214/27

# Highlights

#### **Powered by Android**

Android-powered Philips Professional Displays are fast, versatile and easy to navigate. The displays are optimised for native Android apps and you can install web apps directly to the display too. Automatic updates ensure apps stay up to date

#### **Chromecast built-in**

Make meetings run smoother and faster with seamless wireless connectivity to the big screen from any Apple, Windows or Android™ device. Chromecast built-in enables instant casting of presentations and media from mobiles, laptops, and tablets in up to 4K resolution. It's cost-effective, requires no extra hardware, and is secure for corporate use.

#### **Crestron Connected certified**

Connect this Philips Professional Display to your Crestron network for full remote control via your laptop, desktop or mobile device. Switch the display on and off, schedule content, manage settings, and easily connect external devices.

Crestron Connected provides a fast, reliable and secure enterprise level solution for wireless and wired content sharing from Apple, Windows, Android and Linux devices.

#### **Google Play Store access**

Full access to the entire Google Play Store makes it easy to add apps, games, music, movies, and more to your Philips Professional Display. New business tools and extra entertainment options are added to the catalogue daily, ensuring that you always have access to the latest global trends.

#### **HDMI** hotplug detection

When wireless connectivity is not an option, HDMI hotplug detection recognises direct cabled connections from presentation sources and automatically handles source changes and on/off functioning.

#### **AppControl**

Take full, centralised control of the apps installed on your Philips Professional Displays. AppControl lets you install, delete, and manage apps on selected Displays or your entire network so that you can offer personalized experiences to your guests and customers-no matter how many displays you are managing.

#### **CMND & Control**

Run your display network over a local (LAN or RF) connection. CMND & Control allows you to perform vital functions like updating software and settings, as well as monitoring display status. Whether you're in charge of one TV or more, CMND & Control makes managing your fleet easy.

#### **Scheduler for content playback**

Built-in scheduler makes it easy to launch content and apps based on time of day for a more engaging environment with better results.



## Specifications

#### **Picture/Display**

Diagonal screen size (inch): 50 inch Display: 4K Ultra HD LED Panel resolution: 3840x2160p Contrast ratio (typical): 5000:1

Brightness: 300 nit

Operation Mode: Landscape, 16/7

#### **Supported Display Resolution**

HDMI: Up to 3840x2160p@60Hz USB, LAN: HEVC: up to 3840x2160@60Hz, Others: up to 1920x1080p@60Hz

#### **Tuner/Reception/Transmission**

Digital TV: 8VSB ATSC; 256QAM Cable

**Analog TV: NTSC** 

IP Playback: Multicast, Unicast, HLS, OTT App

Channels

#### **Android TV**

OS: Android TV™ 9 (Pie)

Pre-installed apps: YouTube, Google Play Store\*, Google Play Movies, Google Play Games, YouTube

Music

Memory size(Flash): 16GB\*

#### **Corporate Features**

Wired Presentations: Auto Input Selection, Auto

Power ON, Auto Power OFF

Wireless Presentations: Chromecast built-in, Secure Sharing, Network-managed Sharing Signage Functions: CMND&Create, Scheduler,

Banners

Control: Crestron Connected (v2), Extron, SICP

over IF

Customizable: Home Screen, Location Name,

43.82

**Device Name** 

#### **Professional TV Features**

Professional Mode: Installation Menu Lock, Menu Lock, Switch-ON Settings Control, Volume

Limitation

Control: AppControl, CMND IP Remote

Management, JAPIT HTML5 Control, JEDI Android

**API Control** 

Convenience: >40 Supported Menu Languages, Google Account Login, Google Assistant\*,

Weather Forecast

Safety: Double Isolation Class II, Flame Retardant

**DRM**: Pro:Idiom, VSecure

#### **Multimedia**

Video playback supported: Formats: H.264/MPEG4 AVC, MPEG1, MPEG2, MPEG4, WMV9/VC1, HEVC, Containers: AVI, MKV, VP9 Music formats supported: MP3, AAC, WAV, WMA (v2 up to v9.2), WMA-PRO (v9 and v10) Subtitle formats supported: SRT, SMI, TXT Picture formats supported: JPG, PNG, BMP, GIF

#### Audio

Sound output Power: 20 (2x10) W

Speakers: 2.0, Down Firing

Sound Features: DTS-HD, Dolby Atmos Compatible, Dolby MS12D, AC-4, DTS Studio

Sound

External speaker out: 1.5W Mono 8 Ohm

### Power

Mains power: AC 110-240V; 50-60Hz

Ambient temperature: 0°C to 40°C (32°F to 104°F)

Standby power consumption: <0.5 W

Power Saving Features: Eco mode, Auto switch-off

timer

Maximum Power Consumption: 120 W

#### **Green Specifications**

**Energy Star** 

#### **Accessories**

Included: Remote Control 22AV1905A/12, 2x

AAA batteries, Power Cord

Optional: Setup RC 22AV9574A/12

#### **Wireless Connectivity**

Wireless LAN: 802.11 ac, Wifi-Direct

#### **Connectivity Bottom**

Antenna: F-Type

Digital Audio out: Optical Ethernet (LAN): RJ-45

HDMI3: HDMI 2.0 with HDCP 2.2

**USB2:** USB 2.0

External power: 12V, max 1.5A HDMI4: HDMI 2.0 with HDCP 2.2 External speaker out: Mini-Jack

#### **Connectivity Side**

HDMI1: HDMI 2.0 with HDCP 2.2 HDMI2: HDMI 2.0 with HDCP 2.2 Headphone out: Mini-Jack

**USB1:** USB 3.0

#### **Connectivity Enhancements**

EasyLink (HDMI CEC): One touch play, System Standby, RC pass through, system audio control HDMI: ARC (all ports), Auto Input Selection

#### Design

Colour: Black

#### **Dimensions**

Wall mount compatible: 200 x 200 mm, M6

Set Width (inch): 43.82 inch Set Height (inch): 25.49 inch Set Depth (inch): 3.35 inch Product weight (lb): 23.0 lb



© 2025 Koninklijke Philips N.V. All Rights reserved. Issue date 2025-05-30 Version: 3.3.2

UPC: 8 71886 30020 7

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

UPC: 8 /1886 30020

www.philips.com



- \* Availability of features will depend on implementation chosen by integrator.
- Philips does not guarantee the availability or continuity of correct functioning of apps.
- \* Actual free memory may be less due to device preconfiguration
- \* This television contains lead only in certain parts or components where no technology alternatives exist in