

Philips widescreen flat TV with Pixel Plus

81 cm (32") LCD integrated digital

32PF7611D



Turn up your viewing experience

with Digital Tuner and Pixel Plus

Digital TV does not get much better! This Flat TV has Pixel Plus for breathtaking natural pictures, Active Control for optimum brightness, Electronic Program Guide for digital TV combined in a contemporary design.

Breathtaking natural pictures

- HD LCD WXGA display, with a 1366 x 768p resolution
- Integrated Digital Tuner for DVB-T reception
- HD Ready for the highest quality display of HD signals
- · Pixel Plus for detail, depth and clarity

Superb sound reproduction

· Virtual Dolby Surround for a cinema-like audio experience

Slim, stylish design to complement your interior

• Compact and slim design that fits in every room

Designed for your convenience

• Watch analog TV while recording a digital program

For advanced performance

• HDMI input for full digital HD connection in one cable



Highlights

LCD WXGA display, 1366 x 768p

This WXGA display with state-of-the-art LCD screen technology gives you widescreen HD resolution of 1366 x 768p pixels. It produces brilliant flicker-free progressive scan pictures with optimum brightness and superb colors. This vibrant and sharp image will provide you with an enhanced viewing experience.

Integrated Digital DVB-T tuner

The integrated Digital DVB-T tuner lets you receive digital terrestrial TV without an additional set top box. Enjoy quality TV clutter free.

HD Ready

Enjoy the exceptional picture quality of High Definition pictures and be fully prepared for HD sources like HDTV settop box or Blu-ray disc. HD Ready is a protected label that offers picture quality beyond that of progressive scan.

It conforms to strict standards laid out by EICTA to offer a HD screen that displays the benefits of resolution and picture quality of a High Definition signal. It has a universal connection for both analog YPbPr and uncompressed Digital connection of DVI or HDMI, supporting HDCP. It can display 720p, and 1080i signals at 50 and 60Hz.

Pixel Plus

Pixel Plus is a digital picture processing technology that increases the number of lines and the number of pixels. The result is razor sharp pictures with incredible detail and depth, every time from any source.

Virtual Dolby Surround

Virtual Dolby Surround is a processing technology for enhancing surround sound effects. It will create the sensation of Dolby Pro Logic without the necessity of additional rear speakers. You become totally immersed in your television experience.

Watch analog, record digital

Watch analog TV while recording a digital program

HDMI input

HDMI makes an uncompressed digital RGB connection from the source to the screen. By eliminating conversion to an analog signal, it delivers an unblemished image. The non-degraded signal reduces flicker and leads to a clearer picture. HDMI intelligently communicates the highest output resolution with the source device. The HDMI input is fully backward compatible with DVI sources but includes digital audio. HDMI uses HDCP copy protection.













Specifications

Picture/Display

- Aspect ratio: 16:9
- Brightness: 500 cd/m²
- Contrast ratio (typical): 800:1
- Dynamic screen contrast: 3200:1
- Response time (typical): 8 ms
- Viewing angle: 176° (H) / 176° (V)
- Diagonal screen size: 32 inch / 80 cm
- Display screen type: LCD WXGA Active Matrix
 TET
- Panel resolution: 1366 x 768p
- Picture enhancement: Pixel Plus, 3/2 2/2 motion pull down, 3D Combfilter, Active Control, Color Temperature Adjustment, Contrast Plus, Digital Noise Reduction, Jagged Line Suppression, Luminance Transient Improver, Progressive scan, Pulse Killer Chip, Sharpness Adjustment
- Color cabinet: Black Gloss with Tempered Glass Deco Front
- Screen enhancement: Anti-Reflection coated screen

Supported Display Resolution

Computer formats

Resolution	Refresh rate
640×480	60, 67, 72, 75Hz
720×400	70Hz
800×600	56, 60, 72, 75Hz
1024 x 768	60. 70. 75Hz

Video Formats

Video i oi illats	
Resolution	Refresh rate
640 x 480i	1Fh
$640 \times 480p$	2Fh
720 x 576i	1Fh
$720 \times 576p$	2Fh
$1280 \times 720p$	3Fh
1920 x 1080i	2Fh

Sound

- Equalizer: 5-bands
- Output power (RMS): 2 x 15 W
- Sound Enhancement: Dynamic Bass Enhancement
- Sound System: Stereo, Virtual Dolby Surround

Loudspeakers

- Built-in speakers: 4
- · Loudspeaker types: Dome tweeter

Tuner/Reception/Transmission

- Aerial Input: 75 ohm coaxial (IEC75)
- · Video Playback: NTSC, PAL, SECAM
- Digital TV: DVB Terrestrial
- Tuner bands: Hyperband, S-Channel, UHF, VHF
- Number of Preset Channels: 100
- Tuner Display: PLL

Connectivity

- Ext 2 Scart: RGB out, S-video in
- Number of Scarts: 2
- Ext 4: YPbPr
- Ext 5: HDMI
- Ext 6: HDMI
- Front / Side connections: Audio L/R in, CVBS in, Headphone Out, S-video in
- Other connections: S/PDIF out (coaxial), Common Interface

Convenience

- Clock: Sleep Timer, Wake up Clock
- Ease of Installation: Auto Program Naming, Automatic Channel Install(ACI), Automatic Tuning System (ATS), Autostore, Fine Tuning, Plug & Play, Program Name, Sorting
- Ease of Use: Auto Volume Leveller (AVL), Easy toggle Dig/Analog modes, Program List, Side Control, Smart Picture, Smart Sound, Watch analogue/record digital
- Picture in Picture: Picture in graphics
- Remote Control: TV, DVD
- Remote control type: RC4343/01
- Screen Format Adjustments: 4:3, Movie expand 14:9, Movie expand 16:9, Subtitle Zoom, Super Zoom, Widescreen
- Teletext: 1000 page Smart Text
- Teletext enhancements: 4 favourite pages, Program information Line

Accessories

- Included accessories: Table top stand, Power cord, Quick start guide, User Manual, Registration card, Warranty certificate, Remote Control, Batteries for remote control
- · Optional accessories: Floor stand

Dimensions

- Set dimensions (W \times H \times D): 935 \times 516.5 \times 120 mm
- Dimensions (with base) (H x D): 558 x 233 mm
- Weight incl. Packaging: 22.5 kg
- Product weight: 19.2 kg
- Box dimensions (W x H x D): 1012 x 698 x 240 mm
- VESA wall mount compatible: 200 x 100 mm

Power

- Ambient temperature: 5 °C to 40 °C
- Mains power: AC 220 240 V +/- 10%
- Power consumption: TBC W
- Power supply: AC 90-240
- Standby power consumption: < 1 W









Issue date 2019-06-28

© 2019 Koninklijke Philips N.V. All Rights reserved.

Version: 1.0.4

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 24294 EAN: 87 10895 97978 8

www.philips.com