

Professional TV

- EasySuite
- Full HD 1080p

50HFL3014/12



## Take control

Powered by CMND

Show more with a budget-friendly standalone professional TV. The intuitive CMND solution makes it simple to deploy and manage connected displays. Benefit from simple, fast installation and an on-screen welcome page that's easy to program.

### Benefits

#### Simple set up. **ADVANCED** performance

- CMND and Control: effortless maintenance of your TVs
- MyChoice compatible. Built-in pay-to-view solution
- Be seen. Brand the TV's UI with your logo
- Instant initial USB cloning. Rapidly configure Pro TVs
- Mixed channel map to combine analogue and digital channels
- USB auto playback. Music, movies, and more

#### Cost-effective solution

- 3 years warranty, extendable to 5 years
- Multilingual customer support

#### Sustainable and safe

- Low power consumption

**PHILIPS**

## Features

### CMND&Control

CMND and Control allows for remote configuration and installation of your TVs from a central location, without the need to visit any rooms. Update and manage all your displays, with minimal effort, all without having to disturb your guests.

### Built-in pay-to-view solution

Offer pay-to-view content in any situation-from a complete pay-to-access-all-channels model to selected premium content. MyChoice is an integrated solution that allows viewers to access pay-per-view channels via a code or a card.

### UI branding

Your Philips Professional TV offers a clear, easy-to-navigate user interface (UI), which you can customize with your own branding. Easily add your logo or custom background to the menu to increase the visibility of your brand.

### Instant initial USB cloning.

Provides the ability to easily copy all programming and channel programming settings from one TV into other TV sets in less than a minute. The feature ensures uniformity between TV sets and significantly reduces installation time and costs.

### Mixed channel map

One integrated channel list for digital and analogue channels. This allows the guest to flick seamlessly between Analogue and Digital channels.

### USB auto playback.

Share the fun. Connect your USB memory-stick, digital camera, mp3 player or other multimedia device to the USB port on your TV to enjoy photos, videos and music with the easy to use onscreen content browser.

## Specifications

[field not found 'disclaimer\_text']

### Picture/Display

Display	LED Full HD D-LED
Diagonal screen size (metric)	126 cm
Diagonal screen size (inch)	50 inch
Panel resolution	1920x1080p
Brightness	250 cd/m <sup>2</sup>
Viewing angle	178° (H) / 178° (V)

### Audio

Sound output Power Speakers	16 (2x8) W 2.0 Down Firing
Sound Features	AVL Dynamic Bass Incredible surround Dolby MS10

### Design

Colour	Black
--------	-------

### Tuner/Reception/Transmission

Digital TV	DVB-T/T2/C HEVC FHD (up to 1080p60)
Analog TV	PAL SECAM
Video Playback	NTSC PAL SECAM

### Connectivity Rear

Antenna	IEC-75
HDMI1	ARC HDMI 1.4
HDMI2	HDMI 1.4
Digital Audio out	Optical
DVI audio in	Mini-Jack
VGA input	15 pin D-sub
Scart	CVBS RGB

### Connectivity Side

Common Interface Slot	CI+ 1.3.2
Headphone out	Mini-Jack
USB1	USB 2.0

### Connectivity Enhancements

HDMI EasyLink (HDMI CEC)	ARC (HDMI1) One touch play System Standby RC pass through system audio control
Scart	Power on scart

### Features

Digital services	8d EPG Now&Next MHEG Teletext Subtitles
Ease of use	Picture Style Sound Style Picture Format Independent volume control
Local control	Joystick

### Hospitality Features

Hotel mode	Joystick Control Lock Menu lock Installation Menu Lock Volume limitation
Prison mode	high security mode TXT/MHEG/USB/EPG/Subtitle Lock
CMND&Control	Remote Management over RF TV Group management Off-Line Settings Editor Off-Line Channel Editor
Your brand	Customizable Home Screen Welcome Logo
Revenue generation	MyChoice Instant Initial Cloning Via USB/RF
Cloning and Firm-ware update	Sleep Timer Wake Up Alarm Wake Up On Channel Wake up Sounds
Timer	On-screen Clock Glow-in-the-Dark RC button
Clock	Combined List Off-Line Channel Editor
Channels	Block Automatic Channel Update Green/fast startup
Control	Channel Feature
Power control	
Switch On control	

	Picture Format	Supp. Video Resolu- tion on USB	up to 1920x1080p@60Hz
	Picture Style		
	Sound Style		
	Volume		
Remote Control	Menu language	<b>Accessories</b>	
	Cable Strap Ready	Included	Edge Stand 2x AAA batteries Power Cord Warranty Leaflet Legal and Safety brochure
Anti-Theft	Low Battery Detection		Remote Control 22AV1903A/12
	RC Battery Door Lock		Easy RC 22AV1601B/12
	Glow-in-the-Dark Clock button		Healthcare RC 22AV1604B/12
	Battery Anti-theft Protection	Optional	Setup RC 22AV9574A/12
Languages	Kensington Lock		
	Guest language control		
<b>Healthcare features</b>			
Control	Multi-Remote Control	<b>Power</b>	
	Healthcare RC compatible	Mains power	AC 220-240V; 50-60Hz
Convenience	Headphone out	Energy Label Class	E
	Independent main speaker mute	EPREL registration number	341985
	Headphone Detection	Eu Energy Label power	46 W
Safety	Double isolation class II	Standby power consumption	<0.3W
	Flame retardant	Power Saving Features	Eco mode Auto switch-off timer
		Ambient temperature	0 °C to 40 °C
<b>Multimedia</b>			
Multimedia connec- tions	USB	<b>Dimensions</b>	
Video playback supported	Formats: H.264/MPEG4 AVC MPEG1 MPEG2 MPEG4 WMV9/VC1 HEVC MP4 MPG WMV TS	Set Width	1128 mm
	Containers: AVI, MKV	Set Height	655 mm
Subtitle formats supported	SRT SMI SSA SUB TXT ASS	Set Depth	81/86 mm
	MP3	Set width (with stand)	1128 mm
Music formats supported	AAC WAV WMA (v2 up to v9.2)	Set height (with stand)	679 mm
	BMP	Set depth (with stand)	214,5 mm
Picture formats supported	JPG PNG GIF	Product weight	11.3 kg
		Product weight (+stand)	11.6 kg
		Wall mount compat- ible	200 x 200 mm M6

\* Availability of features will depend on implementation chosen by integrator.

\* Philips does not guarantee the availability or continuity of correct functioning of apps.

\* Typical on-mode power consumption measured according to IEC62087 Ed 2. The actual energy consumption will depend on how the television is used.

\* This television contains lead only in certain parts or components where no technology alternatives exist in accordance with existing exemption clauses under the RoHS Directive.



data subject to change  
2022, September 8

Version: 4.1.1  
EAN: 8718863021934

© 2022 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)