

Philips commercial flat HDTV

- 94 cm (37")
- LCD
- HDTV monitor

37HF7544D

Picture the Interactive possibilites

with the Philips Flat LCD HDTV

This Pro:idiom equipped LCD TV delivers a superior picture for your guests. Philips' advanced LCD technologies produce razor sharp images and brilliant colors. The SmartPlug interface provides seamless pay-per-view sytem connectivity.

System ready and future proof

- HD content protection $Pro:Idiom^{TM}$
- · Compatible with all major PPV systems
- SmartPlug Xpress interface

Best total cost of ownership

- Smart Cloning
- External loudspeaker connector
- · Installation menu locking

Maximum guest comfort

- · Welcome message on screen display
- Volume limitation
- Switch On Channel Programming

Great viewing experience and guest comfort

· HDTV for Hospitality



Specifications

Picture/Display

- · Aspect ratio: Widescreen
- Color cabinet: Silver Frost & Black Deco Front
- Brightness: 500 cd/m²
- Contrast ratio (typical): 800:1
- Diagonal screen size: 37 inch / 94 cm
- Display screen type: LCD WXGA Active Matrix
- Picture enhancement: Progressive scan, 3/2 2/2 motion pull down, Digital Noise Reduction, Jagged Line Suppression, Active Control, Luminance Transient Improver, Dynamic contrast
- · Screen enhancement: Anti-Reflection coated screen
- Viewing angle (H / V): 176 / 176 degree
- Panel resolution: 1366 x 768p
- Response time (typical): 8 ms

Supported Display Resolution

Video Formats

Resolution Refresh rate 640 x 480i 1Fh $640 \times 480p$ 2Fh 720 x 576i 1Fh $720 \times 576p$ 2Fh $1280 \times 720p$ 3Fh 1920 x 1080i 2Fh

• Computer formats

Resolution Refresh rate 1024×768 60Hz 60, 67, 72, 75Hz 640×480

 800×600 56, 60, 72, 75Hz

Sound

- · Sound Enhancement: Auto Volume Leveller
- · Sound System: Stereo, Virtual Dolby Surround
- Output power (RMS): 2 x 15W

Convenience

- Ease of Installation: Fine Tuning, PLL Digital Tuning, Wireless Smart Loading, Program Name, Advanced Hotel Mode
- · Ease of Use: Auto Volume Leveller (AVL), Smart Picture, Smart Sound
- · Screen Format Adjustments: Auto Format, Widescreen
- · Clock: Sleep Timer
- VESA Mount: 800 x 400 mm
- Comfort: Hotel Guest features
- On-Screen Display languages: English, French, Spanish

Tuner/Reception/Transmission

- Tuner bands: Hyperband, S-Channel, UHF, VHF
- TV system: NTSC, ATSC
- · Video Playback: NTSC, PAL
- · Aerial Input: 75 ohm coaxial (IEC75)
- Tuner Display: PLL
- Number of Preset Channels: 125
- · Cable: Unscrambled Digital Cable QAM
- Terrestrial: ATSC (8VSB)

Connectivity

- Number of AV connections: 5
- AV 1: YPbPr (2fh), Audio L/R in
- · AV 2: CVBS, Audio L/R in
- AV 3: VGA PC-in, YPbPr (2Fh), Audio L/R in
- AV 4: HDMI
- AV 5: HDMI
- Front / Side connections: CVBS in, S-video in, Audio L/R in
- Connectivity Enhancements: RI12 connector, RI45 connector, HM-Link, SmartCard Xpress box ready, External Loudspeaker connector
- · Other connections: Audio constant level out, PCin VGA + Audio L/R in, Antenna IEC75

Power

- Power consumption: 235 W
- Ambient temperature: 5 °C to 40 °C
- Mains power: 120V, 50-60Hz
- Standby power consumption: 2 W <

Dimensions

- Set dimensions in inch (W x H x D): $43.5 \times 24.02 \times 5.59$ inch
- Set dimensions with stand in inch (W x H x D): $43.5 \times 25.51 \times 9.41$ inch
- Box dimensions in inch (W x H x D): $45.67 \times 32.01 \times 11.42$ inch
- Product weight (lb): 59.41
- Weight incl. Packaging (lb): 79.26
- VESA wall mount compatible: 800 x 400 mm

Accessories

- Included accessories: Power cord, Table top stand, Wall mounting bracket
- Optional accessories: Wireless SmartLoader 22AV1120, Wired SmartLoader 22AV1125, Guest remote control, Set up Remote RC2573GR, Mounting brackets/ stands

Loudspeakers

• Built-in speakers: 2













Highlights

HDTV for Hospitality

There are many ways you may choose to offer HDTV to your guests, but regardless of the source, Philips Hospitality televisions will always deliver the best viewing experience possible to your guests by utilizing the most advanced FlatTV displays and award winning technologies such as Pixel Plus 3 HD.

HD content protection

Content protection technology specially created for the hospitality industry which allows guest to enjoy first run movies and other premium content in true HD quality. (Pro:Idiom™ is a trademark of Zenith Corp.)

Smart Cloning

Philips offers the most flexible and easiest cloning options for hospitality applications. Take advantage of wireless or wired cloning convenience to quickly and easily copy all TV settings from one set to all others in a system configuration.

PPV system compatiblePhilips Hospitality sets are designed to be compatible with all major Pay Per View systems, including, but not limited to, LodgeNet, OnCommand, NxTV, GuesTek, nStreams, Hospitality Network, and KoolConnect. This guarantees seamless integration in almost any system configuration.

SmartPlug Xpress

The SmartPlug Xpress communication port (RJ-12) is compatible with all major premium entertainment services. The protocols enables the TV connection with external decoders, set-top boxes and PC based solutions.

External loudspeaker connector

Amplified audio connector for easy installation of external speakers (like for bathrooms), eliminating the need for investments in external equipment

Installation menu locking

Prevents unauthorized access to installation and configuration settings, to ensure maximum guest convenience and avoid unnecessary reprogramming

Welcome message

A welcome greeting is displayed each time the TV set is switched on.

Volume limitation

This feature predefines the volume range with which the TV set is allowed to operate, preventing excessive volume adjustments and avoiding disturbance of next door guests.



Issue date 2013-06-22

© 2013 Koninklijke Philips N.V. All Rights reserved.

Version: 3.2.8

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 24051 UPC: 6 09585 11454 8

www.philips.com