

Philips Hospitality LCD TV

LCD b-LAN™, Pro:Idiom®, MPEG-4



32HFL5561L

Experience Hospitality TV

The L (Synergy) Series

The Philips L Series is a turnkey solution featuring our V series television, Meet the Truck professional installation, a Philips Smart Gateway, and an additional year advanced exchange warranty (3 total).

Sustainable solutions

- SmartPower³ for the best picture and ultra low power use
- ENERGY STAR® qualified product
- Eco-friendly design & flame retardant housing

Guest experience

- ThemeTV simplifies channel selection
- SmartCP integrated connectivity for the guest
- SmartWindow for simultaneous TV viewing and PC use.

Operational excellence

- · SmartInstall allows easy installation, cloning and setup
- SmartUpdate keeps TV channels, settings and software current
- Integrated two-way b-LAN[™] communication with PPV support
- SmartStand² for security and elegance
- · Additional year advanced exchange warranty
- Live customer support 7 days a week



Highlights

Additional year warranty

Philips offers unmatched commitment to keeping your guest rooms in working order. This product is sold as part of our turnkey solution which includes our Meet the Truck professional installation. As an additional benefit, since a Philips partner installed the television, we extend the warranty for one additional year (for a total of three years) to provide even more peace of mind.

Eco-friendly design

Sustainability is integral to the way Philips does business. Philips TVs are designed and produced according to our EcoDesign principles aimed at minimizing overall environmental impact, through lower power consumption, removal of hazardous substances, lower weight, more efficient packaging and better recyclability. Philips TVs also have a special housing of flame retardant material. Independent tests carried out by emergency fire services have shown that whereas TVs can sometimes intensify fires caused by external sources, Philips TVs will not contribute to the fire.

ENERGY STAR®



This product has earned the ENERGY STAR®. ENERGY STAR qualified products meet or exceed the guidelines established by the U.S. govenment for in-use and standby power consumption, at the time of manufacture. Learn more at ENERGYSTAR.gov.

Everyday support (USA-based)

Your hotel never closes, and neither do we. Philips offers you real help from a live person 7 days a week, excluding major holidays.

Integrated two-way b-LAN™

Philips televisions feature the LodgeNet Interactive b-LAN™ communication protocol built into the TV. This allows for simple and reliable cloning, customizing, and updating of our products. By integrating b-LAN™, these televisions also work right out of the box in all LodgeNet® systems, without any need for terminals or cards.

SmartCP autosensing inputs

Allowing your guests to access their content has never been easier or more affordable. Guests can simply plug devices into our easily accessible side connectivity panel and the television will automatically detect and switch to the correct input. Guests can even plug their USB memory sticks right into the set and play back music or photos (.mp3 or .jpg files).

SmartInstall

Philips introduces SmartInstall, the most complete and easy to use installation process we have ever offered. SmartInstall consists of an easy to use PC program that allows all features to be configured and all channels to be mapped in a fraction of the time it takes to do so on an actual television with a remote. And with the addition of the Philips Smart Gateway, the televisions can even automatically clone all settings when plugged in.

SmartPower³ with AutoSense

SmartPower³ allows the backlight intensity to be varied based on real time picture measures and actual room lighting conditions to deliver the best possible picture at the lowest possible energy consumption.

SmartStand²

Philips unique SmartStand² is a complete commercial solution, offering 180 degree

swivel that can be limited in either or both directions to 30, 60, or 90 degrees. The stand includes a securable mounting plate that can be affixed either using security screws or non-drill adhesive. In addition, all security hardware for drill and non-drill mounting is included on select models (check with your Philips representative for specific models).

SmartUpdate

Philips televisions are the first to automatically keep themselves updated. All SmartUpdate featured Philips commercial televisions on the property can automatically check for and download updated channel maps, settings, and/ or software. Philips televisions update in the background when new files are found, and as a result, the guest experience has minimal disruption. SmartUpdate requires a Philips Smart Gateway to operate.

SmartWindow

SmartWindow allows your guests the added convenience of working on their laptop PC's on one half of the screen while enjoying the TV content of their choice on the other half. This feature offers the perfect balance of work and leisure.

ThemeTV

Hotel guests often have difficulty locating desirable programs since they are unfamiliar with the channel lineup. Traditional Electronic Program Guides (EPGs) are little help as the guest has to scroll through multiple pages to find channels. In addition, traditional EPGs require hotels to pay fees for channel information on a per room basis. Philips is proud to introduce a better program-location tool with ThemeTV. Guests simply filter by type of channel, for example "Sports" and instantly see and tune to any Sports channel available. Guests are seconds away from desirable content.

















Specifications

Picture/Display

- · Aspect ratio: 16:9, Widescreen
- · Color cabinet: Black
- Brightness: 500 cd/m²
- · Contrast ratio (typical): 1100:1
- Dynamic screen contrast: 8800:1
- Diagonal screen size: 32 inch / 80 cm
- Picture enhancement: Pixel Plus 3 HD, Progressive scan, 3/2 - 2/2 motion pull down, 3D Combfilter, Dynamic contrast enhancement, Contrast Plus, Digital Noise Reduction, Jagged Line Suppression, Luminance Transient Improver, Color Transient Improvement, Automatic skin tone correction, Color Enhancement, Motion adaptive de-
- interlacing, Active Control + Light sensor
 Screen enhancement: Anti-Reflection coated
- Display screen type: LCD WXGA Active Matrix
- Panel resolution: 1366 x 768p
- Response time (typical): 8 ms
 Viewing angle: 178° (H) / 178° (V)

Supported Display Resolution

Computer formats

Video formats

 Resolution
 Refresh rate

 480i
 60Hz

 480p
 60Hz

 720p
 60Hz

 1080i
 60Hz

1080p 24, 25, 30, 50, 60Hz

Sound

- Sound System: Stereo, Dolby Digital (AC-3)
- Output power (RMS): 2 x 10W
- Sound Enhancement: Auto Volume Leveller, Incredible Surround, Treble and Bass Control

Loudspeakers

• Built-in speakers: 2

Convenience

- Ease of Installation: Fine Tuning, PLL Digital Tuning, Program Name, Advanced Hotel Mode, Cloning of TV settings via USB, Keyboard lock-out, Security menu access
- Ease of Use: Auto Volume Leveller (AVL), Smart Picture. Smart Sound
- Screen Format Adjustments: 4:3, 7 Widescreen Modes
- Comfort: Hotel Guest features, Sleep timer, Switch on channel, Volume limitation, Welcome message
- User convenience: Closed captioning (digital),
 Vchip and parental lock
- Interactive hotel features: Connectivity panel compatible, Remote diagnostics, SmartClone, SmartGuide, SmartInstall, SmartSecure,

SmartUpdate, SmartWindow, SmartCP, Integrated bLAN, Smoovie Pay TV

• Other convenience: Kensington lock

Tuner/Reception/Transmission

- Tuner bands: Hyperband, S-Channel, UHF, VHF
- TV system: ATSC, NTSC
- Video Playback: NTSC
- Number of Preset Channels: 250
- Cable: Unscrambled Digital Cable -QAM
- Terrestrial: ATSC (8VSB)
- Aerial Input: 75 ohm F-type

Connectivity

- AV 1: Audio L/R in, CVBS in
- AV 2: Audio L/R in, YPbPr
- AV 3: VGA PC-in
- AV 4: HDMI (v1.3 with CEC)
- AV 5: HDMI (v1.3 with CEC)
- AV 6: HDMI (v1.3 with CEC)
- Front / Side connections: Audio L/R in, CVBS in, Headphone Out, S-video in, USB
- Other connections: Antenna F-type, RS232 Serial, S/PDIF out (coaxial)
- Connectivity Enhancements: External Loudspeaker connector, RJ12 SmartPlug connector

Power

- Mains power: 110 240V, 50/60Hz
- Maximum Power Consumption: 150 W
- SmartPower High + AutoSense: 63.4 W
- SmartPower high mode: 65.6 W
- SmartPower Medium + AutoSense: 65.8 W
- SmartPower medium mode: 85.3 W
- SmartPower Low + AutoSense: 77.2 W
- SmartPower low mode: 107.5 W
- SmartPower Off + AutoSense: 82.8 W
- SmartPower Off mode: 115.2 W
 Standby power consumption: < 1 W
- Ambient temperature: 5 °C to 40 °C

Dimensions

- Set dimensions in inch (W x H x D): 31.9 x 20.4 x 3.9 inch
- Set dimensions with stand in inch (W \times H \times D): 31.9 \times 22.4 \times 14.2 inch
- Product weight (lb): 25.4
- Product weight (+stand) (lb): 35.3 lb
- Weight incl. Packaging (lb): 38.6
- \bullet VESA wall mount compatible: 200 x 200 mm
- Box dimensions in inch (W x H x D): 44.2 x 23.4 x 8.3 inch

Accessories

- Included accessories: Warranty Leaflet, Power Cord (3m), Quick start guide, Swivel stand with anti-theft, Security Bolts (Table Stand), Security Screws (Table Stand)
- Optional accessories: Set up Remote RC2573GR, Mounting brackets/ stands, Guest remote control

Multimedia Applications

- Multimedia connections: USB
- Playback Formats: JPEG Still pictures, MP3,



Issue date 2014-10-29

Version: 6.3.7

12 NC: 8670 000 54294 UPC: 6 09585 17448 1 © 2014 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com

Slideshow files (.alb)

Green Specifications

- Safety: Flame retardant housing
- SmartPower²
- Eco Designed
- Energy Star 3.0
- Low Power Standby

- * Advanced Exchange warranty is valid in the United States only. Local warranties govern sales in other countries.
- * LodgeNet and b-LAN are trademarks of LodgeNet Interactive
- * Pro:Idiom is a registered trademark of the Zenith corporation.