


Philips
Professional TV

Remote Control

22AV1604B



Healthcare remote control

Hygienic and easy to clean

Designed for use in healthcare environments, this Philips Professional Remote Control features a simple, colour-coded button layout on an easy-clean surface.

Easy to use. Easy to see.

- Top surface can be cleaned with alcohol
- White design for the healthcare environment

Cost-effective, secure solution

- Lockable battery compartment
- Low-battery detection with TV notification

Smarter by design

- Multi-RC settings memory

PHILIPS

Specifications

Hospitality Features

- Remote Control: Multi-RC Compatible, Studio/ES/MS/Sig compatible, PrimeSuite, RC Battery Door Lock, Cable Strap Ready, Low-Battery Detection

Battery

- Type: 2 x AAA (Not Included)

Dimensions

- Product dimensions (WxDxH): 203 x 48 x 20 mm

Highlights

Top surface can be cleaned

The top surface of this Philips Professional Remote Control is flat, making it easy to clean with alcohol. The flat surface is also hygienic: no raised buttons means no crevices for germs to get into.

White design for healthcare

The white design and rounded edges give this remote a clean, friendly appearance — perfect for use in healthcare environments. Essential buttons are colour-coded and conveniently placed, ensuring ease of operation.

Lockable battery compartment

The lockable battery compartment is secured with a screw, ensuring batteries can only be removed or changed by staff.

Low-battery detection

When the battery in your Philips Professional Remote Control runs low, a notification appears on the TV screen, allowing you to change the batteries before service is affected.

Multi-RC settings memory

Keep your settings exactly the same between battery changes. Multi-RC saves your configuration in a permanent storage for effortless maintenance.



Issue date 2024-03-24

Version: 3.0.1

EAN: 87 18863 01800 2

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com