



Philips 6700 series
4K Ultra Slim Smart LED
TV with Ambilight 3-sided

164 cm (65")

4K Ultra HD LED TV
Quad Core
DVB-T/T2



65PUT6703

Ultra Slim 4K UHD LED Smart TV

with Ambilight 3-sided and Saphi system

Sit back and enjoy the rich quality of 4K UHD on a Smart TV that's brilliantly easy to use. Access favourite content instantly with SAPHI. Pixel Precise Ultra HD makes everything look smooth and sharp. And Ambilight ties it all together.

Sharp. Light. Beautiful.

- Ambilight. Take the emotion beyond the screen.
- Ultra-slim frame with aluminium coloured bezel & stand.

See every detail

- 4K Ultra HD. Pictures so sharp you'll think you're there.
- Pixel Precise Ultra HD. Fluid images with incredible depth.

SAPHI:intuitive app content selection

- SAPHI. The smart way to enjoy your TV.

Passionate about Picture Quality

- Micro Dimming optimizes the contrast on your TV
- Experience better contrast, color & sharpness with HDR Plus

Slim TV. Clear sound.

- Deep bass and crystal-clear dialogue.

PHILIPS

Highlights

Ambilight 3-sided

With Philips Ambilight, movies and games feel more immersive. Music gets a light show. And your screen will feel bigger than it is. Intelligent LEDs around the edges of the TV cast on-screen colours onto the walls, and into the room, in real time. You get perfectly tuned ambient lighting. And one more reason to love your TV.

Metal Angled Stand

Modern European Design is visible in the floating aluminium stands finished in dark silver matching the ultra-slim bezel.

4K Ultra HD

With four times the resolution of conventional Full HD, Ultra HD lights up your screen with over 8 million pixels and our unique Ultra Resolution Upscaling technology. Experience improved images regardless of the original content, and enjoy a sharper picture with

superior depth, contrast, natural motion and vivid details.

Pixel Precise Ultra HD

The beauty of 4K Ultra HD TV is in savoring every detail. Philips Pixel Precise Ultra HD engine converts any input picture into stunning UHD resolution on your screen. Enjoy a smooth, yet sharp moving image and exceptional contrast. Discover deeper blacks, whiter whites, vivid colors and natural skin tones - every time, and from any source.

HDR Plus

High Dynamic Range Plus redefines in-home entertainment. Experience a sensory journey with its advanced processing power. Capture the richness and liveliness of the content just as the creator intended. Get ready to enjoy brighter highlights, greater contrast, a broader range of colors and detail like never before.

Saphi TV system

SAPHI is a fast, intuitive operating system that makes your Philips Smart TV a real pleasure to use. Enjoy great picture quality and one-button access to a clear icon-based menu. Operate your TV with ease, and quickly navigate to popular Philips Smart TV apps including YouTube, and more.

DTS HD

DTS HD optimizes sound processing by preserving the original sound content so that you can enjoy a better sound from your speakers with crystal-clear dialog.

Micro Dimming

Thanks to our special software that analyzes the picture in 6400 different zones and adjusts it accordingly, you'll enjoy incredible contrast and image quality for a truly lifelike visual experience.



Specifications

Ambilight

- Ambilight Version: 3 sided

Picture/Display

- Display: 4K Ultra HD LED
- Panel resolution: 3840x2160
- Aspect ratio: 16:9
- Picture enhancement: Micro Dimming, 1100 PPI, Pixel Precise Ultra HD, Ultra Resolution

Smart TV Features

- User Interaction: MultiRoom Client, SimplyShare, Wi-Fi Miracast Certified*
- Program: Pause TV
- SmartTV apps*: Online Video Stores, Open Internet Browser, Youtube
- Ease of Installation: Auto detect Philips devices, Device connection wizard, Network installation wizard, Settings assistant wizard
- Firmware upgradeable: Firmware auto upgrade wizard, Firmware upgradeable via USB, Online firmware upgrade
- Screen Format Adjustments: Basic - Fill Screen, Fit to Screen, Zoom, Stretch
- Philips TV Remote app*: Apps, Channels, Control, NowOnTV, TV Guide, Video On Demand

Processing

- Processing Power: Quad Core

Sound

- Output power (RMS): 20W
- Sound Enhancement: Incredible Surround, Clear Sound, Auto Volume Leveller, Smart Sound

Connectivity

- Number of HDMI connections: 3
- Number of USBs: 2
- Number of component in (YPbPr): 1
- Number of AV connections: 1
- Wireless connections: Wi-Fi 802.11n 2x2 integrated, Dual Band
- Other connections: Digital audio out (optical), Ethernet-LAN RJ-45, Audio L/R in, Headphone out, Antenna IEC75
- HDMI features: Audio Return Channel, 4K
- EasyLink (HDMI-CEC): Remote control pass-through, System audio control, System standby, One touch play

Multimedia Applications

- Video Playback Formats: Containers: AVI, MKV, H264/MPEG-4 AVC, MPEG-1, MPEG-2, MPEG-4, WMV9/VC1, VP9, HEVC
- Subtitles Formats Support: .SML, .SRT, .SUB, .TXT, .ASS, .SSA
- Music Playback Formats: AAC, MP3, WAV, WMA (v2 up to v9.2), WMA-PRO (v9 and v10)
- Picture Playback Formats: JPEG, BMP, GIF, PNG

Supported Display Resolution

- Computer inputs on HDMI1: up to 4K UHD 3840x 2160 @30Hz
- Computer inputs on HDMI2/3: up to 4K UHD 3840x 2160 @60Hz
- Video inputs on HDMI2/3: up to 4K UHD 3840x 2160 @60Hz
- Video inputs on HDMI1: up to 4K UHD 3840x 2160 @30Hz

Tuner/Reception/Transmission

- Digital TV: DVB-T/T2
- MPEG Support: MPEG2, MPEG4
- Video Playback: PAL, SECAM
- TV Program guide*: 8 day Electronic Program Guide

Power

- Mains power: 220-240V 50/60Hz
- Ambient temperature: 5 °C to 35 °C
- Power Saving Features: Auto switch-off timer

Dimensions

- Box dimensions (W x H x D): 1600 x 995 x 185 mm
- Set dimensions (W x H x D): 1462.3 x 852.3 x 87.5 mm
- Set dimensions with stand (W x H x D): 1462.3 x 884.1 x 295.7 mm
- VESA wall mount compatible: 400 x 200 mm
- Product weight: 24.45 kg
- Product weight (+stand): 25.1 kg
- Weight incl. Packaging: 32.0 kg

Accessories

- Included accessories: Remote Control, 2 x AAA Batteries, Power cord, Quick start guide, Legal and safety brochure, Table top stand

Connections

Side



Rear



Bottom



Issue date 2018-11-30

Version: 4.1.1

12 NC: 8670 001 56143
EAN: 87 18863 01741 8

© 2018 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com



* EPG and actual visibility (up to 8 days) is country and operator dependent.
* (Philips) only compatible with specific Philips player device.
* Smart TV app offerings vary per TV model and country. For more details please visit: www.philips.com/smarttv.
* Compatibility depends on Wifi Miracast certification & Android 4.2 or later. For more details please refer to your device documentation.