



Philips
Flat TV with Pixel Plus 2
HD

107cm (42")
LCD
Full HD 1080p

42PFL7782D



Slimmer by inches. Clearer by miles.

This TV is our slimmest yet, boasting an elegant, ultra-sleek form factor, paired with a full HD 1080p screen. The powerful Pixel Plus 2HD engine and deep bass subwoofer gives an experience that's better by inches and clearer by miles.

Breathtaking natural pictures

- Full HD LCD display, with a 1920x1080p resolution
- Pixel Plus 2 HD for great details, depth and clarity
- Up to 5ms response time for clear, fast moving action
- Digital Natural Motion for smooth moving images
- 28.9 billion colors and up to 7500:1 contrast ratio

Exciting and lifelike sound

- Incredible Surround with subwoofer for deep bass
- BBE for superior sound clarity

Designed for your convenience

- Swivel stand for the optimal viewing angle
- 4 HDMI inputs for full digital HD connection in one cable

Ready for the future

- Integrated Digital Tuner for DVB-T reception
- HD Ready for the highest quality display of HD signals

PHILIPS

Highlights

Full HD LCD display 1920x1080p

The Full HD screen has the widescreen resolution of 1920 x 1080p. This is the highest resolution of HD sources for the best possible picture quality. It is fully future proof as it supports 1080p signals from all sources, including the most recent like Blu-ray and advanced HD game consoles. The signal processing is extensively upgraded to support this much higher signal quality and resolution. It produces brilliant flicker-free progressive scan pictures with superb brightness and colors.

Integrated Digital DVB-T tuner

The integrated Digital DVB-T tuner lets you receive digital terrestrial TV without an additional set top box. Enjoy quality TV clutter free.

HD Ready

Enjoy the exceptional picture quality of High Definition pictures and be fully prepared for HD sources like HDTV settop box or Blu-ray disc. HD Ready is a protected label that offers picture quality beyond that of progressive scan. It conforms to strict standards laid out by EICTA to offer a HD screen that displays the benefits of resolution and picture quality of a High Definition signal. It has a universal connection for both analog YPbPr and uncompressed Digital connection of DVI or

HDMI, supporting HDCP. It can display 720p, and 1080i signals at 50 and 60Hz.

Pixel Plus 2 HD

Pixel Plus 2 HD offers the unique combination of ultimate sharpness, natural detail, increased depth, vivid colors and smooth and natural motion from standard TV, High Definition signals and multimedia sources. Each pixel of the incoming picture is enhanced to better match the surrounding pixels, resulting in a more natural picture. Artifacts in compressed multimedia content are detected and reduced, ensuring that the picture is clean and razor sharp. Digital noise reduction ensures that the picture is perfectly smooth yet razor sharp.

Digital Natural Motion

Philips invented Digital Natural Motion to eliminate juddering effects that are visible with moving picture content. Digital Natural Motion estimates motion in the picture and corrects juddering movements in both broadcast and recorded movie material (such as DVD). The resulting smooth motion reproduction and excellent sharpness take the viewing experience to a higher level.

Incredible Surround subwoofer

Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting,

Incredible Surround mixes sounds from left and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround with integrated subwoofer now allows you to experience total surround with greater depth and bass ,width of sound with the use of an integrated subwoofer.

BBE

BBE high definition sound is the core sound enhancement technology (licensed by BBE Sound) that will enable you to experience real natural music, speech intelligibility with rich and clear audible vocals.

4 HDMI inputs

HDMI makes an uncompressed digital RGB connection from the source to the screen for the ultimate picture quality. HDMI intelligently communicates the highest output resolution with the source device. The HDMI input is fully backward compatible with DVI sources and includes digital audio. HDMI uses HDCP copy protection. With 3 HDMI inputs on the back and 1 HDMI on the side of the TV you can connect multiple HD sources, for instance an HD settop box, a Blu-ray player, and game console or digital Camcorder. Your TV is fully prepared for the HD future.



Specifications

Picture/Display

- Color cabinet: High Gloss black deco front with Titanium rim cabinet
- Aspect ratio: Widescreen, 16:9
- Brightness: 500 cd/m²
- Dynamic screen contrast: 7500:1
- Response time (typical): 5 ms
- Viewing angle (H / V): 178 / 178 degree
- Diagonal screen size: 42 inch / 107 cm
- Display screen type: LCD Full HD W-UXGA Act. matrix
- Panel resolution: 1920x1080p
- Picture enhancement: Pixel Plus 2 HD, Digital Natural Motion, Luminance Transient Improver, Color Transient Improvement, Dynamic contrast enhancement, 3/2 - 2/2 motion pull down, 3D Combfilter, Active Control, Color Enhancement, Digital Noise Reduction
- Screen enhancement: Anti-Reflection coated screen

Supported Display Resolution

Computer formats

Resolution	Refresh rate
640 x 480	60, 72, 75, 85Hz
800 x 600	60, 72, 75, 85Hz
1024 x 768	60, 70, 75, 85Hz
1280 x 768	60Hz
1280 x 1024	60Hz
1360 x 768	60Hz

Video formats

Resolution	Refresh rate
480i	60Hz
480p	60Hz
576i	50Hz
576p	50Hz
720p	50, 60Hz
1080i	50, 60Hz
1080p	24, 25, 30Hz
1080p	24, 50, 60Hz

Sound

- Equalizer: 7-bands
- Output power (RMS): 20W
- Sound Enhancement: Auto Volume Leveler,

- Incredible Surround, Dynamic Bass Enhancement
- Sound System: Stereo, BBE

Loudspeakers

- Built-in speakers: 2
- Loudspeaker types: Integrated subwoofer

Convenience

- Child Protection: Child Lock+Parental Control
- Clock: Sleep Timer, Wake up Clock
- Ease of Installation: Auto Program Naming, Automatic Channel Install(ACI), Automatic Tuning System (ATS), Autostore, Fine Tuning, Plug & Play, Program Name, Sorting
- Ease of Use: Auto Volume Leveller (AVL), Easy toggle Dig/Analog modes, Program List, Side Control, Smart Picture, Smart Sound
- Electronic Program Guide: 8 day Electronic Program Guide
- Remote Control: TV
- Remote control type: RC2034314/01
- Screen Format Adjustments: 4:3, Movie expand 14:9, Movie expand 16:9, Subtitle Zoom, Super Zoom, Widescreen
- Picture in Picture: Text dual screen
- Teletext: 1200 page Hypertext
- Teletext enhancements: 4 favourite pages, Program information Line

Tuner/Reception/Transmission

- Aerial Input: 75 ohm coaxial (IEC75)
- TV system: PAL I, PAL B/G, PAL D/K, SECAM B/G, SECAM D/K, SECAM L/L', DVB COFDM 2K/8K
- Video Playback: NTSC, SECAM, PAL
- Digital TV: DVB Terrestrial *
- Tuner bands: Hyperband, S-Channel, UHF, VHF
- Number of Preset Channels: 100
- Tuner Display: PLL

Connectivity

- Ext 1 Scart: Audio L/R, CVBS in/out, RGB
- Ext 2 Scart: Audio L/R, CVBS in/out, S-video in
- Number of Scarts: 2
- Ext 3: HDMI v1.3, CVBS in, Audio L/R in
- Ext 4: YPbPr, S-video in, Audio L/R in

- Ext 5: HDMI v1.3
- Ext 6: HDMI v1.3
- Ext 7: HDMI v1.3
- Other connections: Headphone out, Common Interface

Power

- Ambient temperature: 5 °C to 40 °C
- Mains power: 220 - 240V, 50/60Hz
- Power consumption: 170 W
- Standby power consumption: < 1 W

Accessories

- Included accessories: Table top stand, Power cord, Quick start guide, User Manual, Registration card, Warranty certificate, Remote Control, Batteries for remote control

Dimensions

- Set dimensions (W x H x D): 1029 x 662 x 136 mm
- Set dimensions with stand (W x H x D): 1029 x 725 x 279 mm
- Product weight: 25.5 kg
- Product weight (+stand): 30 kg
- Box dimensions (W x H x D): 1129 x 756 x 314 mm
- Weight incl. Packaging: 37.5 kg
- Wall mount compatible: 600 x 400 mm

Stereo system					Transmission system					
2CS DK	NICAM DK	2CS BG	NICAM I	NICAM LL	PAL BG	PAL D/K	PAL I	SECAM BG	SECAM DK	SECAM LL
•	•	•	•	•	•	•	•	•	•	•



Issue date 2022-07-14

Version: 4.0.10

12 NC: 8670 000 34086
EAN: 87 12581 36507 3

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com