



## Professional TV

- 32" Studio
- DVB-T2/C/S2

32HFL2889S/12

# Keep it simple

Standalone Pro TV.

From hotel room to boardroom, give them Philips renowned picture quality with this budget-friendly standalone professional TV. Benefit from simple, lightning-fast installation and an on-screen welcome page that's easy to program.

## Benefits

### Brilliant picture. Easy management.

- Secure menu and control locking
- 16/7. Beautifully clear, high-contrast image
- 3 years warranty, extendable to 5 years
- Multilingual customer support

### Simple set up. Flexible connections.

- Mixed channel map to combine analogue, DVB-T/C/S channels
- Instant initial USB cloning. Rapidly configure Pro TVs
- HDMI & VGA for PC connection.

- Offline channel editor. Easily manage channels on a PC
- S2 satellite tuner on board

### Cost-effective standalone solution

- USB auto playback. Music, movies, and more
- Low power consumption
- HDMI-CEC to control external devices

# PHILIPS

## Features

### DVB-T/C/S channels

One integrated channel list for digital (T/C/S) and analogue channels. This allows the guest to flick seamlessly between Analogue and Digital (T/C/S) channels.

### Instant initial USB cloning.

Provides the ability to easily copy all programming and channel programming settings from one TV into other TV sets in less than a minute. The feature ensures uniformity between TV sets and significantly reduces installation time and costs.

### Control locking

By disabling or enabling the local control locking, the administrator can prevent unauthorised use of the TV via the control buttons, saving the hotelier overheads.

### USB auto playback.

Share the fun. Connect your USB memory-stick, digital camera, mp3 player or other multimedia device to the USB port on your TV to enjoy photos, videos and music with the easy to use onscreen content browser.

### Low power consumption

Philips TVs are designed to minimise power consumption. This will not only reduce environmental impact but also lower operating costs.

## Specifications

[field not found 'disclaimer\_text']

### Picture/Display

Display	LED HD TV
Diagonal screen size (metric)	80 cm
Diagonal screen size (inch)	32 inch
Aspect ratio	16:9
Panel resolution	1366 x 768p
Brightness	250 cd/m <sup>2</sup>
Viewing angle	178° (H) / 178° (V)

### Audio

Sound output Power	12 (2x6) W
Speakers	2.0 Down Firing
Sound Features	Equalizer Balance AVL Incredible surround Dynamic Bass

### Design

Colour	Black
--------	-------

### Tuner/Reception/Transmission

Digital TV	DVB-T2/C/S2 HEVC FHD (up to 1080p60)
Analog TV	PAL SECAM

### Connectivity Rear

Antenna	IEC-75 F-Type
HDMI1	HDMI 1.4 ARC
HDMI2	HDMI 1.4
Digital Audio out	Optical
Scart	CVBS RGB SVHS
VGA input	15 pin D-sub

### Connectivity Side

Common Interface Slot	CI+ 1.3
AV input	CVBS+L/R (Cinch)
Headphone out	Mini-Jack
USB1	USB 2.0

### Connectivity Enhancements

EasyLink (HDMI CEC)	One touch play System Standby RC pass through
---------------------	---

### Features

Digital services	Subtitles Teletext MHEG Now&Next 8d EPG
Ease of use	Picture Style Sound Style
Local control	Joystick

### Hospitality Features

Hotel mode	Joystick Control Lock Menu lock Installation Menu Lock Volume limitation (incl. HP)
Prison mode	high security mode TXT/MHEG/USB/EPG/Subtitle Lock
Your brand Cloning and Firmware update	Welcome Logo via USB
Switch On control	Instant Initial Cloning Channel/Source Picture Style Volume (incl. HP)
Timer	Sleep Timer Wake Up Alarm
Channels	Combined List Off-Line Channel Editor
Control Power control	Block Automatic Channel Update Green/fast startup
Remote Control	Cable Strap Ready RC Battery Door Lock
Anti-Theft	Kensington Lock

### Healthcare features

Control Convenience	Multi-Remote Control Headphone out
---------------------	---------------------------------------

### Multimedia

Multimedia connections	USB
Video playback supported	Containers: AVI, MKV Formats: H.264/MPEG4 AVC MPEG1 MPEG2 MPEG4

Subtitle formats supported	HEVC TS SRT SSA SUB ASS SMI TXT	Energy Label Class	A+
Music formats supported	MP3 AAC WAV WMA (v2 up to v9.2)	Eu Energy Label power	31 W
Picture formats supported	BMP JPG PNG	Annual energy consumption	45 kW h
Supp. Video Resolution on USB	up to 1920x1080p@30Hz	Standby power consumption	<0.3 W
<b>Accessories</b>		Power Saving Features	Eco mode
Included	Remote Control 22AV1407A/12 2xAAA Batteries Tabletop Stand Warranty Leaflet	Ambient temperature	5 °C to 45 °C
Optional	Legal and Safety brochure Easy RC 22AV1601B/12 Setup RC 22AV9574A/12	<b>Dimensions</b>	
<b>Power</b>		Set Width	735 mm
Mains power	AC 220-240V; 50-60Hz	Set Height	442 mm
		Set Depth	77/89 mm
		Set width (with stand)	735 mm
		Set height (with stand)	478 mm
		Set depth (with stand)	184 mm
		Product weight	5.1 kg
		Product weight (+stand)	5.6 kg
		VESA wall mount compatible	M4 200 x 100 mm

\* Availability of features will depend on implementation chosen by integrator.

\* Typical on-mode power consumption measured according to IEC62087 Ed 2. The actual energy consumption will depend on how the television is used.

\* This television contains lead only in certain parts or components where no technology alternatives exist in accordance with existing exemption clauses under the RoHS Directive.



data subject to change  
2019, September 30

Version: 1.1.1  
EAN: 8718863020418

© 2019 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)