



Philips
LCD TV with Pixel Plus
HD

81 cm (32")
integrated digital

32PFL5403D



Brilliant design, powerful performance.

Style and performance meet in one complete experience. Combining a HD Ready display, Pixel Plus HD engine and fantastic invisible sound, this Flat TV provides brilliant design and powerful performance for years to come.

Vivid and razor sharp pictures

- Pixel Plus HD for better details, depth and clarity
- HD LCD display, with a 1366 x 768p resolution
- 28.9 billion colors for brilliant natural images
- Dynamic contrast 30000:1 for incredible rich black details

Pure and powerful sound

- Superb audio enjoyment from unique invisible speakers
- Virtual Dolby Digital for a true life audio experience

Connect, install and enjoy

- Enjoy photo and music playback via USB
- 4 HDMI inputs for full digital HD connection in one cable
- EasyLink: easy control of TV & connected device via HDMI CEC

Ready for digital

- Integrated Digital Tuner for DVB-T reception

PHILIPS

LCD TV
81 cm (32") integrated digital

32PFL5403D/12

Highlights

Pixel Plus HD

Pixel Plus HD is a picture processing technology that enables viewers to watch content that is vivid, natural, and real. The result means superbly life-like pictures with incredible details and depth from any HD source.

LCD display, 1366 x 768p

This WXGA display with state-of-the-art LCD screen technology gives you widescreen HD resolution of 1366 x 768p pixels. It produces brilliant flicker-free progressive scan pictures with optimum brightness and superb colors. This vibrant and sharp image will provide you with an enhanced viewing experience.

Integrated Digital DVB-T tuner

The integrated Digital DVB-T tuner lets you receive digital terrestrial TV without an additional set top box. Enjoy quality TV clutter free.

Virtual Dolby Digital

Virtual Dolby Digital is a processing technology for enhancing surround sound effects. It will create the sensation of Dolby Pro Logic without the necessity of additional rear speakers. You become totally immersed in your television experience.

USB for photo & music playback

The USB connector allows access to jpeg photos and mp3 music of most USB-sticks (USB memory-class device). Plug the USB into the slot at the side of the TV and access the multimedia content using the easy on screen content browser. You can now view and share your photos and music.

4 HDMI inputs

HDMI makes an uncompressed digital RGB connection from the source to the screen for the ultimate picture quality. HDMI intelligently

communicates the highest output resolution with the source device. The HDMI input is fully backward compatible with DVI sources and includes digital audio. HDMI uses HDCP copy protection. With 3 HDMI inputs on the back and 1 HDMI on the side of the TV you can connect multiple HD sources, for instance an HD settop box, a Blu-ray player, and game console or digital Camcorder. Your TV is fully prepared for the HD future.

EasyLink

EasyLink uses the HDMI CEC industry standard protocol to share functionality between connected devices and the TV. With EasyLink only one remote control is needed to operate main functionalities on your TV and connected devices. EasyLink uses the standard HDMI cable to transfer system commands. It works between all electronic devices equipped with HDMI CEC.

Pixel
Plus HD

HD
ready

28.9 billion colours

30 000 : 1
Dynamic
contrast ratio

DOLBY
DIGITAL

4x
HDMI

easy
LINK

USB

Specifications

Picture/Display

- Aspect ratio: Widescreen
- Brightness: 500 cd/m²
- Dynamic screen contrast: 30000:1
- Response time (typical): 6 ms
- Viewing angle: 176° (H) / 176° (V)
- Diagonal screen size: 32 inch / 81 cm
- Display screen type: LCD WXGA Active Matrix TFT
- Panel resolution: 1366 x 768p
- Picture enhancement: Pixel Plus HD, 3/2 - 2/2 motion pull down, 3D Combfilter, Active Control + Light sensor, Color Transient Improvement, Digital Noise Reduction, Dynamic contrast enhancement, Luminance Transient Improver, 1080p 24/25/30Hz processing, 1080p 50/60Hz processing
- Screen enhancement: Anti-Reflection coated screen
- Color cabinet: Black cabinet with High Gloss deco front

Supported Display Resolution

Computer formats

Resolution	Refresh rate
640 x 480	60, 72, 75, 85Hz
800 x 600	60, 72, 75, 85Hz
1024 x 768	60, 70, 75, 85Hz
1920 x 1080i	60Hz

Via HDMI/DVI input

Video formats

Resolution	Refresh rate
480i	60Hz
480p	60Hz
576i	50Hz
576p	50Hz
720p	50, 60Hz
1080i	50, 60Hz
1080p	24, 50, 60Hz
1080p	24, 25, 30Hz

Sound

- Equalizer: 5-bands

- Output power (RMS): 2 x 15W
- Sound Enhancement: Auto Volume Leveler, Graphic Equaliser
- Sound System: Nicam Stereo, Virtual Dolby Digital, BBE

Convenience

- Child Protection: Child Lock+Parental Control
- Clock: Sleep Timer, Wake up Clock
- Ease of Installation: Auto Program Naming, Automatic Channel Install(ACI), Automatic Tuning System (ATS), Autostore, Fine Tuning, PLL Digital Tuning, Plug & Play
- Ease of Use: 4 favorite lists, Auto Volume Leveler (AVL), Delta Volume per preset, Graphical User Interface, On Screen Display, Program List, Settings assistant Wizard, Side Control
- Electronic Program Guide: Now + Next EPG
- Picture in Picture: Text dual screen
- Remote Control: TV
- Remote control type: RCPF05E08B
- Screen Format Adjustments: 4:3, Auto Format, Movie expand 14:9, Movie expand 16:9, Subtitle Zoom, Super Zoom, Widescreen
- Teletext: 1200 page Hypertext
- Teletext enhancements: 4 favourite pages, Program information Line
- Smart mode: Movie, Standard, Vivid

Multimedia Applications

- Multimedia connections: USB
- Playback Formats: MP3, Slideshow files (.alb), JPEG Still pictures

Tuner/Reception/Transmission

- Aerial Input: 75 ohm coaxial (IEC75)
- TV system: PAL I, PAL B/G, PAL D/K, SECAM B/G, SECAM D/K, SECAM L/L', DVB COFDM 2K/8K
- Video Playback: NTSC, SECAM, PAL
- Digital TV: DVB Terrestrial *
- Tuner bands: Hyperband, S-Channel, UHF, VHF
- Tuner Display: PLL

Connectivity

- Ext 1 Scart: Audio L/R, CVBS in/out, RGB
- Ext 2 Scart: Audio L/R, CVBS in/out, RGB
- Ext 3: YPbPr, Audio L/R in
- Ext 4: HDMI v1.3
- Ext 5: HDMI v1.3
- Ext 6: HDMI v1.3
- EasyLink (HDMI-CEC): One touch play, System standby
- Front / Side connections: HDMI v1.3, S-video in, CVBS in, Audio L/R in, Headphone Out, USB
- Other connections: Analog audio Left/Right out, PC Audio in, S/PDIF out (coaxial), Common Interface

Power

- Ambient temperature: 5 °C to 35 °C
- Mains power: 220 - 240V, 50/60Hz
- Power consumption: 130 W
- Standby power consumption: 0.15 W


Dimensions

- Set dimensions (W x H x D): 819 x 518 x 92 mm
- Set dimensions with stand (W x H x D): 819 x 579 x 220 mm
- Weight incl. Packaging: 19 kg
- Product weight: 13 kg
- Product weight (+stand): 16 kg
- Box dimensions (W x H x D): 918 x 629 x 255 mm
- Wall mount compatible: 200 x 300 mm

Accessories

- Included accessories: Tabletop swivel stand, Power cord, Quick start guide, User Manual, Warranty certificate, Remote Control, Batteries for remote control

Stereo system				Transmission system						
2CS DK	NICAM DK	2CS BG	NICAM I	NICAM LL	PAL BG	PAL D/K	PAL I	SECAM BG	SECAM DK	SECAM LL
•	•	•	•	•	•	•	•	•	•	•



Issue date 2022-07-14

Version: 4.0.13

12 NC: 8670 000 34626
EAN: 87 12581 37077 0

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com