



Philips
widescreen flat TV with
Crystal Clear III

58 cm (23")
LCD
HD Ready

23PFL5322



Turn up your viewing experience

Here is a wonderful new TV that not only gives you great picture and sound but also modern styling and quality finish. It features Crystal Clear III for natural, vivid images and superb audio

Vivid, natural and razor sharp images

- HD LCD WXGA display, with a 1366 x 768p resolution
- HD Ready for the highest quality display of HD signals
- Crystal Clear III for natural images with enhanced quality

Slim, stylish design to complement your interior

- Compact and slim design that fits in every room

Designed for your convenience

- PC input lets you also use your TV as a PC monitor

PHILIPS

widescreen flat TV
58 cm (23") LCD, HD Ready

23PFL5322/01

Highlights

LCD WXGA display, 1366 x 768p

This WXGA display with state-of-the-art LCD screen technology gives you widescreen HD resolution of 1366 x 768p pixels. It produces brilliant flicker-free progressive scan pictures with optimum brightness and superb colors. This vibrant and sharp image will provide you with an enhanced viewing experience.

HD Ready

Enjoy the exceptional picture quality of High Definition pictures and be fully prepared for HD sources like HDTV settop box or Blu-ray disc. HD Ready is a protected label that offers picture quality beyond that of progressive scan. It conforms to strict standards laid out by EICTA to offer a HD screen that displays the benefits of resolution and picture quality of a High Definition signal. It has a universal connection for both analog YPbPr and

uncompressed Digital connection of DVI or HDMI, supporting HDCP. It can display 720p, and 1080i signals at 50 and 60Hz.

Compact and slim design

This design style emphasizes a slim, compact look that saves space and fits in anywhere.

PC input

With PC input you can connect your TV to a computer and use the TV as a PC monitor.



Specifications

Picture/Display

- Color cabinet: Black High Gloss
- Aspect ratio: Widescreen, 16:9
- Brightness: 500 cd/m²
- Contrast ratio (typical): 700:1
- Response time (typical): 8 ms
- Viewing angle (H / V): 160 / 160 degree
- Diagonal screen size: 23 inch / 58 cm
- Display screen type: LCD WXGA Active Matrix TFT
- Panel resolution: 1366 x 768p
- Picture enhancement: Crystal Clear III, Contrast Plus, Active Control, Color Temperature Adjustment, Sharpness Adjustment
- Screen enhancement: Anti-Reflection coated screen

Supported Display Resolution

Computer formats

Resolution	Refresh rate
640 x 480	60, 75Hz
800 x 600	60, 75Hz
1024 x 768	60, 75Hz
1280 x 768	60Hz

Video Formats

Resolution	Refresh rate
1280 x 720p	3Fh
1920 x 1080i	2Fh
720 x 576i	1Fh
720 x 576p	2Fh

Sound

- Equalizer: 5-bands
- Output power (RMS): 2 x 5W
- Sound Enhancement: Dynamic Bass Enhancement
- Sound System: Nicam Stereo, Stereo

Loudspeakers

- Built-in speakers: 2

Convenience

- Clock: Sleep Timer
- Ease of Installation: Auto Program Naming, Automatic Channel Install(ACI), Automatic Tuning

- System (ATS), Autostore, Fine Tuning, Plug & Play, Program Name, Sorting
- Ease of Use: Auto Volume Leveller (AVL), FM Radio, Menu Control, On Screen Display, Program List, Smart Picture, Smart Sound, Top Controls
- Remote Control: TV
- Remote control type: Racer
- Screen Format Adjustments: 4:3, Movie expand 14:9, Movie expand 16:9, Subtitle Zoom, Super Zoom, Widescreen
- Teletext: 10 page Smart Text
- Teletext enhancements: 4 favourite pages, Program information Line

Tuner/Reception/Transmission

- Aerial Input: 75 ohm coaxial (IEC75)
- TV system: PAL I, PAL B/G, PAL D/K, SECAM B/G, SECAM D/K, SECAM L/L'
- Video Playback: NTSC, SECAM, PAL
- Tuner bands: Hyperband, S-Channel, UHF, VHF, FM
- Number of Preset Channels: 100
- Tuner Display: PLL

Connectivity

- Ext 1 Scart: Audio L/R, CVBS in/out, RGB
- Front / Side connections: Audio in, CVBS in, Headphone Out, S-video in
- Other connections: PC Audio in

Power

- Ambient temperature: 5 °C to 40 °C
- Mains power: 220 - 240V, 50/60Hz
- Power consumption: 77 W
- Standby power consumption: < 2 W

Accessories

- Included accessories: Table top stand, FM antenna, Power cord, Quick start guide, User Manual, Registration card, Warranty certificate, Remote Control, Batteries for remote control

Dimensions

- Set dimensions (W x H x D): 590 x 420 x 106 mm

stereo system					transmission system					
2CS	NICAM	2CS	NICAM	NICAM	PAL	PAL	PAL	SECAM	SECAM	SECAM
DK	DK	BG	I	LL'	BG	DK	I	BG	DK	LL'
o	o	o	o	o	o	o	o	o	o	o



Issue date 2022-07-14

Version: 11.0.10

12 NC: 8670 000 30536
EAN: 87 12581 33909 8

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com