



Philips
digital widescreen flat TV
with Pixel Plus

66 cm (26")
LCD
integrated digital

26PF7521D



Turn up your viewing experience

with Digital Tuner and Pixel Plus

Digital TV does not get much better! This Flat TV has Pixel Plus for breathtaking natural pictures, Active Control for optimum brightness, Electronic Program Guide for digital TV combined in a contemporary design.

Breathtaking natural pictures

- HD LCD WXGA display, with a 1366 x 768p resolution
- Integrated Digital Tuner for DVB-T reception
- HD Ready for the highest quality display of HD signals
- Pixel Plus for detail, depth and clarity
- Dynamic contrast enhancer delivering rich black details

Superb sound reproduction

- Virtual Dolby Surround for a cinema-like audio experience

Slim, stylish design to complement your interior

- Compact and slim design that fits in every room

Designed for your convenience

- Watch analog TV while recording a digital program

For advanced performance

- HDMI input for full digital HD connection in one cable

PHILIPS

digital widescreen flat TV
66 cm (26") LCD, integrated digital

26PF7521D/12

Highlights

LCD WXGA display, 1366 x 768p

This WXGA display with state-of-the-art LCD screen technology gives you widescreen HD resolution of 1366 x 768p pixels. It produces brilliant flicker-free progressive scan pictures with optimum brightness and superb colors. This vibrant and sharp image will provide you with an enhanced viewing experience.

Integrated Digital DVB-T tuner

The integrated Digital DVB-T tuner lets you receive digital terrestrial TV without an additional set top box. Enjoy quality TV clutter free.

HD Ready

Enjoy the exceptional picture quality of High Definition pictures and be fully prepared for HD sources like HDTV settop box or Blu-ray disc. HD Ready is a protected label that offers picture quality beyond that of progressive scan. It conforms to strict standards laid out by EICTA to offer a HD screen that displays the benefits of resolution and picture quality of a High Definition signal. It has a universal

connection for both analog YPbPr and uncompressed Digital connection of DVI or HDMI, supporting HDCP. It can display 720p, and 1080i signals at 50 and 60Hz.

Pixel Plus

Pixel Plus is a digital picture processing technology that increases the number of lines and the number of pixels. The result is razor sharp pictures with incredible detail and depth, every time from any source.

Dynamic contrast enhancer

You want the LCD flat display with the highest contrast and most vibrant images even at wide viewing angle. The Philips dynamic contrast enhancer uses video processing and unique dimming backlight technology. This delivers deep rich black levels with increased detail. The dimming backlight increases the contrast up to 5 times*, and at the same time improves the viewing angle. It gives a bright, lifelike picture with high contrast and vibrant colors, (* factor between 2 and 5, screen type and picture content dependant).

Virtual Dolby Surround

Virtual Dolby Surround is a processing technology for enhancing surround sound effects. It will create the sensation of Dolby Pro Logic without the necessity of additional rear speakers. You become totally immersed in your television experience.

Watch analog, record digital

Watch analog TV while recording a digital program

HDMI input

HDMI makes an uncompressed digital RGB connection from the source to the screen. By eliminating conversion to an analog signal, it delivers an unblemished image. The non-degraded signal reduces flicker and leads to a clearer picture. HDMI intelligently communicates the highest output resolution with the source device. The HDMI input is fully backward compatible with DVI sources but includes digital audio. HDMI uses HDCP copy protection.



Specifications

Picture/Display

- Aspect ratio: 16:9
- Brightness: 500 cd/m²
- Contrast ratio (typical): 600:1
- Diagonal screen size: 26 inch / 66 cm
- Color cabinet: High Gloss Black Deco Front with Silver Frost cabinet
- Picture enhancement: Progressive scan, 3D Combfilter, 3/2 - 2/2 motion pull down, Digital Noise Reduction, Jagged Line Suppression, Pulse Killer Chip, Active Control, Contrast Plus, Luminance Transient Improver, Pixel Plus, Color Temperature Adjustment, Sharpness Adjustment
- Screen enhancement: Anti-Reflection coated screen
- Panel resolution: 1366 x 768p
- Response time (typical): 8 ms
- Dynamic screen contrast: 2400:1
- Viewing angle: 176° (H) / 176° (V)
- Display screen type: LCD WXGA Active Matrix TFT

Supported Display Resolution

Computer formats

Resolution	Refresh rate
640 x 480	60, 67, 72, 75Hz
800 x 600	56, 60, 72, 75Hz
1024 x 768	60, 70, 75Hz
720 x 400	70Hz

Video Formats

Resolution	Refresh rate
640 x 480i	1Fh
640 x 480p	2Fh
720 x 576i	1Fh
720 x 576p	2Fh
1280 x 720p	3Fh
1920 x 1080i	2Fh

Sound

- Sound Enhancement: Dynamic Bass Enhancement
- Sound System: Virtual Dolby Surround, Stereo
- Output power (RMS): 2 x 5 W
- Equalizer: 5-bands

Convenience

- Ease of Installation: Auto Program Naming, Automatic Channel Install(ACI), Automatic Tuning System (ATS), Autostore, Fine Tuning, Plug & Play, Program Name, Sorting
- Ease of Use: Auto Volume Leveller (AVL), Program List, Smart Picture, Smart Sound, Side Control, Watch analogue/record digital, Easy toggle Dig/ Analog modes
- Remote control type: RC4343/01
- Teletext enhancements: Program information Line, 4 favourite pages
- Picture in Picture: Picture in graphics
- Remote Control: DVD, TV, Multi-functional
- Screen Format Adjustments: 4:3, Movie expand 14:9, Movie expand 16:9, Subtitle Zoom, Super Zoom, Widescreen
- Clock: Sleep Timer, Wake up Clock
- Teletext: 1000 page Smart Text

Tuner/Reception/Transmission

- Tuner bands: Hyperband, S-Channel, UHF, VHF
- TV system: PAL, SECAM
- Video Playback: NTSC, PAL, SECAM
- Aerial Input: 75 ohm coaxial (IEC75)
- Tuner Display: PLL
- Number of Preset Channels: 100
- Digital TV: DVB Terrestrial *

Connectivity

- Ext 2 Scart: S-video in, RGB out
- Other connections: Common Interface, S/PDIF out (coaxial), Antenna IEC75
- Front / Side connections: CVBS in, Headphone Out, S-video in, Audio L/R in
- Ext 6: HDMI
- Ext 5: HDMI
- Ext 4: YPbPr
- Number of Scarts: 2

Power

- Power consumption: TBC W
- Standby power consumption: < 1 W
- Ambient temperature: 5 °C to 40 °C

- Mains power: AC 220 - 240 V +/- 10%
- Power supply: AC 90-240

Dimensions

- Product weight: 13 kg
- Weight incl. Packaging: 17 kg
- Dimensions (with base) (H x D): 540.2 x 246.8 mm
- Box dimensions (W x H x D): 880 x 214 x 560 mm
- Set dimensions (W x H x D): 697.5 x 494.8 x 99.7 mm
- Wall mount compatible: 200 x 100 mm


Accessories

- Included accessories: Power cord, Quick start guide, Registration card, Remote Control, User Manual, Batteries for remote control, Table top stand, Warranty certificate
- Optional accessories: Floor stand

Loudspeakers

- Built-in speakers: 2

Stereo system					Transmission system					
2CS DK	NICAM DK	2CS BG	NICAM I	NICAM LL	PAL BG	PAL D/K	PAL I	SECAM BG	SECAM DK	SECAM LL
•	•	•	•	•	•	•	•	•	•	•



Issue date 2022-07-14

Version: 1.0.3

12 NC: 8670 000 23954
EAN: 87 10895 94515 8

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com