



Philips
widescreen flat TV with
Crystal Clear III

94 cm (37")
LCD
HD Ready

37PF3321



Turn up your viewing experience

Crystal Clear III

Here is a wonderful new TV that not only gives you great picture and sound but also modern styling and quality finish. It features Crystal Clear III for natural, vivid images and superb audio.

Vivid, natural and razor sharp images

- HD LCD WXGA display, with a 1366 x 768p resolution
- HD Ready for the highest quality display of HD signals
- Crystal Clear III for natural images with enhanced quality
- Dynamic contrast enhancer delivering rich black details
- Active Control optimizes picture quality whatever the source

Slim, stylish design to complement your interior

- Compact and slim design that fits in every room

Designed for your convenience

- Turn your TV screen into a mosaic of different channels

For advanced performance

- HDMI input for full digital HD connection in one cable

Superb sound reproduction

- Virtual Dolby Surround for a cinema-like audio experience

PHILIPS

widescreen flat TV
94 cm (37") LCD, HD Ready

37PF3321/10

Highlights

LCD WXGA display, 1366 x 768p

This WXGA display with state-of-the-art LCD screen technology gives you widescreen HD resolution of 1366 x 768p pixels. It produces brilliant flicker-free progressive scan pictures with optimum brightness and superb colors. This vibrant and sharp image will provide you with an enhanced viewing experience.

HD Ready

Enjoy the exceptional picture quality of High Definition pictures and be fully prepared for HD sources like HDTV settop box or Blu-ray disc. HD Ready is a protected label that offers picture quality beyond that of progressive scan. It conforms to strict standards laid out by EICTA to offer a HD screen that displays the benefits of resolution and picture quality of a High Definition signal. It has a universal connection for both analog YPbPr and uncompressed Digital connection of DVI or HDMI, supporting HDCP. It can display 720p, and 1080i signals at 50 and 60Hz.

Crystal Clear III

Crystal Clear III combines a whole range of enhancements to provide a better picture.

They include a 2D Comb filter, Dynamic contrast, Blue stretch and Green enhancement so that you always get the most natural looking colors.

Dynamic contrast enhancer

You want the LCD flat display with the highest contrast and most vibrant images even at wide viewing angle. The Philips dynamic contrast enhancer uses video processing and unique dimming backlight technology. This delivers deep rich black levels with increased detail. The dimming backlight increases the contrast up to 5 times*, and at the same time improves the viewing angle. It gives a bright, lifelike picture with high contrast and vibrant colors, (* factor between 2 and 5, screen type and picture content dependant).

Active Control

Active Control ensure that noise and sharpness improvements are continuously made at a rate of 60 times per second. By continually adjusting picture setting over 3,000 times per minute, Active Control Plus ensures that the viewing experience is optimized.

Multiple PiP Modes

Multiple Picture-in-Picture modes allow you to simultaneously watch two video sources either picture-in-picture, side by side, or in a mosaic-view with still images.

HDMI input

HDMI makes an uncompressed digital RGB connection from the source to the screen. By eliminating conversion to an analog signal, it delivers an unblemished image. The non-degraded signal reduces flicker and leads to a clearer picture. HDMI intelligently communicates the highest output resolution with the source device. The HDMI input is fully backward compatible with DVI sources but includes digital audio. HDMI uses HDCP copy protection.

Virtual Dolby Surround

Virtual Dolby Surround is a processing technology for enhancing surround sound effects. It will create the sensation of Dolby Pro Logic without the necessity of additional rear speakers. You become totally immersed in your television experience.



Specifications

Picture/Display

- Aspect ratio: 16:9, Widescreen
- Brightness: 500 cd/m²
- Diagonal screen size: 37 inch / 94 cm
- Color cabinet: Black
- Display screen type: LCD WXGA Active Matrix TFT
- Picture enhancement: Progressive scan, 3/2 - 2/2 motion pull down, Contrast Plus, Digital Noise Reduction, Jagged Line Suppression, Active Control, 2D Combfilter, Crystal Clear III
- Screen enhancement: Anti-Reflection coated screen
- Panel resolution: 1366 x 768p
- Response time (typical): 8 ms
- Viewing angle (H / V): 176 / 176 degree
- Dynamic screen contrast: 1600:1
- Contrast ratio (typical): 800:1

Supported Display Resolution

Computer formats

Resolution	Refresh rate
640 x 480	60, 67, 72, 75Hz
800 x 600	56, 60, 72, 75Hz
1024 x 768	60, 70, 75Hz

Video Formats

Resolution	Refresh rate
640 x 480p	2Fh
720 x 576p	2Fh
1280 x 720p	3Fh
1920 x 1080i	2Fh

Sound

- Sound Enhancement: Dynamic Bass Enhancement, Auto Volume Leveler
- Sound System: Virtual Dolby Surround
- Output power (RMS): 2 x 15W
- Equalizer: 5-bands

Loudspeakers

- Built-in speakers: 2

Convenience

- Ease of Installation: Autostore, Plug & Play, Auto Program Naming, Automatic Channel Install(ACI), Automatic Tuning System (ATS), Fine Tuning, Program Name, Sorting
- Ease of Use: Side Control, Smart Picture, Smart Sound, Auto Volume Leveller (AVL), Program List

- Remote control type: RCFE06SPS00
- Remote Control: DVD, Multi-functional, TV
- Screen Format Adjustments: 4:3, Subtitle Zoom, Super Zoom, Widescreen, Movie expand 14:9, Movie expand 16:9
- Clock: Sleep Timer, Wake up Clock
- Teletext enhancements: 4 favourite pages, Program information Line
- VESA Mount: 800 x 400 mm
- Teletext: 10 page Smart Text
- Picture in Picture: Twin page text

Tuner/Reception/Transmission

- Tuner bands: Hyperband, S-Channel, UHF, VHF
- Video Playback: NTSC, PAL, SECAM
- Aerial Input: 75 ohm coaxial (IEC75)
- Tuner Display: PLL
- Number of Preset Channels: 100
- TV system: PAL B/G, PAL D/K, SECAM B/G, SECAM D/K, SECAM L/L'

Connectivity

- Ext 1 Scart: Audio L/R, CVBS in/out, RGB
- Ext 2 Scart: Audio L/R, CVBS in/out, S-video in
- Front / Side connections: Audio L/R in, CVBS in, Headphone Out, S-video in
- Number of Scarts: 2
- Ext 4: YPbPr
- Ext 5: HDMI

Power

- Power consumption: 180 W Normal Operation W
- Standby power consumption: < 2 W
- Mains power: AC 220 - 240 V +/- 10%
- Ambient temperature: 5 °C to 40 °C

Dimensions

- Product weight: 25.1 kg
- Weight incl. Packaging: 31.5 kg
- Wall mount compatible: 0
- Box dimensions (W x H x D): 1167 x 821 x 330 mm
- Dimensions (with base) (W x H x D): 1100 x 657 x 240 mm
- Set dimensions (W x H x D): 1100 x 609 x 102.5 mm

Accessories

- Included accessories: Table top stand, Power cord,

- Registration card, Remote Control, User Manual, Warranty certificate, Batteries for remote control
- Optional accessories: Floor stand



Issue date 2022-07-14

Version: 5.0.9

12 NC: 8670 000 24337
EAN: 87 10895 98875 9

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com