



Philips
digital widescreen flat TV
with Digital Crystal Clear

81 cm (32")

LCD
integrated digital

32PF5520D



Turn up your viewing experience

with Integrated Digital tuner

With this TV enjoy the benefits of digital TV, 8 day Electronic Program Guide and digital quality content. Also watch superb pictures with Digital Crystal Clear and Active Control.

Vivid, natural and razor sharp images

- HD LCD WXGA display, with a 1366 x 768p resolution
- Integrated Digital Tuner for DVB-T reception
- HD Ready for the highest quality display of HD signals
- Digital Crystal Clear provides vivid cinema-like images
- Built-in Pulse Killer Chip neutralizes interferences

Superb sound reproduction

- Virtual Dolby Surround for a cinema-like audio experience

Slim, stylish design to complement your interior

- Compact and slim design that fits in every room

Multi-purpose convenience

- Watch analog TV while recording a digital program
- PC input lets you also use your TV as a PC monitor

PHILIPS

Highlights

Integrated Digital DVB-T tuner

The integrated Digital DVB-T tuner lets you receive digital terrestrial TV without an additional set top box. Enjoy quality TV clutter free.

HD Ready

Enjoy the exceptional picture quality of High Definition pictures and be fully prepared for HD sources like HDTV settop box or Blu-ray disc. HD Ready is a protected label that offers picture quality beyond that of progressive scan. It conforms to strict standards laid out by EICTA to offer a HD screen that displays the benefits of resolution and picture quality of a High Definition signal. It has a universal connection for both analog YPbPr and uncompressed Digital connection of DVI or HDMI, supporting HDCP. It can display 720p, and 1080i signals at 50 and 60Hz.

Digital Crystal Clear

Digital Crystal Clear is a package of picture innovations that digitally adjusts and optimizes picture quality to optimal contrast, color and sharpness levels. It's like watching vivid cinema-like images.

Pulse Killer Chip

Electrical interferences are neutralised by a built in chip called PKC

Virtual Dolby Surround

Virtual Dolby Surround is a processing technology for enhancing surround sound effects. It will create the sensation of Dolby Pro Logic without the necessity of additional rear speakers. You become totally immersed in your television experience.

Watch analog, record digital

Watch analog TV while recording a digital program

PC input

With PC input you can connect your TV to a computer and use the TV as a PC monitor.

DVI-I Input

A DVI-I input connects the non-compressed high-bandwidth digital RGB signal from source to screen. By eliminating the conversion of the digital signals to analog, it delivers an unblemished and noise-free image, that is clear and flicker-free. The DVI input supports HDCP copy protection that allows viewing of copy protected programs from Digital Settop boxes, DVD players and HD recorders. DVI-I is future proof as it can be connected to all HDMI devices (a converter cable is required). The DVI-I input also supports analog PC-VGA signals.



Specifications

Picture/Display

- Aspect ratio: Widescreen, 16:9
- Brightness: 500 cd/m²
- Contrast ratio (typical): 600:1
- Diagonal screen size: 32 inch / 80 cm
- Display screen type: LCD WXGA Active Matrix TFT
- Picture enhancement: Digital Crystal Clear, Progressive scan, 3D Combfilter, 3/2 - 2/2 motion pull down, Digital Noise Reduction, Jagged Line Suppression, Sharpness Adjustment, Pulse Killer Chip, Active Control + Light sensor, Contrast Plus
- Screen enhancement: Anti-Reflection coated screen
- Viewing angle (H / V): 176 / 176 degree
- Panel resolution: 1366 x 768p
- Response time (typical): 18 ms
- Color cabinet: Silver Frost

Supported Display Resolution

Video Formats

Resolution	Refresh rate
640 x 480i	1Fh
640 x 480p	2Fh
720 x 576i	1Fh
720 x 576p	2Fh
1280 x 720p	3Fh
1920 x 1080i	2Fh

Computer formats

Resolution	Refresh rate
640 x 480	60, 67, 72, 75Hz
800 x 600	56, 60, 72, 75Hz
1024 x 768	60, 70, 75Hz

Sound

- Sound Enhancement: Dynamic Bass Enhancement
- Sound System: Virtual Dolby Surround, Stereo
- Output power (RMS): 2 x 15 W
- Equalizer: 5-bands

Convenience

- Ease of Installation: Auto Program Naming, Automatic Channel Install(ACI), Automatic Tuning System (ATS), Autostore, Fine Tuning, PLL Digital

- Tuning, Plug & Play, Program Name, Sorting
- Ease of Use: Auto Volume Leveller (AVL), Easy toggle Dig/Analog modes, Graphical User Interface, Program List, Smart Picture, Smart Sound, Watch analogue/record digital
- Remote control type: RCFE05SL505
- Teletext: 10 page Smart Text
- Teletext enhancements: Program information Line
- Picture in Picture: Picture in graphics, Twin page text
- Screen Format Adjustments: 4:3, Movie expand 14:9, Movie expand 16:9, Subtitle Zoom, Super Zoom, Widescreen
- Clock: Sleep Timer
- VESA Mount: 200 x 100 mm
- User Interface: 7 day Electronic program Guide
- Remote Control: TV, Amp, DVD, Multi-functional

Tuner/Reception/Transmission

- Tuner bands: Hyperband, S-Channel, UHF, VHF
- TV system: PAL, SECAM
- Video Playback: NTSC, PAL, SECAM
- Aerial Input: 75 ohm coaxial (IEC75)
- Tuner Display: PLL
- Number of Preset Channels: 100
- Digital TV: DVB Terrestrial *

Connectivity

- Number of Scarts: 2
- Ext 1 Scart: Audio L/R, CVBS in/out, RGB
- Ext 2 Scart: Audio L/R, CVBS in/out, S-video in
- Other connections: Antenna IEC75, DVI-I, Common Interface
- Front / Side connections: Audio in, CVBS in, Headphone Out, S-video in
- Audio Output - Digital: AC3 over S/PDIF (Optical)
- AV 3: DVI-I with HDCP, Audio-in mini jack 3.5mm

Power

- Power consumption: TBC W
- Standby power consumption: < 1 W
- Ambient temperature: 5 °C to 45 °C
- Power supply: AC 90-240


Dimensions

- Product weight: 18.2 kg
- Dimensions (with base) (W x H x D): 924 x 550 x 222 mm
- Box dimensions (W x H x D): 1000 x 690 x 240 mm
- Set dimensions (W x H x D): 924 x 511 x 118 mm
- Weight incl. Packaging (lb): 22.6

Accessories

- Included accessories: Power cord, Quick start guide, Registration card, Remote Control, User Manual, Batteries for remote control, Table top stand
- Cables: DVI-I to YPbPr cable

Stereo system					Transmission system				
2CS DK	NICAM DK	2CS BG	NICAM I	NICAM LL	PAL BG	PAL D/K	PAL I	SECAM BG	SECAM DK
•	•	•	•	•	•	•	•	•	•



Issue date 2019-06-28

Version: 16.0.20

12 NC: 8670 000 21883
EAN: 87 10895 87566 0

© 2019 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com