



Philips
Under-the-sink water
filtration system

4-stage Ultrafiltration
2.5L/min fast flow

AUT1211

Advanced ultrafiltration in a compact size

Removes 99.9% of bacteria*

With the advanced ultrafiltration technology, this 4-stage filtration system has a deep filtration down to 0.1 micron for pure-tasting water. 2.5L/min fast flow allows you to enjoy pure-tasting water in seconds.

Flexible installation

- Compact size to leave you more space for storage
- No power supply needed, flexibly installed

Clean water assured

- Advanced multi-stage ultrafiltration for better performance
- The beneficial minerals are effectively retained

Build for your convenience

- 1.5L/min fast water flow
- Long-lasting filters for cost-saving
- Quick installation and filter replacement

Economical and environmental-friendly

- The filtered water is 100 percent used

PHILIPS

Specifications

Filtration performance

- Filter lifetime: CB filter: 6-12 months, UF filter: 12-24 months, CP filter: 6-12 months
- Filtered water flow rate: 1.5L/min
- Filter number: 3
- Rated filtration capacity: 3650L

General specifications

- Product size: 285*265*99mm
- Faucet: Standard faucet
- Pipe material: BPA free

Highlights

Compact size

285*265*99mm, the product is designed with super compact size, which is easy to be installed in any area of the under-the-sink cabinet, freeing up your storage space.

No electricity needed

No electricity needed. Even there is no power supply in your under-the-sink area, the filtration system can be easily installed and works.

Multi-stage filtration system

A 4-stage ultrafiltration system filters out a wide range of pollutants for superior, long-lasting performance. The carbon block and sediment 2-in-1 filter effectively reduces large particles, chlorine, volatile organic compounds, and taste impairing substances. Then the hollow fiber membrane filter reduces turbidity, particles down to 0.01 microns, and up to 99.9%* of bacteria. The last carbon block filter further improves the taste of water.

Fast water flow, less waiting

1.5L/min fast flow allows you to enjoy pure-tasting water in seconds.

Retains minerals

The beneficial minerals in the tap water are effectively retained, for example, the trace elements calcium, magnesium, sodium, potassium, etc.

No drain water

The is no drain water generated during filtration. The filtered water is 100 percent used.

Long filter lifetime

Long-lasting filters save your spending on water
Hollow fiber membrane filter: up to 7,300L filtration capacity and lasts up to 24 months; CP filter and CB filter: up to 3,650L filtration capacity and lasts for up to 12 months**

Easy to install and replace



Minimum pipes and connections to install the system at the very beginning. Easy and hygienic filter replacement thanks to the QuickTwist system without the need for extra tools and cleaning.

