



Professional TV

- 49" Studio
- DVB-T2/C/S2

49HFL2889S/12

Keep it simple

Standalone Pro TV.

From hotel room to boardroom, give them Philips renowned picture quality with this budget-friendly standalone professional TV. Benefit from simple, lightning-fast installation and an on-screen welcome page that's easy to program.

Benefits

Brilliant picture. Easy management.

- 16/7. Beautifully clear, high-contrast image
- 3 years warranty, extendable to 5 years
- Multilingual customer support
- Secure menu and control locking

Simple set up. Flexible connections.

- HDMI & VGA for PC connection.
- Instant initial USB cloning. Rapidly configure Pro TVs
- Mixed channel map to combine analogue, DVB-T/C/S channels

- Offline channel editor. Easily manage channels on a PC
- S2 satellite tuner on board

Cost-effective standalone solution

- HDMI-CEC to control external devices
- Low power consumption
- USB auto playback. Music, movies, and more

Features

Instant initial USB cloning.

Provides the ability to easily copy all programming and channel programming settings from one TV into other TV sets in less than a minute. The feature

PHILIPS

ensures uniformity between TV sets and significantly reduces installation time and costs.

Low power consumption

Philips TVs are designed to minimise power consumption. This will not only reduce environmental impact but also lower operating costs.

DVB-T/C/S channels

One integrated channel list for digital (T/C/S) and analogue channels. This allows the guest to flick seamlessly between Analogue and Digital (T/C/S) channels.

Specifications

[field not found 'disclaimer_text']

Picture/Display

Display	LED Full HD
Diagonal screen size (metric)	123 cm
Diagonal screen size (inch)	49 inch
Aspect ratio	16:9
Panel resolution	1920x1080p
Brightness	300 cd/m ²
Viewing angle	178° (H) / 178° (V)

Audio

Sound output Power	16 (2x8) W
Speakers	2.0
Sound Features	Down Firing Equalizer Balance AVL Incredible surround Dynamic Bass

Design

Colour	Black
--------	-------

Tuner/Reception/Transmission

Digital TV	DVB-T2/C/S2 HEVC FHD (up to 1080p60)
Analog TV	PAL SECAM

Connectivity Rear

Antenna	IEC-75 F-Type
HDMI1	HDMI 1.4 ARC
HDMI2	HDMI 1.4
Digital Audio out	Optical
Scart	CVBS RGB SVHS
VGA input	15 pin D-sub

Connectivity Side

Common Interface Slot	CI+ 1.3
AV input	CVBS+L/R (Cinch)
Headphone out	Mini-Jack
USB1	USB 2.0

Connectivity Enhancements

EasyLink (HDMI CEC)	One touch play System Standby RC pass through
---------------------	---

Features

Digital services	Subtitles
------------------	-----------

Control locking

By disabling or enabling the local control locking, the administrator can prevent unauthorised use of the TV via the control buttons, saving the hotelier overheads.

USB auto playback.

Share the fun. Connect your USB memory-stick, digital camera, mp3 player or other multimedia device to the USB port on your TV to enjoy photos, videos and music with the easy to use onscreen content browser.

Ease of use	Teletext MHEG 8d EPG Now&Next Picture Style Sound Style Joystick
Local control	

Hospitality Features

Hotel mode	Joystick Control Lock Menu lock Installation Menu Lock Volume limitation (incl. HP)
Prison mode	high security mode TXT/MHEG/USB/EPG/Subtitle Lock
Your brand Cloning and Firm-ware update	Welcome Logo via USB
Switch On control	Instant Initial Cloning Channel/Source Picture Style Volume (incl. HP)
Timer	Sleep Timer Wake Up Alarm
Channels	Combined List Off-Line Channel Editor
Control	Block Automatic Channel Update
Power control	Green/fast startup
Remote Control	Cable Strap Ready
Anti-Theft	RC Battery Door Lock Kensington Lock

Healthcare features

Control Convenience	Multi-Remote Control Headphone out
---------------------	---------------------------------------

Multimedia

Multimedia connections	USB
Video playback supported	Containers: AVI, MKV Formats: H.264/MPEG4 AVC MPEG1 MPEG2 MPEG4 HEVC TS SRT SSA SUB ASS SMI TXT MP3 AAC WAV WMA (v2 up to v9.2)
Subtitle formats supported	BMP JPG PNG
Music formats supported	
Picture formats supported	

Supp. Video Resolution on USB up to 1920x1080p@30Hz

Power Saving Features
Ambient temperature Eco mode
5 °C to 45 °C

Accessories

Included	Remote Control 22AV1407A/12 2xAAA Batteries Tabletop Stand Warranty Leaflet
Optional	Legal and Safety brochure Setup RC 22AV9574A/12 Easy RC 22AV1601B/12

Dimensions

Set Depth	43/73 mm
Set depth (with stand)	235 mm
Set Height	645 mm
Set height (with stand)	697 mm
Set Width	1105 mm
Set width (with stand)	1105 mm
Product weight	10.6 kg
Product weight (+stand)	11.5 kg
VESA wall mount compatible	M6 200 x 200 mm

Power

Mains power	AC 220-240V; 50-60Hz
Energy Label Class	A++
Eu Energy Label power	48 W
Annual energy consumption	70 kWh
Standby power consumption	<0.3 W

* Availability of features will depend on implementation chosen by integrator.

* Typical on-mode power consumption measured according to IEC62087 Ed 2. The actual energy consumption will depend on how the television is used.

* This television contains lead only in certain parts or components where no technology alternatives exist in accordance with existing exemption clauses under the RoHS Directive.



data subject to change
2019, September 30

Version: 1.1.1
EAN: 8718863020432

© 2019 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com