



Philips Matchline
widescreen flat TV with
Digital Crystal Clear

107cm (42")

plasma
Progressive Scan

MATCH  **LINE**

42PF9936D



Best in class Picture Quality

With the latest in Plasma technology

The dream of the TV that can hang on the wall is now reality. This 76 cm (30") Flat TV is the ultimate centre piece for any Home Entertainment set up.

Vivid, natural and razor sharp images

- Digital Crystal Clear provides vivid cinema-like images
- Progressive Scan component video for optimized image quality
- 3D combfilter separates colors for a razor-sharp image
- Active Control with Light Sensor optimizes picture quality

Impressive sound

- Virtual Dolby Surround for a cinema-like audio experience

PHILIPS

Specifications

Picture/Display

- Aspect ratio: 16:9
- Brightness: 1000 cd/m²
- Contrast ratio (typical): 3000:1
- Diagonal screen size: 42 inch / 107 cm
- Color cabinet: Silver Frost
- Display screen type: WVGA Plasma panel
- Picture enhancement: 3/2 - 2/2 motion pull down, Active Control + Light sensor, Comb Filter Digital, Digital Crystal Clear, Progressive scan, Widescreen Plus
- Screen enhancement: Anti ageing circuit, Anti-Reflection coated screen
- Viewing angle (horizontal): 160 degree
- Panel resolution: 852 x 480p
- Response time (typical): 16 ms

Supported Display Resolution

Computer formats

Resolution	Refresh rate
640 x 480	60, 67, 72, 75Hz
800 x 600	56, 60, 72, 75Hz
1024 x 768	60, 70, 75Hz

Video Formats

Resolution	Refresh rate
640 x 480p	2Fh

Sound

- Sound Enhancement: Smart Sound, Auto Volume Leveller, Graphic Equaliser, Digital Signal Processing
- Sound System: Virtual Dolby Surround
- Output power (RMS): 2 x 15W

Loudspeakers

- Built-in speakers: 2

Convenience

- Ease of Installation: Auto Volume Leveler, Autostore, PLL Digital Tuning, Plug & Play

- Ease of Use: On Screen Display, Smart Picture, Top Controls, 9-channel smart surf list, Smart Sound
- Remote control type: RC4334/01
- Teletext: Closed Captioning Full Text
- Picture in Picture: Picture in graphics, Twin page text
- Remote Control: Multi-functional, Universal
- Screen Format Adjustments: 6 Widescreen Modes, Auto Format, Subtitle and Heading Shift
- Child Protection: Child Lock+Parental Control
- User convenience: Vchip and parental lock

Tuner/Reception/Transmission

- Tuner bands: Hyperband, S-Channel, UHF, VHF
- TV system: NTSC, SECAM, PAL N, PAL M
- Video Playback: NTSC, PAL
- Aerial Input: 75 ohm coaxial (IEC75)

Connectivity

- AV 1: Audio L/R in, CVBS in, YPbPr(1Fh)
- AV 2: Audio L/R in, CVBS, S-Video Y/C
- AV 3: YPbPr (2Fh), HDMI, Audio L/R in, VGA PC-in

Power

- Power consumption: 350 W
- Standby power consumption: < 3 W
- Mains power: AC 100 - 240 V, 50/60 Hz
- Ambient temperature: 5 °C to 40 °C

Dimensions

- Product weight: 42 kg
- Weight incl. Packaging: 47 kg

Accessories

- Included accessories: Table top stand, Wall mounting bracket, Mini-jack to CVBS-L/R cable, VGA to YPbPr-Cinch cable
- Optional accessories: Floor stand

Highlights

Digital Crystal Clear

Digital Crystal Clear is a package of picture innovations that digitally adjusts and optimizes picture quality to optimal contrast, color and sharpness levels. It's like watching vivid cinema-like images.

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

3D Combfilter

The 3D comb filter separates brightness and color signals better in 3D domain to eliminate cross-color, cross-luminance and dot-crawl distortion - all of which detract from your viewing pleasure. The 3D digital comb filter performs field-by-field comparisons of the television image to accurately separate the color from the black-and-white information and remove both horizontally and vertically hanging dots, as well as dot crawl. The result is a razor sharp image.

Active Control + Light Sensor

Active Control is a unique and intelligent way of optimizing picture quality by measuring and analyzing the incoming signal to automatically adjust picture quality settings. Active Control with Light Sensor uses a sensor to adjust the picture brightness depending on the room light conditions.

Virtual Dolby Surround

Virtual Dolby Surround is a processing technology for enhancing surround sound effects. It will create the sensation of Dolby Pro Logic without the necessity of additional rear speakers. You become totally immersed in your television experience.



Issue date 2014-02-06

Version: 2.0.3

12 NC: 8670 000 22007
EAN: 87 10895 86681 1

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* For a maximum picture quality without distortion it is necessary a high quality digital signal in widescreen format or to use a signal converter/decoder. Static images can damage the quality of the screen.

* Avoid extensive use of the set in a volume higher than 85 decibel because this may damage your hearing.