

Philips 6700 series  
4K Ultra Slim Smart LED  
TV

**164 cm (65")**

4K Ultra HD LED TV  
Quad Core  
DVB-T/T2



**65PUT6703S**

## Ultra Slim 4K UHD LED Smart TV

with Ambilight 3-sided and Saphi system

Sit back and enjoy the rich quality of 4K UHD on a Smart TV that's brilliantly easy to use. Access favourite content instantly with SAPHI. Pixel Precise Ultra HD makes everything look smooth and sharp. And Ambilight ties it all together.

### Passionate about Picture Quality

- Micro Dimming optimizes the contrast on your TV
- Experience better contrast, color & sharpness with HDR Plus

### SAPHI: intuitive app content selection

- SAPHI. The smart way to enjoy your TV.

### Slim TV. Clear sound.

- Deep bass and crystal-clear dialogue.

### Sharp. Light. Beautiful.

- Ambilight. Take the emotion beyond the screen.
- Ultra-slim frame with aluminium coloured bezel & stand.

### See every detail

- 4K Ultra HD. Pictures so sharp you'll think you're there.
- Pixel Precise Ultra HD. Fluid images with incredible depth.

# PHILIPS

# Highlights

## Ambilight 3-sided



With Philips Ambilight, movies and games feel more immersive. Music gets a light show. And your screen will feel bigger than it is. Intelligent LEDs around the edges of the TV cast on-screen colours onto the walls, and into the room, in real time. You get perfectly tuned ambient lighting. And one more reason to love your TV.

## Metal Angled Stand

Modern European Design is visible in the floating aluminium stands finished in dark silver matching the ultra-slim bezel.

## 4K Ultra HD



With four times the resolution of conventional Full HD, Ultra HD lights up your screen with

over 8 million pixels and our unique Ultra Resolution Upscaling technology. Experience improved images regardless of the original content, and enjoy a sharper picture with superior depth, contrast, natural motion and vivid details.

## Pixel Precise Ultra HD

The beauty of 4K Ultra HD TV is in savoring every detail. Philips Pixel Precise Ultra HD engine converts any input picture into stunning UHD resolution on your screen. Enjoy a smooth, yet sharp moving image and exceptional contrast. Discover deeper blacks, whiter whites, vivid colors and natural skin tones - every time, and from any source.

## HDR Plus



High Dynamic Range Plus redefines in-home entertainment. Experience a sensory journey with its advanced processing power. Capture the richness and liveliness of the content just as the creator intended. Get ready to enjoy brighter highlights, greater contrast, a broader range of colors and detail like never before.

## Saphi TV system

SAPHI is a fast, intuitive operating system that makes your Philips Smart TV a real pleasure to use. Enjoy great picture quality and one-button access to a clear icon-based menu. Operate your TV with ease, and quickly navigate to popular Philips Smart TV apps including YouTube, and more.

## DTS HD

DTS HD optimizes sound processing by preserving the original sound content so that you can enjoy a better sound from your speakers with crystal-clear dialog.

## Micro Dimming



Thanks to our special software that analyzes the picture in 6400 different zones and adjusts it accordingly, you'll enjoy incredible contrast and image quality for a truly lifelike visual experience.



# Specifications

## Ambilight

- Ambilight Version: 3-sided

## Picture/Display

- Aspect ratio: 16:9
- Display: 4K Ultra HD LED
- Panel resolution: 3840x2160
- Picture enhancement: Micro Dimming, 1100 PPI, Pixel Precise Ultra HD, Ultra Resolution

## Supported Display Resolution

- Video inputs on HDMI1: up to 4K UHD 3840x 2160 @30Hz
- Computer inputs on HDMI1: up to 4K UHD 3840x 2160 @30Hz
- Computer inputs on HDMI2/3: up to 4K UHD 3840x 2160 @60Hz
- Video inputs on HDMI2/3: up to 4K UHD 3840x 2160 @60Hz

## Tuner/Reception/Transmission

- Digital TV: DVB-T/T2
- Video Playback: PAL, SECAM
- MPEG Support: MPEG2, MPEG4
- TV Program guide\*: 8 day Electronic Program Guide

## Smart TV Features

- User Interaction: MultiRoom client, SimplyShare, Wi-Fi Miracast certified\*
- Program: Pause TV
- SmartTV apps\*: Open internet browser, Youtube, Netflix TV, Philips store
- Ease of Installation: Auto detect Philips devices, Device connection wizard, Network installation wizard, Settings assistant wizard
- Firmware upgradeable: Firmware auto upgrade wizard, Firmware upgradeable via USB, Online firmware upgrade
- Screen Format Adjustments: Basic - Fill Screen, Fit to screen, Zoom, stretch
- Philips TV Remote app\*: Apps, Channels, Control, NowOnTV, TV Guide, Video On Demand

## Multimedia Applications

- Video Playback Formats: Containers: AVI, MKV, H264/MPEG-4 AVC, MPEG-1, MPEG-2, MPEG-4, WMV9/VC1, VP9, HEVC
- Music Playback Formats: AAC, MP3, WAV, WMA (v2 up to v9.2), WMA-PRO (v9 and v10)

- Subtitles Formats Support: .SML, .SRT, .SUB, .TXT, .ASS, .SSA
- Picture Playback Formats: JPEG, BMP, GIF, PNG

## Processing

- Processing Power: Quad Core

## Sound

- Output power (RMS): 20W
- Sound Enhancement: Incredible Surround, Clear Sound, Auto Volume Leveler, Smart Sound

## Connectivity

- Number of AV connections: 1
- Number of HDMI connections: 3
- HDMI features: Audio Return Channel, 4K
- Number of component in (YPbPr): 1
- EasyLink (HDMI-CEC): Remote control pass-through, System audio control, System standby, One touch play
- Number of USBs: 2
- Wireless connection: Wi-Fi 802.11n 2x2 integrated, Dual Band
- Other connections: Digital audio out (optical), Ethernet-LAN RJ-45, Audio L/R in, Headphone out, Antenna IEC75

## Power

- Mains power: 220-240V 50/60Hz
- Ambient temperature: 5 °C to 35 °C
- Power Saving Features: Auto switch-off timer

## Accessories

- Included accessories: Remote Control, 2 x AAA Batteries, Power cord, Quick start guide, Legal and safety brochure, Table top stand

## Dimensions

- Set Width: 1462.3 mm
- Set Height: 852.3 mm
- Set Depth: 87.5 mm
- Product weight: 24.45 kg
- Set width (with stand): 1462.3 mm
- Set height (with stand): 884.1 mm
- Set depth (with stand): 295.7 mm
- Product weight (+stand): 25.1 kg
- Box width: 1600 mm
- Box height: 995 mm
- Box depth: 185 mm
- Weight incl. Packaging: 32.0 kg

## Connections


### Side



### Rear



### Bottom



Issue date 2023-10-18

Version: 3.1.1

EAN: 87 18863 01814 9

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)



- Wall mount compatible: 400 x 200 mm

\* EPG and actual visibility (up to 8 days) is country and operator dependent.  
\* (Philips) only compatible with specific Philips player device.  
\* Smart TV app offerings vary per TV model and country. For more details please visit: [www.philips.com/smarttv](http://www.philips.com/smarttv).  
\* Compatibility depends on Wifi Miracast certification & Android 4.2 or later. For more details please refer to your device documentation.