

Philips 9000 series
Smart LED TV with
Ambilight Spectra 3 and
Perfect Pixel HD

81 cm (32")

Full HD 3D Max
DVB T/C/S2

32PFL9606K



Award winning performance

3 sided Ambilight and best picture quality

Awarded Best LCD TV by EISA for the last 10 years, the 9000 series brings innovation in picture and connectivity. Perfect Pixel HD Engine and LED give you the most true to life images. Ambilight and 3D Max bring movies to life.

Intensify your viewing experience

- Ambilight Spectra 3-sided intensifies the viewing experience
- 3D Max for a truly immersive Full HD 3D experience

Award winning picture and sound performance

- Full HD TV and Perfect Pixel HD Engine for unrivaled clarity
- Brilliant LED images with incredible contrast
- 600Hz Perfect Motion Rate (PMR) for superb motion sharpness
- Perfect Natural Motion for ultra smooth Full HD movies
- 40W SoundStage for dynamic powerful sound in a ultra slim TV

Enjoy the online world with Smart TV

- A wealth of online apps, videos to rent and catch-up TV
- Control the TV with your smart phone, tablet or keyboard
- With SimplyShare, enjoy photos, music and movies on your TV
- Find, schedule, record* & pause TV
- Integrated Wi-Fi to use Net TV apps and SimplyShare wireless



PHILIPS

Highlights

Ambilight Spectra 3



Add a new dimension to your viewing experience with Ambilight Spectra 3. This patented Philips technology enlarges the screen by projecting a glow of light from 3 sides of the back of the TV screen onto the surrounding wall. Ambilight automatically adjusts the color and brightness of the light to match the TV picture. Thanks to the wall-adaptive function, the color of the light is perfect, regardless of your wall color.

3D Max



Be enthralled by 3D movies in your own living room with the 3D Max. The combination of the fast display and Active shutter glasses bring real life depth in Full HD resolution. Your TV is ready for the 3D Max experience by adding the 3D Max glasses.

Perfect Pixel HD

Experience unrivaled sharpness and clarity with Perfect Pixel HD Engine. Each pixel of the picture is enhanced to better match the surrounding pixels. The result is a unique combination of sharpness, natural detail, vivid colors, superior contrast, and smooth natural motion. Clean and razor sharp images come from artifact and noise detection and reduction in all content sources. The Full HD screen with 1920x1080 pixels produces brilliant flicker-free pictures with superb brightness.

Full HD LED TV



The most advanced LED lighting technology in this Full HD LED TV combines an eye-catching minimalistic design with stunning image quality as well as the lowest power consumption in its category. On top of that, LED lighting technology does not contain any hazardous materials. Thus, with LED backlight you can enjoy low power consumption, high brightness, incredible contrast, sharpness and vibrant colors.

600Hz Perfect Motion Rate



600Hz Perfect Motion Rate (PMR) creates extreme motion sharpness for clear and vibrant images in fast action movies. The new Philips PMR standard shows the combined visible effect of the fastest panel refresh rate, Perfect Natural Motion and unique processing formula, for unprecedented motion sharpness.

40W SoundStage




Philips SoundStage with 40W RMS output power has far more dynamism and power than

anything heard on LCD TVs today. Now we can combine an ultra thin design with powerful TV sound. The TV stand houses an advanced ultra-thin speaker system. It combines deep, warm bass with excellent clarity. Also in wallmount position you can enjoy the excellent sound experience, thanks to advanced processing corrections. Enjoy great sound and a thin design.



Smart TV

Smart TV for an easier & wireless TV experience in 4 areas. Net TV lets you enjoy a wealth of online apps on your TV: rent movies, watch catch-up TV and enjoy social media. Stay in Control: change channels or enter text using your Smartphone or tablet. Use SimplyShare to enjoy photos, music and video from your computer, phone & tablet on your TV. Watch your favorite Program whenever you want: our program guide helps you with Smart USB recording.



2 in 1 Stand

This TV comes with a revolutionary table top stand that can also be use to wall-mount your television. There is no need to buy additional wall-mount brackets, it comes conveniently with the TV in the box. The patented design allows for no less than 4 mounting positions: Tabletop swivel stand, Wallmount with swivel, ultra flat wallmount and Vesa compatible wallmount fixation. Mounting is easy with 2 fixation points on the wall and smart leveling to get the TV perfectly horizontal with the touch of your hand!



Specifications

Ambilight

- Ambilight Version: 3-sided
- Ambilight Features: Ambilight Spectra 3, Wall colour adaptive, Lounge light mode

Picture/Display

- Display: edge LED backlight
- Diagonal screen size: 32 inch / 81 cm
- Panel resolution: 1920x1080p
- 3D: 3D Max*
- Aspect ratio: 16:9
- Brightness: 450 cd/m²
- Peak Luminance ratio: 65 %
- Dynamic screen contrast: 500.000:1
- Response time (typical): 1 ms
- Picture enhancement: Perfect Pixel HD Engine, Perfect Natural Motion, Active Control + Light sensor, Wide color gamut display, Super Resolution, Perfect Colors, Perfect Contrast, Scanning backlight, 600 Hz Perfect Motion Rate
- Color cabinet: Stainless Steel

Sound

- Output power (RMS): 40W (2 x 20W)
- Sound Enhancement: Auto Volume Leveler, Clear Sound, Incredible Surround, Treble and Bass Control
- Loudspeaker types: Soundstage stand enclosure

Smart TV Applications

- Control: MyRemote app (iOS & Android), USB Keyboard & Mouse support
- SimplyShare: DLNA media browser, USB media browser, WiFi MediaConnect*
- Net TV: Catch-up TV, Online Video stores, Open Internet browser, Online apps
- Program: Pause TV, USB recording

Connectivity

- Number of HDMI connections: 4
- HDMI features: 3D, Audio Return Channel
- EasyLink (HDMI-CEC): Remote control pass-through, System audio control, System standby, Plug & play add to Homescreen, Auto subtitle shift (Philips), Pixel Plus link (Philips), One touch play
- Number of component in (YPbPr): 1
- Number of scarts (RGB/CVBS): 1
- Number of USBs: 2
- Other connections: Antenna IEC75, Antenna F-

- type, Common Interface Plus (CI+), Ethernet-LAN RJ-45, SD card slot (Videostore), Digital audio out (optical), PC-in VGA + Audio L/R in, Headphone out, Service connector
- Wireless connection: WiFi Certified
- Satellite antenna interface: DiSeq 1.0

Multimedia Applications

- Video Playback Formats: Codec support:, Containers: AVI, MKV, H264/MPEG-4 AVC, MPEG-1, MPEG-2, MPEG-4, WMV9/VC1
- Music Playback Formats: AAC, MP3, WMA (v2 up to v9.2)
- Picture Playback Formats: JPEG
- Net TV: Included

Supported Display Resolution

- Computer inputs: up to 1920x1080 @ 60Hz
- Video inputs: 24, 25, 30, 50, 60 Hz, up to 1920x1080p

Convenience

- PC network link: DLNA 1.5 certified
- USB recording*: Pause-live TV, Record in Standby, Scheduled record via IP-EPG*
- Electronic Program Guide: 8day Electronic Program Guide*
- Ease of Installation: Auto detect Philips devices, Channel installation wizard, Device connection wizard, Network installation wizard, Settings assistant wizard, 2-in-1 Wallmount Stand
- Ease of Use: One-stop Home button, Onscreen Usermanual, Touch control buttons
- Screen Format Adjustments: Autofill, Autozoom, Movie expand 16:9, Super Zoom, Unscaled, Widescreen
- Signal strength indication
- Teletext: 1200 page Hypertext
- Firmware upgradeable: Firmware auto upgrade wizard, Firmware upgradeable via USB, Online firmware upgrade

Tuner/Reception/Transmission

- Aerial Input: 75 ohm coaxial (IEC75), 75 ohm F-type
- Digital TV: DVB-C MPEG2*, DVB-C MPEG4*, DVB-S2 MPEG4 HD, DVB-T MPEG4*, DVB-S HD+ support (Astra)

- Video Playback: NTSC, PAL, SECAM
- LNB: 1 to 4 LNBs supported

Power

- Mains power: AC 220 - 240 V 50/60Hz
- Ambient temperature: 5 °C to 35 °C
- Energy Label Class: A
- Eu Energy Label power: 42 W
- Annual energy consumption: 58 kWh
- Standby power consumption: <0.1 W
- Power Saving Features: 0 Watt Power-off switch, Auto switch-off timer, Eco mode, Eco settings menu, Light sensor, Picture mute (for radio)
- Presence of lead: Yes*
- Off mode power consumption: < 0.01


Dimensions

- Box dimensions (W x H x D): 1017 x 607 x 160 mm
- Set dimensions (W x H x D): 761 x 478 x 32 mm
- Set dimensions with stand (W x H x D): 761 x 533 x 214 mm
- Product weight: 9 kg
- Product weight (+stand): 11 kg
- Compatible wall mount: adjustable 200 x 100mm
- Stand width: 402 mm

Accessories

- Included accessories: Power cord, Remote Control, 2x battery CR2032, Tabletop swivel stand, Quick start guide, Safety/legal instructions, Wi-Fi MediaConnect CD, Wall mounting bracket
- Optional accessories: 3DMax Glasses PTA516 (Active), 3D TV glasses PTA03 (Active)

Connections



Issue date 2022-06-03

Version: 15.3.12

12 NC: 8670 000 74658
EAN: 87 12581 59529 6

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* 3D TV requires Accessory PTA516 (Active shutter glasses), a 3D compatible source device, and 3D source material.

* Net TV: Visit www.philips.com/smarttv to discover the services offering in your country.

* Wi-Fi Media connect: The playback of video can be affected by your PC speed and Wi-Fi bandwidth. For minimum and recommended system requirements go to www.philips.com/wifimediaconnect. Displays content with a delay of some seconds. Small differences of image and sound can occur.

* The TV supports DVB reception for 'Free to air' broadcast. Specific DVB operators may not be supported. An up to date list can be found in the FAQ section of the Philips support website. For some operators Conditional Access and subscription are required. Contact your operator for more information.

* 8 days EPG, service not available in all countries

* USB pause and recording requires an empty USB Hard Disk of at least 32GB, recommended is 250GB (not supplied). Function available only for DVB-T C and S channels, not on analog broadcast or external inputs.

* USB recording only for digital channels covered by the TV IP bases Electronic Programme Guide (country and channel restrictions may apply), recordings may be limited by broadcast copy protection (CI+). An internet connection is required.

* Energy consumption in kWh per year, based on the power consumption of the television operating 4 hours per day for 365 days. The actual energy consumption will depend on how the television is used.

* This television contains lead only in certain parts or components where no technology alternatives exist in accordance with existing exemption clauses under the RoHS Directive.