



Philips 5000 series  
LCD TV with Pixel Plus  
HD

Philips 32"  
HD Ready

32PFL5409



## Brilliant design, powerful performance

With superb picture and sound.

Experience brilliant performance with a HD 1366 x 768p display. Combined with a powerful Pixel Plus HD Engine and fantastic invisible sound, this Flat TV will never let you down.

### Vivid and razor sharp pictures

- Pixel Plus HD for better details, depth and clarity
- HD LCD display, with a 1366 x 768p resolution
- Dynamic contrast 50000:1 for incredible rich black details
- Active Control with Light Sensor optimizes picture quality
- Native cinema mode for real movie experience

### Pure and lifelike sound

- 20W for superior sound clarity
- Dynamic Bass Enhancement for cinematic sound
- Invisible speakers with incredible surround

### Easy to connect and enjoy

- USB for fantastic multimedia playback
- 3 HDMI inputs with Easylink for a full HD connection
- PC-input allows you to use your TV as a PC monitor
- Smart Picture and Smart Sound to personalize your viewing

# PHILIPS

# Highlights

## Pixel Plus HD

Pixel Plus HD is a picture processing technology that enables viewers to watch content that is vivid, natural and real. The result are superbly life-like pictures with incredible details and depth from any HD source.

## LCD display, 1366 x 768p

This WXGA display with state-of-the-art LCD screen technology gives you widescreen HD resolution of 1366 x 768p pixels. It produces brilliant flicker-free progressive scan pictures with optimum brightness and superb colors. This vibrant and sharp image will provide you with an enhanced viewing experience.

## USB (multimedia)

The USB connector allows access to jpeg photos, mp3 music and video files of most USB-sticks (USB memory-class device). Plug

the USB into the slot at the side of the TV and access the multimedia content using the easy on screen content browser. You can now view and share your videos, photos and music.

## 3 HDMI inputs with EasyLink

EasyLink uses the HDMI CEC industry standard protocol to share functionality between connected devices and the TV. With Easylink only one remote control is needed to operate main functionalities on your TV and connected devices. HDMI makes an uncompressed digital RGB connection from the source to the screen for the ultimate picture quality. HDMI uses HDCP copy protection. With 2 HDMI inputs on the back and 1 HDMI on the side of the TV you can connect multiple HD sources, for instance an HD settop box, a Blu-ray player, and Game Console or Digital Camcorder.

## PC input (HDMI+VGA)

With PC input you can use your TV as a PC monitor either using a HDMI-DVI cable/ converter (for digital signals) or VGA cable (for analog signals).

## Smart Picture and Smart Sound

Philips preset modes for Smart Picture and Smart Sound provide you with direct access via a single key on the remote control. You can select optimized picture and sound settings for the various picture and sound modes.

## Invisible speakers

An invisible sound system that blends perfectly with the design of the cabinet. The Incredible Surround allows you to experience total surround with greater depth and width of sound. It gives a clear and spacious sound stage complementary to the rich viewing experience.



# Specifications

## Picture/Display

- Aspect ratio: Widescreen
- Brightness: 450 cd/m<sup>2</sup>
- Dynamic screen contrast: 50 000:1
- Response time (typical): 5 ms
- Viewing angle: 178° (H) / 178° (V)
- Diagonal screen size: 32 inch / 81 cm
- Display screen type: LCD WXGA+ Active Matrix TFT
- Panel resolution: 1366 x 768p
- Picture enhancement: Pixel Plus HD, 3/2 - 2/2 motion pull down, 3D Combfilter, Active Control + Light sensor, Color Enhancement, Dynamic contrast enhancement, Jagged Line Suppression, Sharpness Adjustment, Dynamic Noise Reduction, 2D/3D noise reduction, 1080p 24/25/30Hz processing, 1080p 50/60Hz processing
- Screen enhancement: Semi-glare

## Supported Display Resolution

### Computer formats

Resolution	Refresh rate
640 x 480	60, 72, 75, 85Hz
800 x 600	60, 72, 75, 85Hz
1024 x 768	60, 70, 75, 85Hz
1280 x 768	60Hz
1280 x 1024	60Hz
1360 x 768	60Hz

Via HDMI/DVI input

### Video formats

Resolution	Refresh rate
480i	60Hz
480p	60Hz
576i	50Hz
576p	50Hz
720p	50, 60Hz
1080i	50, 60Hz
1080p	24, 25, 30, 50, 60Hz

## Sound

- Output power (RMS): 20W
- Sound Enhancement: Auto Volume Leveller, Dynamic Bass Enhancement, Incredible Surround, Treble and Bass Control
- Sound System: Mono, Nicam Stereo, Stereo

## Loudspeakers

- Built-in speakers: 2

## Convenience

- Child Protection: Child Lock+Parental Control
- Clock: On main display, Sleep Timer, Wake up Clock, Wake Up Timer
- Connection Enhancement: Easy link
- Ease of Installation: Autostore, Fine Tuning, PLL Digital Tuning, Plug & Play, Program Name, Sorting
- Ease of Use: Auto Volume Leveller (AVL), Graphical User Interface, On Screen Display, Side Control, Smart Picture, Smart Sound, EasyLink
- On-Screen Display languages: Arabic, English, French, Thai, Traditional Chinese
- Picture in Picture: Picture in graphics
- Remote Control: TV
- Remote control type: PF02A09B
- Screen Format Adjustments: 4:3, Movie expand 14:9, Movie expand 16:9, Subtitle Zoom, Super Zoom, Widescreen
- Teletext: 1000 page Smart Text
- Teletext enhancements: 4 favourite pages
- Signal strength indication
- Firmware upgradeable: Firmware upgradeable via USB
- Multimedia: USB media browser

## Multimedia Applications

- Playback Formats: MP3, JPEG Still pictures, MPEG1, MPEG4, RealMedia Video
- Playback enhancement: Picture slideshow

## Tuner/Reception/Transmission

- Aerial Input: 75 ohm coaxial (IEC75)
- TV system: PAL B/G, PAL D/K
- Video Playback: NTSC, PAL
- Tuner bands: Hyperband, S-Channel, UHF, VHF
- Number of Preset Channels: 99

## Connectivity

- AV 1: Audio L/R in, YPbPr
- AV 2: Audio L/R in, YPbPr
- AV 3: Audio L/R in, CVBS in
- Front / Side connections: HDMI v1.3, S-video in, CVBS in, Audio L/R in, Headphone out, USB
- Other connections: Monitor out, CVBS, L/R (cinch), PC-in VGA + Audio L/R in
- HDMI 1: HDMI v1.3
- HDMI 2: HDMI v1.3
- EasyLink (HDMI-CEC): One touch play, EasyLink, Remote control pass-through, System audio

control, System standby

## Power

- Ambient temperature: 5 °C to 40 °C
- Mains power: 110-240V; 50-60Hz
- Power consumption: 120 W
- Standby power consumption: (typical) <0.15W


## Dimensions

- Set dimensions (W x H x D): 810 x 519 x 95 mm
- Set dimensions with stand (W x H x D): 810 x 570 x 230 mm
- Weight incl. Packaging: 17.5 kg
- Product weight: 10.5 kg
- Product weight (+stand): 12.5 kg
- Box dimensions (W x H x D): 1034 x 662 x 246 mm
- VESA wall mount compatible: 200 x 200 mm

## Accessories

- Included accessories: Tabletop swivel stand, Power cord, Quick start guide, User Manual, Remote Control, 2 x AAA Batteries
- User Manual: Arabic, English, French, Malay, Thai, Traditional Chinese

## Rear connectors



## Side



Issue date 2019-06-28

Version: 5.6.7

12 NC: 8670 000 51769  
EAN: 87 12581 47810 0

© 2019 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)