

Philips Professional LCD TV

26" System
LCD integrated digital



26HFL5850D

# For delighted guests

Philips Digital Hospitality TV with SmartCard slot

This stylish Hospitality TV with integrated SmartCard slot is the best tamper-proof interactive solution for guest infotainment. Your guests can enjoy digital TV, connect their own devices and even enjoy music in the bathroom.

#### Integrated system solution and future proof

- Tamper proof SmartCard slot
- · Remote software upgrading
- HD Ready with integrated DVB-T tuner

#### Differentiating guest experience

- · Integrated clock display with wake-up and message alarm
- USB Connector for easy, instant multimedia playing
- PC input lets you also use your TV as a PC monitor
- Philips Connectivity Panel compatible to enjoy guest devices

### Best total cost of ownership

- $\bullet$  USB cloning of all settings for quick installation
- · External loudspeaker connector and extra power supply

#### Sustainable and safe

- SmartPower for energy saving
- · Eco-friendly design and flame-retardant housing



# Highlights

#### **Integrated SmartCard Slot**

The integrated SmartCard slot allows third parties to add new functionality to the TV through application cards, without the need for additional boxes and external connections. The TV can also be connected to external decoders and set-top boxes of all major interactive system providers, through the SerialXpress Control Interface (supporting UART and RS232 protocols) and the SmartPlug Control interface.

#### **USB Cloning**

Provides the ability to easily copy all programming and channel programming settings from one TV into other TV sets in less than a minute. The feature ensures uniformity between TV sets and significantly reduces installation time and costs.

#### Remote software upgrading

The TV software that controls hotel-specific features can be upgraded remotely through a certified system provider.

#### Integrated clock display

The built-in clock display, which is also a wakeup alarm, eliminates the need for investment in an additional clock with cables and connections in the room. Automatic time synchronisation via teletext and preservation of alarm settings during short power outages further enhances guest comfort

#### **USB** multimedia playing

This Philips TV allows the guest to connect a USB stick for easy and instant playing of multimedia content. Playback formats supported are MP3, Slideshow files (.alb) and IPEG Still pictures.

## **PC** input

With PC input you can connect your TV to a computer and use the TV as a PC monitor.

#### External loudsp and power supply

The TV is equipped with an amplified audio connector for easy installation of external speakers (like for bathrooms), eliminating the need for investments in external equipment. The extra integrated power supply avoids the need for a separate power supply for an interactive system. In case of stand-alone use, the additional power supply can be switched off to save energy.

#### **Connectivity Panel compatible**

This TV works seamlessly with Philips Connectivity Panels. The guest can easily connect and enjoy media from a PC, MP3 player, DVD player, camcorder and various other devices. With autosensing, the Connectivity Panel and the TV will automatically switch to display the content from the connected guest device.

#### **SmartPower**

The backlight intensity can be controlled and pre-set by the system to reduce the power consumption by up to 50%, which saves substantially on energy costs.

#### **Eco-friendly design**

Sustainability is integral to the way Philips does business. Philips TVs are designed and produced according to our EcoDesign principles aimed at minimising overall environmental impact, through lower power consumption, removal of hazardous substances, lower weight, more efficient packaging and better recyclability. Philips TVs also have a special housing of flame-retardant material. Independent tests carried out by emergency fire services have shown that whereas TVs can sometimes intensify fires caused by external sources, Philips TVs will not contribute to the fire.

















• Standby power consumption: <2 W (w. clock)

• Set dimensions (W  $\times$  H  $\times$  D): 686  $\times$  452  $\times$  103 mm

Passive stand-by consumption: 1.2 W

• Active stand-by consumption: 20 W

• Ambient temperature: 5°C to 40°C

• Set dimensions with stand (W x H x D):

VESA wall mount compatible: 200 x 100 mm

Included Accessories: Power cord, Tabletop swivel

Optional accessories: Set up Remote RC2573GR,

Guest remote control 22AV1105, Wall mount

**Dimensions** 

686 x 510 x 220 mm

764 x 522 x 259 mm

Product weight: 10 kg

Colour cabinet: Black

stand, Warranty Leaflet

(tilt) 22AV3200/10

Accessories

Box dimensions (W x H x D):

· Product weight (+stand): 13 kg

· Weight incl. Packaging: 16 kg

# **Specifications**

#### Picture/Display

- Diagonal screen size: 26 inch / 66 cm
- · Aspect ratio: 16:9, Widescreen
- Display screen type: LCD WXGA Active Matrix
- Panel resolution: 1366 x 768p
- Brightness: 450 cd/m²
- · Contrast ratio (typical): 2500:1
- Dynamic screen contrast: 30000:1
- Response time (typical): 6 ms
- Viewing Angle (H / V): 176 / 176 degree
- · Screen enhancement: Anti-Reflection coated
- Picture enhancement: 3/2 2/2 motion pull down, 3D Combfilter, Active Control, Black stretch, Blue stretch, Colour Enhancement, Colour Transient Improvement, Digital Noise Reduction, Luminance Transient Improver, Motion adaptive deinterlacing, Progressive Scan, Automatic skin tone correction, Dynamic contrast enhancement, White stretch, Green stretch, Pixel Plus HD

#### **Supported Display Resolution**

Video formats

Resolution	Refresh rate
480i	60 Hz
480p	60 Hz
576i	50 Hz
576p	50 Hz
1080i	50, 60 Hz
720p	50, 60 Hz

Computer formats

Resolution	Refresh rate
$640 \times 480$	60 Hz
$800 \times 600$	60 Hz
$1024 \times 768$	60 Hz
1280 x 1024	60 Hz
1366 x 768	60 Hz

#### Tuner/Reception/Transmission

- · Aerial Input: 75 ohm coaxial (IEC75)
- Number of Pre-set Channels: 250
- Tuner bands: Hyperband, S-Channel, UHF, VHF
- Tuner Display: PLL
- TV system: PAL I, PAL B/G, PAL D/K, SECAM B/G, SECAM D/K, SECAM L/L', DVB COFDM 2K/8K
- · Video Playback: PAL, SECAM, NTSC
- DVB: DVB Terrestrial\*

#### Sound

- Output power (RMS): 2 x 5 W
- · Sound System: Mono, Stereo, Nicam Stereo, BBE, Dolby Digital (AC-3), Virtual Dolby Digital
- · Sound Enhancement: Auto Volume Leveller. Incredible Surround, Smart Sound
- · Equalizer: 5-bands

#### Loudspeakers

• Built-in speakers: 2

### **Connectivity**

- · Number of Scarts: 2
- Ext 1 Scart: Audio L/R, CVBS in/out, RGB
- Ext 2 Scart: Audio L/R, CVBS in/out

- Ext 3: Audio L/R in, YPbPr
- Ext 4: HDMI v1.3
- Ext 5: HDMI v1.3
- Ext 6: HDMI v1.3
- · Front/Side connections: Audio L/R in, CVBS in, Headphone out, S-video in, USB 2.0, HDMI v1.3
- · Other connections: Analogue audio Left/Right out, S/PDIF out (coaxial), Headphone out, PC-In VGA, Common Interface
- Connectivity Enhancements: Serial Xpress interface, SmartPlug Xpress Interface, RJ12 connector, RJ45 connector, SmartCard Expansion Slot, Fast Infrared loop through, HM-Link, External Loudspeaker connector, Extra Power supply 12 V/ 1 W, Power on scart, USB2.0

#### Convenience

- · Ease of Installation: Advanced Hotel Mode, Fine Tuning, PLL Digital Tuning, Programme Name, Cloning of TV settings via USB, Installation menu locking, Security menu access, Keyboard lock-out
- Ease of Use: Auto Volume Leveller (AVL), 1 channel list analogue/digital, Smart Picture, Smart Sound
- · Comfort: Hotel Guest features, Auto power on, Welcome message, Message indicator, Switch on channel, Volume limitation
- · Interactive hotel features: Connectivity panel compatible
- Prison mode: Teletext and MHEG disable
- · Clock: Integrated LCD Clock Display, Sleep Timer, Wake-up Clock
- Clock Enhancements: Synchro Time via TXT/DVB
- Teletext: 1000-page Smart Text
- · Teletext languages: Western European, Eastern European, Cyrillic
- Electronic Programme Guide: Now + Next EPG
- · Screen Format Adjustments: 4:3, Full screen, Movie expand 14:9, Movie expand 16:9, Widescreen, Subtitle Zoom, Super Zoom, Auto Format
- Firmware upgradeable: Local upgrade total TV softw., Remote upgrade hotel TV softw, Firmware upgradeable via USB
- Other convenience: Kensington lock

#### **Healthcare**

- Control: Multi remote control
- Convenience: Headphone out, Independent main speaker mute
- · Safety: Double isolation Class II

#### **Multimedia Applications**

- Multimedia connections: USB
- · Playback Formats: MP3, JPEG Still pictures, Slideshow files (.alb)

#### **Green Specifications**

- Safety: Flame-retardant housing
- SmartPower

#### **Power**

- Mains power: 220 240 V, 50/60 Hz
- Power consumption: 120 W



Issue date 2009-08-14

Version: 2.2.7

© 2009 Koninklijke Philips Electronics N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips

12 NC: 8670 000 40818 EAN: 87 12581 43155 6 Electronics N.V. or their respective owners.

<sup>\*</sup> For information on DVB-T enrolled countries, please ask your Philips contact.

www.philips.com