



Philips
Professional LCD TV with
Pixel Plus 3 HD

- 66 cm (26")
- LCD
- HD Ready

26HF5335D

Advanced design and outstanding value

Philips HD LCD TV for Hospitality

This professional LCD TV with Smart Hotel Mode offers convenient setup and advanced programming features not found on retail televisions backed by our unique Five Star Service advanced exchange warranty. Ideal for hotels with no PPV system.

Advanced hotel features and future proof

- Smart Hotel Mode
- 2 HDMI inputs for full digital HD connection in one cable

Best total cost of ownership

- Five Star Service - two-year advanced exchange warranty
- USB cloning of all settings for quick installation
- Low power consumption

Great viewing experience and guest comfort

- HDTV for Hospitality
- Pixel Plus 3 HD image enhancement

Sustainable and safe

- Eco-friendly Design
- Flame retardant housing

PHILIPS

Highlights

Smart Hotel Mode

Allows configuration of the TV for limited access, ideal for hotel use. Access to the user menu can be blocked, which enables you to specify channel, picture, and sound settings which your guest will be unable to modify. Picture and sound preferences may be selected from presets on the remote, offering guest selection, but never overwriting your defined settings. Switch on and maximum volume can also be specified so the set always turns on and operates at a comfortable volume. Channels can be blanked to prevent access to premium or adult content. Includes a forced power on mode.

2 HDMI inputs

HDMI makes an uncompressed digital RGB connection from the source to the screen. By eliminating conversion to an analog signal, it delivers an unblemished image. The non-degraded signal reduces flicker and leads to a clearer picture. HDMI intelligently communicates the highest output resolution with the source device. The HDMI input is fully backward compatible with DVI sources but includes digital audio. HDMI uses HDCP copy protection. With 2 HDMI inputs you can connect multiple HD sources, for instance an

HD settop box, and a Blu-ray player. Your TV is fully prepared for the HD future.

HDTV for Hospitality

There are many ways you may choose to offer HDTV to your guests, but regardless of the source, Philips Hospitality televisions will always deliver the best viewing experience possible to your guests by utilizing the most advanced FlatTV displays and award winning technologies such as Pixel Plus 3 HD.

Pixel Plus 3 HD

Pixel Plus 3 HD offers an optimal combination of sharpness, natural detail, vivid colors, and smooth natural motion on any video source, including high definition.

Five Star Service

Philips offers unmatched commitment to keeping your guest rooms in working order. Our products are so reliable that we offer a two-year advanced exchange warranty. In the event that something does go wrong, we guarantee to ship a replacement set to you, within 72 hours during the first year.

USB Cloning

Provides the ability to easily copy all programming and channel programming settings from one TV into other TV sets in less than a minute. The feature ensures uniformity between TV sets and significantly reduces installation time and costs.

Low power consumption

Philips TVs are designed to minimize power consumption. This will not only reduce environmental impact but also lower operating costs.

Eco-friendly Design

Philips TVs are designed and produced according to our EcoDesign principles aimed at minimizing overall environmental impact, through lower power consumption, removal of hazardous substances, lower weight, more efficient packaging and better recyclability.

Flame retardant housing

Philips TVs have a special housing of flame retardant material. Independent tests carried out by emergency fire services have shown that whereas TVs can sometimes intensify fires caused by external sources, Philips TVs will not contribute to the fire.



HDMI



Specifications

Picture/Display

- Aspect ratio: 16:9, Widescreen
- Brightness: 500 cd/m²
- Dynamic screen contrast: 2800:1
- Diagonal screen size: 26 inch / 66 cm
- Picture enhancement: Pixel Plus 3 HD, Progressive scan, 3/2 - 2/2 motion pull down, Active Control, 3D Combfilter, Dynamic contrast enhancement
- Screen enhancement: Anti-Reflection coated screen
- Display screen type: LCD WXGA Active Matrix TFT
- Panel resolution: 1366 x 768p
- Response time (typical): 8 ms
- Viewing angle (H / V): 176 / 176 degree

Supported Display Resolution

Video formats

Resolution	Refresh rate
480i	60Hz
480p	60Hz
720p	60Hz
1080i	60Hz

Sound

- Sound System: Dolby Digital (AC-3), Virtual Dolby Surround
- Output power (RMS): 2 x 10W
- Equalizer: 5-bands

Loudspeakers

- Built-in speakers: 2

Convenience

- Ease of Installation: Autostore, PLL Digital Tuning, Plug & Play
- Ease of Use: On Screen Display, Side Control
- Remote control type: RC2033601
- Screen Format Adjustments: 7 Widescreen Modes, Auto Format
- Child Protection: Child Lock+Parental Control

Multimedia Applications

- Digital Content Management: Digital Media Reader

- Multimedia connections: USB memory class device
- Playback Formats: JPEG Still pictures, MP3, Slideshow files (.alb)

Tuner/Reception/Transmission

- Tuner bands: Hyperband, S-Channel, UHF, VHF
- TV system: ATSC, NTSC
- Video Playback: NTSC
- Aerial Input: 75 ohm F-type
- Cable: Unscrambled Digital Cable QAM

Connectivity

- AV 1: Audio L/R in, CVBS in, YPbPr
- AV 2: Audio L/R in, YPbPr
- AV 3: HDMI
- Front / Side connections: Audio L/R in, CVBS in, Headphone Out, S-video in, USB
- Audio Output - Digital: Coaxial (cinch)
- Other connections: HDMI

Power

- Power consumption: 130 W
- Standby power consumption: < 1 W
- Mains power: 100-250V, 50-60Hz
- Ambient temperature: 5 °C to 40 °C

Dimensions

- Product weight (lb): 30 (with stand), 24.3 (without stand)
- Weight incl. Packaging (lb): 38.3
- Box dimensions in inch (W x H x D): 33.1 x 22.5 x 8.03 inch
- Set dimensions in inch (W x H x D): 26.8 x 18.6 x 4.5 inch
- Set dimensions with stand in inch (W x H x D): 26.8 x 21.1 x 7.9 inch
- VESA wall mount compatible: 200 x 100 mm

Accessories

- Included accessories: Quick start guide, User Manual, Remote Control, Power cord, Tabletop swivel stand, Warranty Leaflet



Issue date 2013-06-22

Version: 3.0.14

12 NC: 8670 000 30273
UPC: 6 09585 13374 7

© 2013 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Five Star Advanced Exchange warranty is valid in the United States only. Local warranties govern sales in other countries.