

Philips
mirror TV with Miravision
and Digital Crystal Clear

30"

LCD

30HM9202



Mirror TV Multi-media Display

with latest high definition LCD display

An elegantly designed TV that you can hang on the wall is now a reality. When off, it's a mirror; when on it delivers best-in-class picture quality for your home or hotel entertainment set-up.

Slim, stylish design to complement your interior

- Unique Miravision technology
- Compact and slim design that fits in every room

Breathtaking natural pictures

- High definition LCD WXGA display, resolution 1280 x 768p
- Digital Crystal Clear provides vivid cinema-like images
- Digital Natural Motion for smooth moving images

Superb sound reproduction

- Virtual Dolby Surround for a cinema-like audio experience
- Unique new slim speakers deliver better stereo performance.

PHILIPS
sense and simplicity

Specifications

Picture/Display

- **Aspect ratio:** 15:9
- **Brightness:** 450 cd/m²
- **Contrast ratio (typical):** 350:1
- **Diagonal screen size:** 30 inch / 76 cm
- **Display screen type:** LCD WXGA Active Matrix TFT
- **Picture enhancement:** Digital Crystal Clear, Progressive scan, Comb filter digital, Active Control + Light sensor, 3/2 - 2/2 motion pull down, Widescreen Plus
- **Screen enhancement:** Anti ageing circuit, Anti reflection coated screen
- **Viewing Angle (Horizontal):** 176 degree
- **Panel resolution:** 1280 x 768p
- **Response time (typical):** 12 ms

Supported Display Resolution

- **Computer formats**

Resolution	Refresh rate
640 x 480	60, 67, 72, 75Hz
800 x 600	56, 60, 72, 75Hz
1024 x 768	60, 70, 75Hz
- **Video formats**

Resolution	Refresh rate
640 x 480p	2Fh

Sound

- **Sound enhancement:** Smart sound
- **Sound System:** Virtual dolby surround
- **Output power (RMS):** 2 x 15W

Loudspeakers

- **Built-in speakers:** 2

Convenience

- **Ease of Installation:** Auto volume leveller, Auto store, PLL Digital Tuning, Plug & Play
- **Ease of Use:** On Screen Display, Smart Picture Control
- **Remote control type:** SIN type number tbc
- **Teletext:** 10 page Smart Text
- **Picture in Picture:** Twin page text
- **Remote Control:** Multi-functional
- **Screen Format Adjustments:** 6 Widescreen Modes, Auto Format, Subtitle and Heading Shift

Tuner/Reception/Transmission

- **Tuner bands:** Hyperband, S-Channel, UHF, VHF
- **TV system:** PAL, SECAM
- **Video Playback:** NTSC, PAL, SECAM
- **Aerial Input:** 75 ohm coaxial (IEC75)

Connectivity

- **Ext 1 Scart:** CVBS in/out, RGB
- **Ext 2 Scart:** CVBS in/out, Y/C
- **Other connections:** Analogue audio Left/Right out, Antenna IEC75, PC in VGA & audio L/R in

Power

- **Power consumption:** 185 W
- **Standby power consumption:** < 3 W
- **Mains power:** AC 220 - 240 V +/- 10%
- **Ambient temperature:** +5 -/+ 40 C

Dimensions

- **Product weight:** 25 kg
- **Weight incl. Packaging:** 30 kg

Accessories

- **Included Accessories:** Wall mounting bracket

Product highlights

Miravison

By utilising a proprietary polarising cover a decorative mirror that turns into a full featured flat TV when switched on. Unique and Stylish.

Compact and slim design

This design style emphasises a slim, compact look that saves space and fits in anywhere.

LCD WXGA display, 1280 x 768p

This WXGA display with state-of-the-art LCD screen technology gives you HD resolution of 1280 x 768p pixels. It produces brilliant flicker-free progressive scan pictures with optimum brightness and superb colours. This vibrant and sharp image will provide you with an enhanced viewing experience.

Digital Crystal Clear

Digital Crystal Clear is a package of picture innovations that digitally adjusts and optimises picture quality to optimal contrast, colour and sharpness levels. It's like watching vivid cinema-like images.

Digital Natural Motion

Philips invented Digital Natural Motion to eliminate juddering effects that are visible with moving picture content. Digital Natural Motion estimates motion in the picture and corrects juddering movements in both broadcast and recorded movie material (DVD). The resulting smooth motion reproduction and excellent sharpness take the viewing experience to a higher level.

Virtual dolby surround

Virtual Dolby Surround is a processing technology for enhancing surround sound effects. It will create the sensation of Dolby Pro Logic without the necessity of additional rear speakers. You become totally immersed in your television experience.

Unique new slim speakers

Enjoy improved balanced sound and stereo performance like you've never heard before. The slim speakers use patented technology featuring a hi-fi like magnet system and unique speaker cones.



Issue date 2007-11-09

Version: 1.0

12 NC: 8670 000 22044
EAN: 87 10895 86930 0

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com