



Philips
Professional LCD TV

- 66 cm (26")
- LCD
- Pro:Idiom™

26HF5545D

The versatile & affordable PPV TV

HD LCD with SmartPlug & Pro:Idiom™

Exceptional performance for guests coupled with bottom line savings for you. SmartPower saves significantly on energy costs, & Five Star advanced exchange warranty keeps rooms saleable. Seamless integration to PPV providers with SmartPlug.

System ready and future proof

- HD content protection with Pro:Idiom™ Plus
- Compatible with all major PPV systems
- New embedded prepaid solutions
- SmartPlug Xpress & Serial Xpress Control interfaces

Best total cost of ownership

- Five Star Service - two-year advanced exchange warranty
- SmartPower for energy saving
- Wireless SmartLoader for fast cloning

Great viewing experience and guest comfort

- HDTV for Hospitality
- Welcome message on screen display

Sustainable and safe

- Eco-friendly Design
- Flame retardant housing

PHILIPS

Highlights

Pro:Idiom™ Plus

Pro:Idiom™ was created for the hospitality industry to protect first run movies and other HD premium content from piracy. Philips Pro:Idiom™ Plus televisions offer secure HD content protection not only for PPV hotels, but now also for stand alone properties. (Additional fees may apply for stand alone use) (Pro:Idiom™ is a trademark of the Zenith Corp.)

PPV system compatible

Philips Hospitality sets are designed to be compatible with all major Pay Per View systems, including, but not limited to, LodgeNet, OnCommand, NxTV, GuesTek, nStreams, Hospitality Network, and KoolConnect. This guarantees seamless integration in almost any system configuration.

New embedded prepaid solutions

Philips Hospitality sets now support SmoovieTV™, a completely new way to offer in room programming optimized for hotels that traditionally have not been able to charge for such amenities due to their size or budget. Simple to use, SmoovieTV™ requires no

expensive head end equipment or in-room control boxes.

Five Star Service

Philips offers unmatched commitment to keeping your guest rooms in working order. Our products are so reliable that we offer a two-year advanced exchange warranty. In the event that something does go wrong, we guarantee to ship a replacement set to you, within 72 hours during the first year.

SmartPower

The backlight intensity can be controlled and pre-set by the system to reduce the power consumption by up to 50%, which saves substantially on energy costs.

Wireless SmartLoader

Provides the ability to copy easy and wireless all programming settings from one TV set into other TV sets in less than a minute. The feature ensures uniformity between TV sets and significantly reduces installation time and costs.

HDTV for Hospitality

There are many ways you may choose to offer HDTV to your guests, but regardless of the source, Philips Hospitality televisions will always deliver the best viewing experience possible to your guests by utilizing the most advanced FlatTV displays and award winning technologies such as Pixel Plus 3 HD.

Welcome message

A welcome greeting is displayed each time the TV set is switched on.

Eco-friendly Design

Philips TVs are designed and produced according to our EcoDesign principles aimed at minimizing overall environmental impact, through lower power consumption, removal of hazardous substances, lower weight, more efficient packaging and better recyclability.

Flame retardant housing

Philips TVs have a special housing of flame retardant material. Independent tests carried out by emergency fire services have shown that whereas TVs can sometimes intensify fires caused by external sources, Philips TVs will not contribute to the fire.



HDMI



Specifications

Picture/Display

- Aspect ratio: 16:9, Widescreen
- Color cabinet: Bicolor - Silver and high gloss Black
- Brightness: 500 cd/m²
- Contrast ratio (typical): 700:1
- Dynamic screen contrast: 3500:1
- Diagonal screen size: 26 inch / 66 cm
- Picture enhancement: Progressive scan, 3/2 - 2/2 motion pull down, Active Control, 3D Combfilter, Dynamic contrast enhancement, Contrast Plus, Digital Noise Reduction, Jagged Line Suppression
- Screen enhancement: Anti-Reflection coated screen
- Display screen type: LCD WXGA Active Matrix TFT
- Panel resolution: 1366 x 768p
- Response time (typical): 8 ms
- Viewing angle (H / V): 160 / 160 degree

Supported Display Resolution

Computer formats

Resolution	Refresh rate
1024 x 768	60, 70, 75, 85Hz
800 x 600	60, 72, 75, 85Hz
640 x 480	60, 72, 75, 85Hz

Video formats

Resolution	Refresh rate
480i	60Hz
480p	60Hz
720p	60Hz
1080i	60Hz

Sound

- Sound System: Stereo, Dolby Digital (AC-3)
- Output power (RMS): 2 x 10W
- Sound Enhancement: Auto Volume Leveller, Incredible Surround

Loudspeakers

- Built-in speakers: 2

Convenience

- Ease of Installation: Fine Tuning, PLL Digital Tuning, Wireless Smart Loading, Program Name, Advanced Hotel Mode
- Ease of Use: Auto Volume Leveller (AVL), Smart Picture, Smart Sound
- Screen Format Adjustments: 4:3, 7 Widescreen

Modes

- Comfort: Hotel Guest features, Sleep timer
- Other convenience: Kensington lock

Tuner/Reception/Transmission

- Tuner bands: Hyperband, S-Channel, UHF, VHF
- TV system: NTSC, ATSC
- Video Playback: NTSC, PAL
- Number of Preset Channels: 125
- Cable: Unscrambled Digital Cable QAM
- Terrestrial: ATSC (8VSB)
- Aerial Input: 75 ohm F-type

Connectivity

- AV 1: Audio L/R in, CVBS in, S-Video Y/C
- AV 2: Audio L/R in, YPbPr
- AV 3: HDMI
- Connectivity Enhancements: SmartCard Xpress box ready, RJ12 connector, RJ45 connector, HM-Link, Extra Power supply 12V/1W, External Loudspeaker connector
- Audio Output - Digital: Coaxial (cinch)
- Other connections: Antenna F-type, PC-In VGA

Power

- Power consumption: 125 W
- Mains power: 110 - 240V, 50/60Hz
- Ambient temperature: 5 °C to 40 °C

Dimensions

- Set dimensions in inch (W x H x D): 26.8 x 18.6 x 4.4 inch
- Set dimensions with stand in inch (W x H x D): 26.8 x 21.1 x 7.9 inch
- Box dimensions in inch (W x H x D): 33.1 x 22.5 x 8.03 inch
- Product weight (lb): 30 (with stand), 24.3 (without stand)
- Weight incl. Packaging (lb): 38.3
- VESA wall mount compatible: 200 x 100 mm

Accessories

- Included accessories: Power cord, Tabletop swivel stand, Warranty Leaflet
- Optional accessories: Set up Remote RC2573GR, Mounting brackets/ stands, Wireless SmartLoader 22AV1135



Issue date 2013-06-22

Version: 2.3.8

12 NC: 8670 000 30268
UPC: 6 09585 13370 9

© 2013 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Five Star Advanced Exchange warranty is valid in the United States only. Local warranties govern sales in other countries.