



Professional TV

- 43" Studio
- DVB-T2/C/S2

43HFL2889S/12

Keep it simple

Standalone Pro TV.

From hotel room to boardroom, give them Philips renowned picture quality with this budget-friendly standalone professional TV. Benefit from simple, lightning-fast installation and an on-screen welcome page that's easy to program.

Benefits

Brilliant picture. Easy management.

- Secure menu and control locking
- 16/7. Beautifully clear, high-contrast image
- 3 years warranty, extendable to 5 years
- Multilingual customer support

Simple set up. Flexible connections.

- Mixed channel map to combine analogue, DVB-T/C/S channels
- Instant initial USB cloning. Rapidly configure Pro TVs
- HDMI & VGA for PC connection.

- Offline channel editor. Easily manage channels on a PC
- S2 satellite tuner on board

Cost-effective standalone solution

- USB auto playback. Music, movies, and more
- Low power consumption
- HDMI-CEC to control external devices

PHILIPS

Features

DVB-T/C/S channels

One integrated channel list for digital (T/C/S) and analogue channels. This allows the guest to flick seamlessly between Analogue and Digital (T/C/S) channels.

Instant initial USB cloning.

Provides the ability to easily copy all programming and channel programming settings from one TV into other TV sets in less than a minute. The feature ensures uniformity between TV sets and significantly reduces installation time and costs.

Control locking

By disabling or enabling the local control locking, the administrator can prevent unauthorised use of the TV via the control buttons, saving the hotelier overheads.

USB auto playback.

Share the fun. Connect your USB memory-stick, digital camera, mp3 player or other multimedia device to the USB port on your TV to enjoy photos, videos and music with the easy to use onscreen content browser.

Low power consumption

Philips TVs are designed to minimise power consumption. This will not only reduce environmental impact but also lower operating costs.

Specifications

[field not found 'disclaimer_text']

Picture/Display

Display	LED Full HD
Diagonal screen size (metric)	108 cm
Diagonal screen size (inch)	43 inch
Aspect ratio	16:9
Panel resolution	1920x1080p
Brightness	300 cd/m ²
Viewing angle	178° (H) / 178° (V)

Audio

Sound output Power	16 (2x8) W
Speakers	2.0
Sound Features	Down Firing Equalizer Balance AVL Incredible surround Dynamic Bass

Design

Colour	Black
--------	-------

Tuner/Reception/Transmission

Digital TV	DVB-T2/C/S2
Analog TV	HEVC FHD (up to 1080p60) PAL SECAM

Connectivity Rear

Antenna	IEC-75
HDMI1	F-Type HDMI 1.4 ARC
HDMI2	HDMI 1.4
Digital Audio out	Optical
Scart	CVBS RGB SVHS
VGA input	15 pin D-sub

Connectivity Side

Common Interface Slot	CI+ 1.3
AV input	CVBS+L/R (Cinch)
Headphone out	Mini-Jack
USB1	USB 2.0

Connectivity Enhancements

EasyLink (HDMI CEC)	One touch play System Standby RC pass through
---------------------	---

Features

Digital services	Subtitles Teletext MHEG Now&Next 8d EPG
Ease of use	Picture Style Sound Style
Local control	Joystick

Hospitality Features

Hotel mode	Joystick Control Lock Menu lock Installation Menu Lock Volume limitation (incl. HP) high security mode TXT/MHEG/USB/EPG/Subtitle Lock
Prison mode	Welcome Logo via USB
Your brand Cloning and Firmware update	Instant Initial Cloning
Switch On control	Channel/Source Picture Style Volume (incl. HP)
Timer	Sleep Timer Wake Up Alarm
Channels	Combined List Off-Line Channel Editor
Control	Block Automatic Channel Update
Power control	Green/fast startup
Remote Control	Cable Strap Ready RC Battery Door Lock
Anti-Theft	Kensington Lock

Healthcare features

Control	Multi-Remote Control
Convenience	Headphone out

Multimedia

Multimedia connections	USB
Video playback supported	Containers: AVI, MKV Formats: H.264/MPEG4 AVC MPEG1 MPEG2 MPEG4

Subtitle formats supported	HEVC	Energy Label Class	A++
	TS	Eu Energy Label	37 W
Music formats supported	SRT	power	
	SSA SUB	Annual energy consumption	54 kW h
Picture formats supported	ASS	Standby power consumption	<0.3 W
	SMI	Power Saving Features	Eco mode
Supp. Video Resolution on USB	TXT	Ambient temperature	5 °C to 45 °C
	MP3		
Accessories	AAC		
	WAV		
Included	WMA (v2 up to v9.2)		
	BMP		
Optional	JPG		
	PNG		
Power	up to 1920x1080p@30Hz		
Mains power			
AC 220-240V; 50-60Hz			

Dimensions

Set Depth	43/73 mm
Set depth (with stand)	235 mm
Set Height	571 mm
Set height (with stand)	625 mm
Set Width	971 mm
Set width (with stand)	971 mm
Product weight	8.3 kg
Product weight (+stand)	9.2 kg
VESA wall mount compatible	M6
	200 x 200 mm

* Availability of features will depend on implementation chosen by integrator.

* Typical on-mode power consumption measured according to IEC62087 Ed 2. The actual energy consumption will depend on how the television is used.

* This television contains lead only in certain parts or components where no technology alternatives exist in accordance with existing exemption clauses under the RoHS Directive.



data subject to change
2019, September 30

Version: 1.1.1
EAN: 8718863020425

© 2019 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com