



#### Professional TV

- 39" Studio
- DVB-T2/T/C HEVC

39HFL2869T/12

## Delight your guests

with pure taste

Show your guests how much you care with this affordable Hospitality TV. You will enjoy dedicated hospitality features like a branded welcome page, installation via USB and menu and control locking.

### Benefits

#### Great viewing experience and guest comfort

- LED TV for images with incredible contrast
- USB for multimedia playback
- Low power consumption

#### Advanced hotel features and future proof

- Greet your guests with a customizable welcome page
- USB cloning of all settings for quick installation

- Ideally suited for prisons
- Off-line channel editor to edit a channel list on a PC
- One combined channel list for Analog and Digital channels
- Advanced volume control to avoid guest disturbance
- Prevent unauthorized use by joystick control locking
- Installation menu locking

# PHILIPS

## Features

### Welcome page



A welcome page is displayed each time the TV set is switched on. The welcome page can be branded and customized easily at the time of installation via a simple welcome image in .png format.

### USB Cloning



Provides the ability to easily copy all programming and channel programming settings from one TV into other TV sets in less than a minute. The feature ensures uniformity between TV sets and significantly reduces installation time and costs.

### PrisonMode

To control communication, this Hospitality TV is equipped with a specific PrisonMode setting. This Advanced Security Mode switches off certain settings not demanded by the detention market like Teletext, Electronic Programme Guide, Subtitles and USB ports.

### USB (photos, music, video)



Share the fun. Connect your USB memory-stick, digital camera, mp3 player or other multimedia device to the USB port on your TV to enjoy photos, videos and music with the easy to use onscreen content browser.

## Specifications

[field not found 'disclaimer\_text']

### Picture/Display

Display	LED HD TV
Diagonal screen size (metric)	98 cm
Diagonal screen size (inch)	39 inch
Aspect ratio	16:9
Panel resolution	1366 x 768p
Brightness	300 cd/m <sup>2</sup>
Viewing angle	178° (H) / 178° (V)

### Audio

Sound output Power	12 (2x6) W
Speakers	2.0
Sound Features	Down Firing Equalizer Balance AVL Incredible surround

Dynamic Bass

### Design

Colour	Black
--------	-------

### Tuner/Reception/Transmission

Digital TV	DVB-T/T2/C HEVC FHD (up to 1080p60)
Analog TV	PAL SECAM

### Connectivity Rear

Antenna	IEC-75
HDMI1	HDMI 1.4 ARC
HDMI2	HDMI 1.4
Digital Audio out	Optical
Scart	CVBS

### One combined channel list

One integrated channel list for digital and analogue channels. This allows the guest to zapp seamless between Analogue and Digital channels.

### Advanced volume control

With advanced volume control you can install the start-up volume of the TV and predifine the volume range with which the TV set is allowed to operate, preventing excessive volume adjustments and avoiding disturbance of next door guests.

### Joystick control locking

By disabling or enabling the joystick control locking, the administrator can prevent unauthorized use of the TV via the joystick, saving the hotelier overheads.

### Installation menu locking

Prevents unauthorized access to installation and configuration settings, to ensure maximum guest convenience and avoid unnecessary reinstalling costs.

### Low power consumption

Philips TVs are designed to minimize power consumption. This will not only reduce environmental impact but also lower operating costs.

VGA input	RGB SVHS 15 pin D-sub		MPEG1 MPEG2 MPEG4 HEVC TS SRT SSA SUB ASS SMI TXT MP3 AAC WAV WMA (v2 up to v9.2) BMP JPG PNG up to 1920x1080p@30Hz
<b>Connectivity Side</b>			
Common Interface Slot	CI+ 1.3	Subtitle formats supported	
AV input	CVBS+L/R (Cinch)	Music formats supported	
Headphone out	Mini-Jack	Picture formats supported	
USB1	USB 2.0	Supp. Video Resolution on USB	
<b>Connectivity Enhancements</b>			
EasyLink (HDMI CEC)	One touch play System Standby RC pass through		
<b>Features</b>			
Digital services	Subtitles Teletext MHEG Now&Next 8d EPG		
Ease of use	Picture Style Sound Style		
Local control	Joystick		
<b>Hospitality Features</b>			
Hotel mode	Joystick Control Lock Menu lock Installation Menu Lock Volume limitation (incl. HP)		
Prison mode	high security mode TXT/MHEG/USB/EPG/Subtitle Lock		
Your brand Cloning and Firmware update	Welcome Logo via USB Instant Initial Cloning Channel/Source Picture Style Volume (incl. HP)		
Switch On control	Sleep Timer Wake Up Alarm		
Timer	Combined List Off-Line Channel Editor Block Automatic Channel Update Green/fast startup		
Channels	Cable Strap Ready RC Battery Door Lock Kensington Lock		
Control			
Power control			
Remote Control			
Anti-Theft			
<b>Healthcare features</b>			
Control Convenience	Multi-Remote Control Headphone out		
<b>Multimedia</b>			
Multimedia connections	USB		
Video playback supported	Containers: AVI, MKV Formats: H.264/MPEG4 AVC		
<b>Accessories</b>			
Included			Remote Control 22AV1407A/12 2xAAA Batteries Tabletop Stand Warranty Leaflet Legal and Safety brochure Setup RC 22AV9573A Remote Control 22AV1601A/12 [Easy remote control]
Optional			
<b>Power</b>			
Mains power			AC 220-240V; 50-60Hz
Energy Label Class			A++
Eu Energy Label power			31 W
Annual energy consumption			45 kW h
Standby power consumption			<0.3 W
Power Saving Features			Eco mode
Ambient temperature			5 °C to 45 °C
<b>Dimensions</b>			
Set Width			889 mm
Set Height			523 mm
Set Depth			79/97 mm
Set width (with stand)			889 mm
Set height (with stand)			563 mm
Set depth (with stand)			220 mm
Product weight			6.6 kg
Product weight (+stand)			7.5 kg
VESA wall mount compatible			200 x 200 mm M6

\* Availability of features will depend on implementation chosen by integrator.

\* Typical on-mode power consumption measured according to IEC62087 Ed 2. The actual energy consumption will depend on how the television is used.

\* This television contains lead only in certain parts or components where no technology alternatives exist in accordance with existing exemption clauses under the RoHS Directive.



data subject to change  
2019, July 9

Version: 1.0.1  
EAN: 8718863013816

© 2019 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)