

Philips 4000 series
LED TV

107cm (42")
Full HD 1080p

42PFL4150



Bring alive the entertainment

with superb picture, sound & connectivity

a perfect combination of clear picture & sound that makes this TV a best choice for your home entertainment

"See brilliant picture quality"

- "IPS Panel for superior performance & widest viewing angle"

See brilliant picture quality

- 240Hz Perfect Motion Rate (PMR) for superb motion sharpness
- Full HD LCD display for better depth and clarity

Hear crisp and clear sound

- Incredible Surround for enhanced audio enjoyment
- Rich and clear sound experience

Easy to connect and enjoy

- Seamless connectivity with 2 HDMI inputs
- Fantastic video, photo and music playback via USB

PHILIPS

LED TV
107cm (42") Full HD 1080p

42PFL4150/V7

Highlights

"IPS Panel"



"IPS displays use an advanced technology which gives you extra wide viewing angles of 178/178 degree, making it possible to view the display from almost any angle. Unlike standard panels, IPS displays gives you remarkably crisp images with vivid colors, making it ideal not only for Photos and movies, but also for professional applications which demand color accuracy and consistent brightness at all times."

Full HD LCD display, 1920 x 10



"The Full HD screen has the widescreen resolution of 1920 x 1080p. This is the highest resolution of HD sources for the best possible picture quality. It is fully future proof as it supports 1080p signals from all sources, including the most recent like Blu-ray and advanced HD game consoles. The signal processing is extensively upgraded to support this much higher signal quality and resolution. It produces brilliant flicker-free progressive

scan pictures with superb brightness and colors.. "

240Hz PMR



240Hz Perfect Motion Rate (PMR) creates extreme motion sharpness for clear and vibrant images in fast action movies. The new Philips PMR standard shows the combined visible effect of the fastest panel refresh rate, HD Natural Motion and unique processing formula, for unprecedented motion sharpness.

Incredible Surround



"Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound

dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.."

Rich & clear sound experience



"Feel the power of the music beat and the atmosphere of the movies. The powerful 16 W RMS (2 x 8W RMS) amplifiers create a lifelike soundstage. It gives a clear and spacious sound stage complementary to the rich viewing experience.."

2 HDMI inputs

HDMI™ x2

"HDMI makes an uncompressed digital RGB connection from the source to the screen for the ultimate picture quality. HDMI uses HDCP copy protection. With 2 HDMI inputs on the back of the TV you can connect multiple HD sources, for instance an HD settop box, a Blu-ray player, and Game Console or Digital Camcorder."



Specifications

Picture/Display

- Diagonal screen size (inch): 42 inch
- Panel resolution: 1920x1080p
- Picture enhancement: Digital Noise Reduction, Pixel precise HD

Supported Display Resolution

- Computer formats: 1024 x 768, 60, 70, 75Hz, 640 x 480, 60, 72, 75Hz, 720 x 400, 70Hz, 800 x 600, 56, 60Hz, Via HDMI/DVI input, 1280 x 1024, 60Hz, 1280 x 720, 60Hz, 1920 x 1080, 60Hz, 720 x 480, 60Hz, 800 x 600, 56, 60, 72, 75Hz
- Video formats: 1080i, 50, 60Hz, 480i, 60Hz, 480p, 60Hz, 576i, 50Hz, 576p, 50Hz, 720p, 50, 60Hz, 1080p, 50Hz, 1080p, 60Hz

Tuner/Reception/Transmission

- Tuner bands: UHF, VHF
- TV system: PAL B/G
- Video Playback: NTSC, PAL

Multimedia Applications

- Playback Formats: AVI, JPEG Still pictures, MPEG1, MPEG2, MPEG4, WMA v2 up to v9.2, H.264/ MPEG-4 AVC, PNG still pictures
- Music Playback Formats: MP3, WMA (v2 up to v9.2)
- Picture Playback Formats: JPEG

Convenience

- Ease of Installation: Autostore, Fine Tuning
- Ease of Use: Graphical User Interface, On Screen Display
- On-Screen Display languages: English

USB - File Extension

- Video: *.avi, *.mkv, *.mov, *.mp4, *.mpg, *.mpeg, *.wmv

USB - Container

- Video: ASF, AVI, MKV, MP4, PS

USB - Video Decoder

- Compression Format: H.264, MPEG 1, MPEG 2,

MPEG 4, VC-1

Sound

- Output power (RMS): 16W
- Sound System: Stereo
- Sound Enhancement: Auto Volume Leveler, Incredible Surround

Loudspeakers

- Built-in speakers: 2

Connectivity

- AV 1: Audio L/R in, YPbPr, CVBS in, VGA-in (5x cinch RGB+H/V)
- USB: USB
- HDMI 1: HDMI
- HDMI 2: HDMI
- Other connections: Antenna F-type, Component Video (YPbPr) input, Composite video (CVBS) input, PC-In VGA
- AV output: Composite (CVBS) x1

Power

- Power supply: 100-240VAC, 50/60Hz
- Power consumption: 98 W
- Standby power consumption: Less than 1 watt

Accessories

- Included accessories: 2 x AAA Batteries, Remote Control, User Manual, Warranty certificate, Power cord, Safety/legal instructions, Table top stand, Wall mounting bracket
- User Manual: English

Dimensions

- Set Width: 967 mm
- Set Height: 565 mm
- Set Depth: 78 mm
- Product weight: 13 kg
- Set width (with stand): 967 mm
- Set height (with stand): 616 mm
- Set depth (with stand): 257 mm
- Product weight (+stand): 14 kg

