



Philips  
Professional Soundbar

**2.1 Soundbar**  
with built-in subwoofer



HAL5023

## Immersive TV Sound Experience

With built-in subwoofer

This sound enhancing subwoofer will extend the experience for guests using Philips MediaSuite TVs. Easy to install, set up and control, with a built-in subwoofer designed to add extra punch to special effects, music and more.

### **A superior TV sound to match the content of choice**

- More powerful TV sound
- Play your personal sound content via Bluetooth Audio

### **Professional and managed**

- Easy set up and cloning via TV professional menu
- Smart power cable for quick installation
- Customizable sound configuration
- Controlled clearing of Bluetooth connections
- Control the soundbar with the TV remote control
- Freedom of placement - whether wall mounted or on a surface
- Anti-theft provision
- Professional warranty

**PHILIPS**

# Specifications

## Sound

- Speaker configuration: 2.1 (2x 2" + 1x 3")
- Speaker output power: 200W max / 100 W RMS (10% THD)
- Equalizer settings: Movie, Music, Voice, Stadium

## Connectivity

- HDMI features: Audio Return Channel, Easylink (HDMI-CEC), HDMI 1.4
- Number of HDMI connections: 1
- Bluetooth version: 4.2
- Bluetooth: SBC, A2DP

## Convenience

- Anti-theft provision: cable
- Wall mountable

## Accessories

- Included: Wall mount bracket (2pcs), Y-shaped power cord adapter, HDMI Cable, Warranty Leaflet

## Power

- Power supply: 100-240VAC, 50/60Hz
- Power consumption: 30 W
- Standby power consumption: < 0.5 W

## Dimensions

- Product dimensions (WxDxH): 70 x 12 x 7 cm
- Product weight: 2.5 kg
- Packaging dimensions (WxDxH): 91.5 x 18 x 13 cm
- Gross weight: 3.8 kg

## Packaging Data

- EAN: 87 18863 03997 7

## Outer Packaging

- GTIN: 1 87 18863 03997 4
- Number of trade items: 4
- Outer carton (W x H x D): 94 x 29 x 38.5 cm
- Gross weight: 16.5 kg
- Nett weight: 12 kg
- Tare weight: 4.5 kg

## Supported by

- B-line 2000-series: BFL2114, BFL2214
- MediaSuite 5000-series: HFL5014, HFL5114, HFL5214
- MediaSuite 6000-series: HFL6014, HFL6114, HFL6214

# Highlights

## Powerful TV sound

Hear more in everything you watch and every track you love. 2.1 channels bring out the best in effects, score and dialogue. The built-in subwoofer lets you feel the bass, whether you're listening to music or watching an action movie.

## Bluetooth audio

Link your mobile device via Bluetooth and play your favourite sound tracks with the enhanced sound performance of the soundbar.

## Easy set up and cloning

Easily configure the soundbar settings through the professional setup menu on the MediaSuite TV. All related settings can be copied and transferred to other TVs through cloning.

## Controlled clearing

Linked to the user data clearance of the TV, it will be ensured that the Bluetooth pairing information from the used mobile devices will also be cleared.

## Smart power cable

With the specially designed power cable adapter, only one power socket is needed to power both the Soundbar and the TV.

## Freedom of placement

Conveniently placed on a surface or mounted with the included wall brackets, the sleek trapezoid design looks great in any setting.

## Anti-theft

Discourage unauthorised removal of the device with the anti-theft cable included.



Issue date 2023-03-16

Version: 2.0.1

12 NC: 8670 001 89365  
EAN: 87 18863 03997 7

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Supporting TV models may require a software update.