



Philips Performer Ultimate  
Vacuum cleaner with bag

**2200 W**

HEPA 13 filter  
4L  
Smart



**FC8924/01**

## High suction power. For a deep clean.

### TriActive LED technology reveals hidden dust

The innovative Philips Performer Ultimate is our most advanced bag vacuum cleaner.

#### Advanced deep cleaning

- Intuitive digital display to get the best performance
- On board accessories for quick and thorough cleaning
- ErgoGrip remote control handle with built-in control buttons
- Soft brush integrated into handle, always ready to use
- 30% recycled plastics

#### Allergy friendly

- s-bag Ultra Long Performance captures even more fine dust
- HEPA 13 filter

#### Optimum performance

- AirflowMax technology for continuous strong suction power
- Auto on-off to deliver suction power only when you need it
- TriActive LED for deep cleaning results
- Made in Europe
- 2200 W input power

# PHILIPS

# Highlights

## AirflowMax technology



The unique AirflowMax technology keeps the suction power strong for long to use the bag to the very end. The technology is built around the optimization of three key elements: 1) Unique ribs profile inside the dust chamber to maximize airflow around the dustbag and enable the use of the entire bag surface. 2) Specially designed dust chamber capacity that allows the dustbag to fully unfold uniformly. 3) High quality, non-clogging fiber dustbag that absorbs dust without blocking the pores, thus avoiding reduction in suction power.

## Auto on-off



The intelligent auto on-off feature will automatically turn your vacuum cleaner on when in use and off when it is not

## On board accessories



The On board accessories includes : - A crevice tool that fits in tighter spots and works well along the edge of baseboards and in hard-to-reach spots, such as vents. - An upholstery tool that has a small, flat head and powerful suction, this attachment works well on fabric surfaces.

## Intuitive digital display



The intuitive digital display shows relevant information, enabling you to get the best performance out of your vacuum cleaner: - 4 cleaning settings - Dust Bag Full Indicator - Auto on-off Indicator

## Soft brush at your fingertips



A dusting brush attachment is built right into the handle so it's always ready to use for furniture, flat surfaces and upholstery.

## s-bag Ultra Long Performance



s-bag® Ultra Long Performance has been developed to provide optimum cleaning performance from your vacuum cleaner. This dust bag provides your cleaner with extreme suction power during the entire lifetime of the bag.

# Specifications

## Nozzles and accessories

- Standard nozzle: TriActive LED nozzle
- Accessories included: Crevice tool, Integrated brush, Small brush
- Extra accessories: ErgoGrip remote control

## Design

- Color: Silver titanium

## Weight and dimensions

- Dimensions of product (LxWxH): 475 x 300 x 280 mm
- Weight of product: 6.2 kg

## Sustainability

- Packaging: > 75% recycled materials
- User manual: 100% recycled paper

## Performance

- Input power (IEC): 1800 W
- Sound power level: 80 dB
- Input power (max): 2200 W
- Suction power (max): 550 W

## Filtration

- Dust bag type: s-bag Ultra Long Performance
- Dust capacity: 4 L
- Exhaust filter: HEPA13 filter

## Usability

- Action radius: 11 m
- Tube coupling: SmartLock
- Carrying handle: Front
- Power control: ErgoGrip remote control
- Tube type: Aluminium 2-P telescopic tube
- Wheel type: Rubber
- Digital Dustbag full indicator



Issue date 2023-08-04

Version: 1.1.2

EAN: 87 10103 75686 6

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)