

Philips PerformerPro
Vacuum cleaner with bag

2200W

HEPA 13 filter
5L
Turbo brush

FC9194/01



Highest suction power, even as the bag fills up*

with 2200W motor and 5L dust capacity

With its powerful 2200W motor and specially designed dust chamber, Philips PerformerPro vacuum cleaner maintains high airflow, giving you the highest suction power. For great cleaning results, even as the bag fills up!*

Convenience

- 360Flex hose swivel for smooth maneuvering
- SmartLock coupling to easily adjust to each cleaning task
- Long reach for convenient cleaning

Excellent cleaning results

- New 3-in-1 TriActive+ nozzle picks up coarse and fine dust
- 2200 Watt motor generating max. 500W suction power
- Revolutionary Airflow Max technology for extreme suction
- 5L dust capacity for longer cleaning
- Turbo Brush nozzle for more thorough cleaning of your carpet

Integrated Anti-Allergy system

- s-bag Ultra Long Performance captures even more fine dust
- HEPA AirSeal with HEPA 13 filter retains 99.99% of dust
- Allergy friendly quality tested by ECARF

PHILIPS

Highlights

2200 Watt motor



2200 W motor generates max. 500W suction power for excellent cleaning results.

Airflow Max technology



Airflow Max technology maximizes the airflow, allowing the dustbag to unfold uniformly, so you get the highest suction power, even as the bag fills-up!

5L dust capacity



The specially designed 5L dust chamber allows you to make optimal use of your dust bag, so you can clean for longer.

TriActive+ nozzle



The TriActive+ nozzle applies 3 cleaning actions in one go: 1) It gently opens the carpet with its specially designed soleplate to remove the dust deep down. 2) It sucks up big bits with its larger opening at the front. 3) It sweeps up the dust and dirt alongside furniture and walls with its two side brushes.

Turbo Brush nozzle



The Turbo Brush nozzle allows deep cleaning of carpets, easily removing hair and fluff. The rotating brush inside the nozzle actively removes small dust particles and hairs, resulting in a better cleaning performance on carpets. The wheels of the nozzle prevent damage in case of use on hard floors.

HEPA AirSeal with HEPA 13



HEPA 13 filter and AirSeal capture even the finest dust before the air is blown out for a dust-free environment and clean, allergen free air. The exhaust air is even cleaner than the air in the room.

ECARF certified



This vacuum cleaner with HEPA 13 filtration is certified as Allergy friendly by the European Centre for Allergy Research Foundation. The HEPA 13 filter purifies the exhaust air up to 99,95% of allergens from; cat & dog hairs, dust mites or pollen to support an allergy friendly home environment.

Specifications

Nozzles and accessories

- Standard nozzle: TriActive+ nozzle
- Accessories included: Crevice tool, 2-in-1 brush/small nozzle
- Additional nozzle: Turbo brush
- Accessory storage: On tubeclip

Design

- Color: Cognac

Weight and dimensions

- Dimensions of product (LxWxH): 500 x 310 x 300 mm
- Weight of product: 5.0 kg

Performance

- Input power (IEC): 1800 W
- Input power (max): 2200 W
- Noise level (Lc IEC): 79 dB
- Suction power (max): 500 W

- Vacuum (max): 36 kPa
- Airflow (max): 51 l/s

Filtration

- Dust bag type: s-bag Ultra Long Performance
- Dust capacity: 5 L
- Exhaust filter: Ultra Clean Air HEPA 13 filter
- Motor filter: Triple layer
- HEPA Air Seal

Usability

- Cord length: 8 m
- Action radius: 11 m
- Tube coupling: SmartLock
- Carrying handle: Top and front
- Power control: Electronic on appliance
- Tube type: Metal 2-piece telescopic tube
- Handgrip: Ergonomic grip with air slider
- Dust full indicator
- Wheel type: Rubber
- Park or storage assist: Vertical and horizontal



Issue date 2023-08-07

Version: 1.1.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Suction power tested in accordance with international standard IEC 60312-1, tested by external test institute SLG Prüf- und Zertifizierungs GmbH (Philips Consumer LifeStyle B.V., August 2012)