



Philips MiniVac  
Handheld vacuum cleaner

**7.2-V battery**  
Bagless Cyclonic  
Crevice and brush tool

**FC6144/01**

## Powerful MiniVac for a better cleaning result

### Bagless cyclonic airflow and aerodynamic nozzle

Enjoy a better cleaning result with the powerful Philips MiniVac 7.2 V vacuum cleaner. The bagless cyclonic airflow and 2-stage filtration system guarantee lasting performance, while the aerodynamic nozzle ensures superior dust pick-up.

#### **Easy to use**

- Looped handle ensures optimum grip
- One-step click-off nozzle for easy emptying

#### **Always at hand**

- Slim charging base (for wall or table)

#### **Optimal filtration**

- 2-stage bagless cyclonic airflow for optimal filtration

#### **High power guaranteed**

- Powerful 7.2 V NiMH batteries

#### **Superior cleaning results**

- Aerodynamic nozzle design for a better dust pick-up

# PHILIPS

## Highlights

### One-step click-off nozzle



The Philips MiniVac vacuum cleaner is easy and quick to empty and hygienic to clean. The Philips MiniVac has a nozzle that easily clicks off in just one step, so you can empty the Mini Vac without touching the dirt.

### Slim charging base (for wall or table)



You can store the Philips Mini Vac on the convenient charging base, mounted on a wall or placed on a table. This means the Mini Vac, with its powerful rechargeable battery, is always ready when you are.

### 2-stage bagless cyclonic



The bagless cyclonic airflow keeps the dirt inside rotating to ensure optimal high suction power and lasting cleaning performance. Its 2-stage filtration system ensures that, once inside, the dirt cannot escape. The first filter blocks most dirt, while the second filter traps the finer dust particles.

### Aerodynamic nozzle design



The aerodynamic nozzle design of the Philips MiniVac is created to ensure optimum dust pick-up of even the finest dust particles. The ergonomic shape of the nozzle helps you to clean even the most hard-to-reach areas.

### Comfortable grip



The Philips Mini Vac has a looped handle that ensures optimum grip. You can grab the Mini Vac in any way you like.

### Powerful 7.2 V NiMH batteries



"The powerful longer-lasting Nickel-Metalhydride (NiMH) batteries of the Philips MiniVac do not cope with memory effect. This effect reduces the capacity of the battery over time, reducing the runtime. This Mini Vac with NiMH batteries ensures longerlasting power versus products with the standard Nickel-Cadmium (NiCd) batteries that do have memory effect."

## Specifications

### Nozzles and accessories

- Other accessories: Charging base

### Design

- Colour: Deep red
- Design features: Translucent dust chamber

### Weight and dimensions

- Dimensions of packaging (L x W x H): 460 x 160 x 160 mm
- Appliances per A-box: 6
- Weight of product: 1.5 kg
- Dimensions of A-box (L x W x H): 508 x 335 x 490 mm

### Performance

- Battery voltage: 7.2 V
- Charging time: 16-18 hour(s)
- Runtime: 9 min
- Vacuum (max): 3.9 kPa
- Input power (max): 87 W
- Suction power (max): 17 W
- Noise level (Lc IEC): 78 dB
- Airflow (max): 840 l/min

### Filtration

- Dust capacity: 0.5 L
- Filter system: 2-stage cyclonic action

### Usability

- Special features: Charging indication, Soft touch handle



Issue date 2023-08-22

Version: 1.1.1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)