

# PHILIPS

Fog and Powersport  
bulbs

UltinonSport  
9003USLED

Up to 6000 K cool white light

Longer-lasting LED bulbs

Plug and Play

AirCool technology

LUM11342ULSX2



## Discover your next adventure with LED light Powerful LED light

Get ready for your next adventure with Philips UltinonSport LED for Fog and Powersports. The perfect upgrade from halogen to LED technology, offering durable long-lasting performance for any terrain. Light the way forward with Philips LED.

### Up to 6000 Kelvin cool white light

- Automotive SMD LED chips, cool white light

### AirCool Technology

- Built-in active cooling fan

### Compact design for plug-and-play use

- Unique design, integrated driver box

### Improved visibility

- Philips homogeneous beam

### LED Accessories

- Optional accessories available for installation

# Highlights

## Up to 6000 K cool white light

Take the next step, and upgrade your car's fog lights or your powersport vehicle's headlights with Philips UltinonSport LED. Featuring powerful Automotive Grade SMD LED chips with a color temperature of up to 6000 Kelvin, these superior bulbs are designed for the ultimate driving experience. Spot obstacles faster to keep you safer in the most difficult terrain. Philips UltinonSport LED bulbs allow you to drive with more confidence and style.

## AirCool Technology

Philips UltinonSport LED bulbs have a durable design with a dual cooling system. The first part of the system is the AirCool technology, which is the built-in active cooling fan. This combines with the aluminum heat sink to divert heat away from the light's critical components. This dual functionality of heat dissipation enables high light output for longer lifetime. They offer up to 2,000 hours' lifetime, which can be as much as four times longer than the halogen bulbs they replace.

## Compact design

While other LED retrofit solutions on the market may feature an external driver box, our Philips UltinonSport LED offers an integrated driver box, making installation quicker and hassle-free. As some car models have optics that can be very small, our compact design fits a wide range of on-road and off-road vehicles.

## Improved visibility

While some other LED bulbs may not be as reliable, because their poor performance or brightness claims might fall short in real-world conditions, the Philips UltinonSport LED provides solid performance and better quality light. Its homogeneous beam lets you see and be seen more clearly. Thanks to the precise optical design and its high luminance that ensures consistent light output in front of the car. For a good forward beam, it's important the LED bulbs are correctly positioned in the headlight/fog light assembly. So, don't skip the alignment - take your time and do it right.

## LED Accessories

Some car models might pose specific challenges for LED-based retrofit bulbs. That's why we've developed Philips accessories like the Philips CANBus adaptor, so that drivers can upgrade to LED technology on a wider selection of car models. Check if you need the optional Philips LED accessories to ensure the best fit with your car.

## Reliable Philips quality

Technologically advanced Philips automotive lighting is renowned in the automotive industry and has been for over 100 years. Philips Automotive Grade Quality products are designed and developed following strict quality-control processes, leading to consistently high production standards.

# Specifications

## Lifetime

**Life time:** Up to 2000 hours

## Light characteristics

**Color temperature:** Up to 6000 K

## Marketing specifications

**Product highlight:** LED lighting that's easy to install

**Expected benefits:** Powerful LED light

## Ordering information

**Order entry:** 11342ULSX2

**Ordering code:** 78003443

## Packaging Data

**EAN1:** 046678003448

**EAN3:** 50046678003443

**Packaging type:** X2

## Packed product information

**Height [in]:** 5.31

**Length [in]:** 4.37

**MOQ (for professionals):** 4 sets/ 8 pcs

**Pack Quantity:** 2

**Width [in]:** 1.97

## Product description

**Application:** Fog light, High beam-off-road, Low beam-off-road

**Designation:** [~9003]

**Homologation ECE:** Fog or off-road use only

**Range:** UltinonSport

**Technology:** LED

**Type:** [~9003]

**Compatible accessories:** Adaptor CANbus (for dashboard error), Light Repair CANBus (for flickering and dimming)

## Electrical characteristics

**Wattage:** 20 W

**Voltage:** 12 V and 24 V, compatible with car and trucks

