

PHILIPS

LED Motorcycle
headlight bulb

Ultinon Pro6000
moto

Road-legal LED

H4-LED

Up to 230% brighter light**

Lumileds automotive LEDs

LUM11342U6000X1



Upgrade to road-legal LED* for superior visibility The perfect blend of performance and durability

Experience unprecedentedly driving with Philips road-approved* LED headlight bulbs. With up to 230% brighter light** and a daylight-like white beam, these LED bulbs illuminate everything clearly without dazzling oncoming drivers.

Road-legal LED

- Road-legal LED upgrade bulbs

Superior brightness

- Reliable illumination and improved visibility
- Perfect beam for a safer driving

White-light experience

- Daylight-like color temperature for comfortable driving

Enhanced fit with compact design

- Compact all-in-one design for easy installation

Long lasting performance

- Built to last up to 3,000 hours

Highlights

Safe, homologated LED light

We are bringing our long expertise to riders with our Philips Ultinon Pro6000 H4-LED bulbs, 100% road-legal* and homologated by the Ministry of Transport for use on public roads and for selected motorbike and motorcycle models. You can now convert the low beam of your halogen headlights to our tested, safe, and road-approved* Philips Ultinon Pro6000 H4-LED lights to enjoy reliable illumination and an unrivaled LED driving experience. Visit our [Philips.com/roadlegalLED](https://philips.com/roadlegalLED) page* for further information.

Up to 230% brighter light**

Drive with greater confidence wherever you go with Philips Ultinon Pro6000 H4-LED. Its accurate and consistent beam pattern will illuminate the road exactly where you need it, giving you better visibility and greater control over your vehicle. With up to 230% brighter light**, the Philips Ultinon Pro6000 H4-LED offers remarkable clarity to spot obstacles and react faster, even in challenging weather conditions.

Experience improved visibility

Beam pattern is just as important as brightness: a uniform, accurate beam pattern lets you see and be seen more clearly. Thanks to the perfect positioning of the LED chips on the Philips Ultinon Pro6000 bulbs, motorbike and motorcycle riders have light exactly where they need it on the road without dazzling oncoming vehicles.

5800 K for crisp white light

With a color temperature of up to 5800 Kelvin, the Philips Ultinon Pro6000 LED bulbs produce a bright white light. The clearer vision this provides makes it easier to spot obstacles and enhances contrasts. The optimal color temperature avoids tiring or straining the eyes, giving you more comfortable and safer night-time driving.

Compact all-in-one design

The brand-new design of the Philips Ultinon Pro6000 H4-LED takes up little space in the headlight. Thanks to its one-piece design and integrated driver, the installation is simple and easy. These Philips Ultinon Pro6000 H4-LED

bulbs are compatible with a range of selected motorcycle models*. For further information, visit [Philips.com/roadlegalLED](https://philips.com/roadlegalLED).

Up to 3-year warranty***

You want bright, stylish headlights but you don't want to keep replacing failed lamps. LED bulbs generate heat that must be managed. Advanced AirBoost technology and a built-in fan for active cooling contribute to long-lasting reliability. This unique system diverts heat away from the bulb's critical components and enables Philips Ultinon Pro6000 H4-LED bulbs to last longer, providing up to 3,000 hours of use. Visit philips.com/auto-warranty to register for an extended warranty***.

Highest quality lighting

Technologically advanced Philips lighting is renowned in the automotive industry and has been for over 100 years. Philips Automotive Grade Quality products are designed and developed following strict quality-control processes, leading to consistently high production standards. Trust the Philips brand.

Specifications

Electrical characteristics

Voltage range: 9 - 36 V
Rated voltage [V]: 12V
Wattage: 18 W

Lifetime

Life time: 3000 hrs

Light characteristics

Color temperature: 5800 K
Lumens: 1000 / 1650 lm

Marketing specifications

Expected benefits: Brighter Lights, Improved visibility, Long lasting performance
Product highlight: Road-legal LED bulb, Automotive Grade LED

Ordering information

Order entry: 11342U6000X1
Ordering code: 2422094

Outerpack information

Gross weight per piece [kg]: 0.555 kg
Height: 23.6 cm
Length: 11.8 cm
Width: 15 cm

Packaging Data

EAN1: 8719018024220
EAN3: 8719018024237
Packaging type: X1

Packed product information

Gross weight per piece [g]: 119 g
Net weight per piece: 91 g
Height: 5.5 cm
Length: 4.5 cm

Width: 13.5 cm

MOQ (for professionals): 4 pcs (4 sets)
Pack Quantity: 1 pc

Product description

Application: Motorcycle Lighting, High beam, Low beam functions
Compatible with: Applicable only for car models listed in the Philips compatibility list*
Base: P43t-38
Designation: LED H4 11342 U6000 X1
Homologation ECE: NO
Range: Ultinon Pro6000
Technical features: Road-legal LED, AirFlux+, SafeBeam Technology
Technology: LED
Type: H4
Designation LED Type: H4-LED
Ingress protection rating (IP): IP55
Operating temperature: -40 to +105 °C

