



Philips Expression
Vacuum cleaner with bag

AnimalCare

FC8608/03

Most cleaning power for your money

This powerful 1800 W vacuum cleaner provides no less than 350 W of suction power! It comes with an extra Turbo Brush nozzle, and has a 5-layer filtration system, Clean Comfort Cassette and extra-long cord.

High cleaning power

- 1800 Watt motor generating max. 350 Watt suction power

Outstanding results on carpets and furniture

- Turbo Brush nozzle removes 25% more hairs and dust

Hygienic disposal of dust bag

- Unique Clean Comfort Cassette to avoid contact with dust

Protecting your floors

- Soft rubber wheels

PHILIPS

Highlights

1800 Watt motor



Vacuum cleaner with 1800 Watt motor generating max. 350 Watt suction power for perfect cleaning results.

Clean Comfort Cassette



When disposing the dust bag of your Philips vacuum cleaner, there will be no contact with the dust thanks to this patented dust bag holder.

Turbo Brush nozzle



The Turbo Brush nozzle allows deep cleaning of carpets and quick hair and fluff removal from carpets. The rotating brush actively removes small dust particles and hairs, resulting in a 25% better cleaning performance on carpets. The wheels of the nozzle prevent damage in case of use on hard-floors.

Soft rubber wheels



This vacuum cleaner has rubber wheels making it glide smoothly over hard floors without the risk of scratches.

Specifications

Performance

- Input power (IEC): 1600 W
- Airflow (max): 40 l/s
- Vacuum (max): 30 kPa
- Input power (max): 1800 W
- Suction power (max): 350 W
- Noise level (Lc IEC): 82 dB

Design

- Color: Oxford blue

Usability

- Action radius: 10 m
- Tube coupling: Conical
- Carrying handle: Front
- Cord length: 7 m
- Tube type: Metal lacquered 2-piece telescopic tube
- Power control: Electronic on appliance
- Dust full indicator
- Wheel type: Rubber
- Clean Comfort cassette

Nozzles and accessories

- Standard nozzle: All-purpose nozzle
- Accessories included: Crevice tool, Small nozzle
- Accessory storage: On tubeclip

Filtration

- Dust bag type: Cotton bag
- Dust capacity: 3 L
- Exhaust filter: Super Clean Air HEPA 12 filter

