

Philips Performer
Vacuum cleaner with bag

2000W

500W suction power
HEPA 13 washable filter

FC9170/67



The highest suction power ever

500 Watt suction power for effortless cleaning

The Special Edition Performer celebrates 40 years of Floor Care experience for Philips. In addition to our new Titanium color, we are celebrating with a handy 5-piece car cleaning kit, added as gift to every Special Edition Performer.

Superior cleaning

- 2200 Watt motor generating max. 500 Watt suction power

Highly efficient anti-allergy system

- HEPA AirSeal plus HEPA 13 filter

Highly efficient anti-allergy system

- ECARF Seal of Quality for trusted results

Long lasting dust pickup

- s-bag in XXL 4 liter capacity for long-lasting performance

Enjoy the comfort of a clean car

- Gift bag with car cleaning kit

PHILIPS

Vacuum cleaner with bag
2000W 500W suction power, HEPA 13 washable filter

FC9170/67

Highlights

Powerful cleaning



Highly efficient 2200 Watt motor generates max. 500 Watt suction power for perfect cleaning results.

HEPA AirSeal, HEPA 13 filter



This Philips vacuum cleaner has been designed in such a way that all the air taken in is passed through the washable HEPA 13 filter (99.95% filtration) before it is exhausted. No escape is possible.

s-bag in XXL 4 liter



This large dust bag capacity allows you to make optimal use of your dust bag, which means you have to change your dust bag less frequently.

TriActive nozzle



The TriActive nozzle cleans your floor in 3 ways in one go: 1) A larger opening at the tip of the nozzle easily sucks up big bits. 2) It has maximum cleaning efficiency due to optimized airflow through the nozzle. 3) The two side brushes sweep up the dust and dirt closely alongside furniture and walls.

Car Cleaning Kit



Every Special Edition Performer comes with a gift bag containing a car cleaning kit. This complete set of tools is of great use while cleaning your car. For different surfaces in your car special nozzles are included in the kit. All nozzles can be easily attached to your Special Edition Performer. Tools include a microfibre cleaning glove, an adjustable brush, an extra long crevice tool, a universal nozzle, and a special upholstery nozzle.

ECARF Seal of Quality Award



This ECARF certified vacuum cleaner guarantees with 99.95% certainty that almost all the air in the room will be filtered along with the normal vacuum action. This removes almost all allergens from carpets, furniture, and other spaces in your house.



Specifications

Nozzles and accessories

- Standard nozzle: TriActive nozzle
- Accessories included: Brush, Crevice tool, Small nozzle
- Accessory storage: On handgrip

Design

- Color: Titanium

Weight and dimensions

- Dimensions of product (LxWxH): 500 x 320 x 280 mm
- Weight of product: 6.3 kg

Performance

- Input power (max): 2200 W
- Input power (IEC): 2000 W
- Noise level (Lc IEC): 78 dB
- Suction power (max): 500 W

- Vacuum (max): 34 kPa
- Airflow (max): 47 l/s

Filtration

- Dust capacity: 4 L
- Dust bag type: s-bag
- Exhaust filter: Ultra Clean Air HEPA 13 washable filter
- HEPA Air Seal

Usability

- Tube coupling: Easy release
- Action radius: 12 m
- Cord length: 7 m
- Carrying handle: Top and front
- Power control: Electronic on appliance
- Tube type: Metal 2-piece telescopic tube
- Wheel type: Rubber
- Dust full indicator
- Clean Comfort cassette



Issue date 2023-08-22

Version: 1.1.1

EAN: 87 10103 59584 7

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com