

Philips Performer
Vacuum cleaner with bag

HomeCare

FC9171/02



The highest suction power ever

500 Watt suction power for effortless cleaning

The highest suction power ever, resulting in effortless cleaning: this is what the FC917x range is all about. Combined with a hygienic filter and easy dust bag removal system the FC917x range takes care of all your dust and dirt.

Superior cleaning

- 2200 Watt motor generating max. 500 Watt suction power

Highly efficient anti-allergy system

- HEPA AirSeal plus HEPA 13 filter

Highly efficient anti-allergy system

- ECARF Seal of Quality for trusted results

Long lasting dust pickup

- s-bag in XXL 4-litre capacity for long-lasting performance

Easy cleaning, even around furniture

- TriActive nozzle with unique 3-in-1 action

PHILIPS

Highlights

Powerful cleaning



Highly efficient 2200 Watt motor generates max. 500 Watt suction power for perfect cleaning results.

HEPA AirSeal, HEPA 13 filter



This Philips vacuum cleaner has been designed in such a way that all the air taken in is passed through the washable HEPA 13 filter (99.95% filtration) before it is exhausted. No escape is possible.

s-bag in XXL 4 litre



This large dust bag capacity allows you to make optimal use of your dust bag, which means you have to change it less frequently.



ECARF Seal of Quality Award



This ECARF certified vacuum cleaner guarantees with 99.95% certainty that almost all the air in the room will be filtered along with the normal vacuum action. This removes almost all allergens from carpets, furniture and other spaces in your house.

TriActive nozzle



The TriActive nozzle cleans your floor in 3 ways in one go: 1) A larger opening at the tip of the nozzle easily sucks up big bits. 2) It has maximum cleaning efficiency due to optimised airflow through the nozzle. 3) The two side brushes sweep up the dust and dirt closely alongside furniture and walls.

Specifications

Performance

- Input power (max): 2200 W
- Input power (IEC): 2000 W
- Input power (IEC): 2000 W
- Noise level (Lc IEC): 78 dB
- Airflow (max): 47 l/s
- Suction power (max): 500 W
- Vacuum (max): 34 kPa
- Vacuum (max): 34 kPa
- Airflow (max): 47 l/s
- Input power (max): 2200 W
- Suction power (max): 500 W

Design

- Colour: Translucent smoked black

Usability

- Tube coupling: Button
- Action radius: 12 m
- Action radius: 12 m
- Cord length: 7 m
- Carrying handle: Top and front
- Tube type: Metal lacquered 2-piece telescopic tube
- Power control: Electronic on appliance
- Cord length: 9 m
- Wheel type: Rubber
- Dust full indicator
- Clean Comfort cassette

Nozzles and accessories

- Accessories included: Crevice tool, Small nozzle
- Standard nozzle: TriActive nozzle
- Accessory storage: On handgrip

Weight and dimensions

- Weight of product: 6.3 kg

Filtration

- Dust bag type: s-bag
- Dust capacity: 4 L
- Dust capacity: 4 L
- Exhaust filter: Ultra Clean Air HEPA 13 washable filter
- HEPA Air Seal



Issue date 2023-04-13

Version: 1.0.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com