

Philips CityLine
Vacuum cleaner with bag

HomeCare

FC8438/02



Minimum size, maximum cleaning

A compact yet powerful 1800 W vacuum cleaner with Reach & Clean nozzle, 5-layer filtration system with Super Clean Air HEPA filter, telescopic tubes and rubber rear wheels. Ideal for smaller households or as a second vacuum cleaner.

Clean air in your home

- HEPA filter for excellent filtration of the exhaust air

High cleaning power

- 1800 Watt motor generating max. 340 Watt suction power

Hygienic dust bag removal

- s-bag is the standard disposable dust bag

Special nozzle for hard-to-reach places

- Reach & Clean nozzle for reach into the narrowest places

Easy to manoeuvre

- Weight/size/carrying handle

PHILIPS

Highlights

1800 Watt motor



1800 Watt motor generating max. 340 Watt suction power

Reach & Clean nozzle



The innovative design of the Reach & Clean nozzle makes it possible to reach into the narrowest spaces simply by repositioning the nozzle head sideways, while offering 40% more suction power at the same time. And by completely reversing the nozzle, you quickly and easily convert it from use on hard floors to use on carpets and rugs.

HEPA filter



This HEPA filter catches harmful microscopic vermin that causes respiratory allergies. To maintain effective filtration, replace the HEPA filter every 6 months.

Weight/size/carrying handle

Weight/size/carrying handle

s-bag



s-bag is the standard disposable dust bag that is widely available and easily recognizable by its logo. It is suitable for bag vacuum cleaners of Philips, Electrolux, AEG, Volta, and Tornado.

Specifications

Performance

- Input power (IEC): 1600 W
- Airflow (max): 38 l/s
- Vacuum (max): 29 kPa
- Input power (max): 1800 W
- Suction power (max): 340 W
- Noise level (Lc IEC): 79 dB

Design

- Color: Pearl white

Usability

- Action radius: 9 m
- Tube coupling: Button
- Carrying handle: Front
- Cord length: 6 m
- Tube type: Metal lacquered 2-piece telescopic tube
- Power control: Electronic on appliance
- Wheel type: Rubber
- Dust full indicator

Nozzles and accessories

- Standard nozzle: Reach & Clean nozzle
- Accessories included: Crevice tool, Small nozzle
- Accessory storage: On tubeclip

Filtration

- Dust bag type: s-bag
- Dust capacity: 2 L
- Exhaust filter: Microfilter, Super Clean Air HEPA 12 filter



Issue date 2023-04-14

Version: 1.1.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com