

Philips  
Back massager

Multi-nodes floating massage  
Thermostatically hot compress  
One-key control

PPM4501



## Full back massage

12 massage nodes provide care of the waist and back

The back massager uses up to 12 floating massage nodes. The massage range covers both the waist and back, so you can instantly get a relaxing experience of the whole back.

Floating massage provides you protection.

### Protective massage

- Multi-node massage relax both the upper and lower back
- Promote blood circulation and muscle relaxation
- Imitate human massage skill, enjoy a comfortable experience
- Innovative floating massage
- Timed massage to avoid overuse

### Easy to use

- One-key control, easy to use
- Personalized massage settings with 4 modes
- Color status indicator: clear and easy to understand

### Comfortably fit

- Comfortable fit to curved surface for complete massage

**PHILIPS**

## Back massager

Multi-nodes floating massage Thermostatically hot compress, One-key control

# Specifications

### General specifications

- Power supply: Adapter (IN100-240V OUT12V)
- Product Dimension (LxWxH): 422x164x470 mm
- Color: Dark blue
- Heating Type: Heating light
- Net weight: approx. 3kg
- Main materials: Mesh cloth, Poly urethane

### Main parameters

- Auto shut-off time: 15 minutes

- Rated Power: 24 W
- Cord length of adapter: 1.8 m

### Country of origin

- Made in: China

### Service

- Warranty period: 2 years

PPM4501BU/97

# Highlights

### Multi-node massage

Up to 12 massage nodes are arranged on both the left and right side. A large area rotation can cover the back to massage all parts precisely.

### Comfort-Fit surface

In-depth study of the human body curve in order to make the massager more compliant with the body and achieve a purer massage experience

### Thermostatically hot compress

42 degrees (3 degrees) hot compress thermostat. While the massage nodes are kneading and massaging, it can also heat the massaged area to accelerate blood circulation, eliminate swelling and pain, and relieve muscle soreness.

### Imitate human massage skill

Use 3D stereo massage nodes, which are different from ordinary 2D flat massage nodes. It can simulate real person's pushing, pulling and kneading massage techniques to deeply soothe muscles and eliminate fatigue.

### 3D floating massage

Design of floating massage nodes provides protection. When the body is close to the massager, it will stretch back and forth to avoid damage caused by squeezing the body tissues.

### Timed massage

15 minutes preset massage function to prevent damage caused by excessive massage or hot compress

### One-key control

Make hard things simple: complete all the functional procedures with one touch.

### Personalized massage settings

Experience in four different modes

### Color status indicator

Buttons and massage heads are equipped with colored status lights. Orange light indicates heated mode while blue light indicates no heat.



Issue date 2023-04-20

Version: 1.1.1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)