

Philips  
Waist massager

Large area hot compress  
Multi-level massage options  
Detachable controller

PPM4325



## Pure enjoyment of warm care

Wireless hot compress for waist and abdomen

Made of Lycra fabric, the waist massager is light and thin. It is equipped with a hot compress function to effectively promote blood circulation and relieve waist pain and discomfort. Magnetic detachable controller, portable without burden.

### Hot compress massage to relieve discomfort

- Large area hot compress, adjustable heating temperature
- Portable massage belt, feel light and thin
- 30-minute intelligent timed massage, avoid excessive massage

### Magnetic suction box, wireless and light to use

- Detachable controller, light and portable for carrying
- Built-in battery, avoid power cord constraints

### Wraparound design for a comfortable fit

- 3D surround ergonomic design for better protection
- Carefully selected fabrics: light, soft & waterproof

**PHILIPS**

## Waist massager

Large area hot compress Multi-level massage options, Detachable controller

# Specifications

### General specifications

- Product Dimension (LxWxH): 1080×110×35 mm
- Net weight: 185 g
- Color: Pink

### Main parameters

- Working voltage: 3.7 V
- Auto shut-off time: 30 minutes
- Temperature of heating: 45-55 °C
- Working power: 6.5 W

- Battery: 3000 mAh
- Charging current: 1 A
- Charging voltage: 5 V
- Charging port: Type-C

### Country of origin

- Made in: China

### Service

- Warranty period: 2 years

PPM4325PK/97

# Highlights

### Hot compress mode

The front and back dual zones are heated at the same time, and the 45-55 degrees can be adjusted in 3 levels to effectively promote blood circulation, relieve back pain and abdominal discomfort.

### Invisible wearing

The net weight of the whole device is 185g, the thin and light body can be worn invisible, so that you are not afraid of pressure and embarrassment.

### Timing shut-off

A timed 30-minute working time for automatically shut off, effectively avoiding excessive massage and causing discomfort of redness and swelling of the skin.

### Detachable magnetic controller

The controller and the main device are fixed by magnetic adsorption, and they can be easily adsorbed when they are close to each other. Detachable design, it is more convenient to travel and carry and easy to clean.

### Use wireless

The control box has a built-in battery with a capacity of 3000mAh, which can be used for 180 minutes when fully charged.

### 3D wraparound design

Wraparound design, you can also use with extension strap, adjust the abdominal and waist massage position through the hook & loop. 360-degree wrap covering waist massage to soothe discomfort.

### Skin- friendly material

Use carefully selected fabrics with antibacterial and water repellent treatment, it prevents odor and damage to skin health caused by the growth of harmful microorganisms. The device is light and thin, make it invisible and non-sensing to wear as well as more convenient to carry.



Issue date 2023-04-24

Version: 1.1.1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)