



Philips  
Mini massage gun

**Hot compress**  
5kg force output  
7 massage heads

PPM7303

## Compact and portable

Enjoy relaxation anytime

Equipped with 7 massage heads including hot compress function, it brings you a personalized experience. 45 degrees thermostatically hot compress, compact and portable, with 5 speed levels, the effect of massage and relaxation is improved.

### **Light and portable, massage anywhere**

- Light and portable, comfortable to hold
- Massagist available anywhere

### **Strong power, metal support**

- High frequency vibration, deep massage
- 7 massage heads, meet your different needs.

### **Hot compress massage**

- Vibrating heat compress to relieve muscle tension
- 45 degrees thermostatically heating

**PHILIPS**

Mini massage gun  
Hot compress 5kg force output, 7 massage heads

# Specifications

## General specifications

- Product Dimension (LxWxH): 75×38×153 mm
- Net weight: 303 g
- Color: Dark grey
- Quantity of massage heads: 7

## Main parameters

- Working voltage: 7.4 V
- Working power: 10 W
- Battery: 1300 mAh

- Maximum thrust: 5 kg
- Charging current: 2 A
- Charging voltage: 5 V
- Charging port: USB Type-C 5V 2A

## Country of origin

- Made in: China

## Service

- Warranty period: 2 years

PPM7303DG/97

# Highlights

## Light and portable

With the weight less than 300g, the massagegun is light and portable to carry. "T" shape design, metallic paint and 36mm wide grip, make the massage gun easy and comfortable to grasp as well as simple to storage.

## Use in multiple scenarios

Enjoy powerful and warm massage in multiple scenarios: Awaken the vitality of muscle groups before training and relieve muscle soreness after training for fitness person. Say goodbye to shoulder pain for office worker. Quickly relieve for sore calves to people on travel or business trip.

## SuperDynamic metal system

SuperDynamic all-metal powertrain, improve the device performance to provide 5kg force output. One key to operate 5 strength levels, deeper and deeper relaxation with step by step massage.

## Professional accessories

Accessories include 7 massage heads. You can have targeted massage on various large muscles of body parts, such as back, arms and thighs.

## Metal hot compress flat head

Once the massage head is connected, the device will automatically recognize and turn on the hot compress mode. The stainless steel surface will heat quickly when the machine is turned on, and the hot compress will be heated at a constant temperature of 45C. With high-frequency impact, the heat penetrates deep into the muscles, and the relaxation effect is more ideal.

## Hot compress massage

Applying heating to high frequency massage gun, differs from the previous series. Special design of hot compress function with vibration improves the massage and relaxation effect.



Issue date 2023-04-29

Version: 1.1.1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)