



Philips HomeRun 7000
Series Aqua
Vacuum and Mop Robot

with Auto-Empty station
Deep Black & Gold
Connected to HomeRun App



XU7100/01

Daily wet & dry deep cleaning without effort

Enjoy a pristine clean every day, with far less effort. The robot delivers ultra-strong suction power and vacuums and mops in one go. It detects small items in the way like shoes or toys, and cleans around them without getting stuck.

Come home to a complete clean every day

- Removes more fine dust than vacuuming alone
- Ultra-strong suction power picks up large dirt
- Vibrating mop removes foot prints gently yet effectively
- Maximum coverage of your floor: doesn't miss a spot

Your intelligent helper saves you time and effort

- Detects and avoids small items in the way like shoes or toys
- Empties itself: 30 days hassle-free
- Cleans up to 180 minutes on a single battery charge
- Also cleans in hard-to-reach areas

Designed around you

- Stylish design fits with your home interior
- Intuitive to use - ideal for first time users
- Clean each room, just the way you like it
- Control where the robot is allowed to clean

PHILIPS

Highlights

Vacuum and Mop in one go



The robot vacuums and mops hard floors in one go to tackle the fine layer of dust that builds up on floors every day. Removing more fine dust than vacuuming alone, so the soles of your feet will stay clean even if you walk around barefoot.

Small obstacle detection



Forget checking for clear pathways the robot will detect and avoid small items in the way, like shoes or toys, and clean closely around them without getting stuck or bumping into things. The state of the art 3D ToF sensor located at the front of the robot can detect items as small as 2,0 x 2,0cm (W x H). Plus, 8 ToF- sensors in the front bumper continuously detect what lies in front and alongside the robot. The sensors work even in low light situations, so you don't need to keep the lights on when you are away from home.

Stylish design



The robot and Auto-Empty station are made from high quality materials with a premium finish to fit in with your home interior. The HomeRun 7000 Series Vacuum and Mop robot is available in two stylish designs to fit in with your home interior: Deep Black & Gold (XU7100/01) and Silk White & Gold (XU7100/02). The white Auto-Empty station is finished with a water-repellent fabric that is easy to maintain.

Ultra-strong suction power



Ultra-strong suction power (rigorously tested to reach up to 5000 Pa*) can pick up large dirt, like crumbs and pet hair. It takes care of the everyday dirt build-up underfoot, as well as removing finer dust from deep within crevices, carpets and rugs.

Auto-Empty station



The robot empties itself automatically into the Auto-Empty Station in less than 30 seconds,

using Philips Dual Wave™ technology. Due to its special airflow simultaneously sucking and pushing, nothing is left behind, not even long hairs. The station contains a 3.0-liter disposable, anti-allergy bag that can hold up to 30 days* worth of dust, hairs and other dirt, to enjoy 30 days with no hassle of emptying. The bag can be hygienically disposed without a cloud of dust - ideal for asthma and allergy sufferers.

HomeRun app



The Philips HomeRun robot app has been designed to be user-friendly and intuitive - ideal for first time users. It features step-by-step guidance and helpful videos to ensure you're getting the very best out of your robot. The app communicates with your robot to control, report and update on its cleaning performance wherever you are, showing in real time where the robot has cleaned.

Vibrating mop technology



The washable mop is made of ultra-fine fibers to efficiently remove 99.99% of bacteria caused by germ carriers like dirty shoes and pet hairs. Its vibrating mop technology removes foot prints gently yet effectively to provide next-level cleaning beyond just vacuuming. The 240 ml water tank allows the robot to mop 130 sqm without refill.

Specifications

Robot highlights

- Vacuum and Mop in one go
- Mopping technology: Vibrating mop
- Suction power (maximum): 5000 Pa
- Type of navigation: 360° laser navigation (LiDAR)
- Small obstacle detection
- Battery capacity: 5200 mAh
- Battery run time (maximum): Up to 180 minutes
- Noise level (minimum): ≤66 dB
- Color: Deep Black & Gold

Docking Station

- Charging function
- Auto-Empty function
- Philips Dual Wave technology
- Type of dust bag: Anti-allergy dust bag
- Size of dust bag: 3.0l

App

- App name: Philips HomeRun
- Connect via Wi-Fi: Yes, dual band (2.4 GHz and 5 GHz)
- Connect via Bluetooth: No
- Languages in the app: English, German, French, Italian, Polish, Spanish, Turkish, Bahasa Malaysia, Bulgarian, Croatian, Czech, Danish, Dutch, Estonian, Finnish, Hungarian, Lettish, Lithuanian, Norwegian, Portuguese, Romanian, Slovak, Slovenian, Swedish, Vietnamese
- How to use videos
- Quick mapping function
- Multi-floor mapping: Yes, save up to 5 maps
- Select which room(s) to clean
- Select room cleaning sequence
- Select cleaning mode per room
- Cleaning modes: Wet & Dry, Dry, Intensive, Silent, Individual
- Suction power (levels): 4 levels: Eco, Normal, High, Max
- Mop wetness (levels): 4 levels: None, Low, Medium, High

- Cleaning path repetition: 1 pass, 2 passes or 5 passes
- Restricted cleaning areas: Virtual wall, No-Go zone, No-Mop zone, No-Climb zone, Gentle zone
- Clean while you're away: real time map
- In-app alerts & notifications
- Cleaning report & history
- Maintenance dashboard
- Scheduled cleaning
- Child lock
- Contact Consumer Care: Phone

Wet cleaning

- Nr. of mop vibrations per minute: 430/min
- Electric water tank to adjust wetness of the mop
- Lifiable mop: No
- Washable & wear resistant microfiber mop
- Can be used with detergents: No

Dry cleaning

- Carpet boost function
- Type of main brush: Multi-surface rubber brush with bristles
- Nr. of side brushes: 1x
- Type of filter: Washable EPA11 filter

Sensors

- Navigation technology: LDS laser navigation
- Small obstacle detection technology: 3D ToF, 8 ToF-sensors
- Obstacle recognition via artificial intelligence: No
- Carpet detection sensor: No
- Anti-drop sensors to detect a cliff: Yes, 6 sensors
- Station seeker: Yes, infrared signal receiver & emitter
- Water tank empty sensor
- Dust bin full sensor
- Dust bag full sensor

Maneuverability & Autonomy

- Clean room by room

- Obstacle crossing ability: Up to 20 mm (empty water tank)
- Automatic recharge function
- Automatic resume function

Voice alert & voice control

- Voice alert function via built-in speaker
- Voice alert languages: English, German, French, Italian, Polish, Spanish, Turkish, Bahasa Malaysia, Czech, Dutch, Estonian, Hungarian, Lithuanian, Norwegian, Romanian, Slovak, Slovenian, Swedish

Power

- Battery type: Lithium-Ion
- Battery run time (minimum): Up to 85 minutes
- Battery charging time: Up to 5 hours
- Battery voltage: 14.4V
- Standby power consumption: 112mA
- Battery can be removed and replaced

Capacity

- Dust bin capacity: 260 ml
- Water tank capacity: 240 ml
- Range: sqm that can be mopped without refill: Up to 130 sqm

Weight and dimensions

- Robot diameter: 350 mm
- Robot height: 97 mm
- Station width x length x height: 355 x 403 x 471 mm
- Weight of robot: 4.0 kg
- Weight of station: 4.7 kg
- Weight incl. packaging: 14.2 kg
- Dimensions of packaging (LxWxH): 469 x 399 x 534 mm

Accessories included

- Station: Auto-Empty station
- Washable mop: 2
- Disposable mops: N/A

Specifications

- Washable filter: 1
- Main brush: 1
- Side brush: 1
- Brush cleaning tool
- Dust bag: 3
- Placemat: No
- Remote control: No
- Power cord
- Quick Start Guide: Yes, printed
- User manual: Digital



Issue date 2023-12-19

Version: 17.17.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com