



Philips
On-tap filtration

X-Guard Ultra

AWP3753

Crisp and pure tasting water

straight from the tap

Enjoy crisp and pure tasting water whenever you turn on the tap, with Philips X-Guard ultrafiltration system reducing chlorine, lead, bacteria and more. Easy one-click installation allows it to fit on your tap in seconds.

Crisp and pure tasting water

- Effectively reduces chlorine, lead, bacteria and more

Made easy

- Easily switch between freshly filtered and unfiltered water
- One-click installation - no need for a plumber
- Timer reminds you when to replace the filter
- Quick twist design for easy filter replacement

Good for you, and good for the environment

- Delicious water at a fraction of the cost of bottled water

PHILIPS

Specifications

Filter specifications

- Replacement filter cartridge: AWP315

Input water conditions

- Input water pressure: 0.15 - 0.35Mpa bar
- Input water temperature: 5-38 °C
- Input water quality: Municipal tap water

General specifications

- Filtration capacity: 1200L
- Water flow rate: 1.6L/min

Country of origin

- Filter cartridge: China
- On-tap: China

Highlights

2 modes to select

Filtered stream water is tailored for drinking and cooking, while unfiltered shower water is suitable for washing dishes and other cleaning purposes.

Easy filter replacement

Effortlessly replace the expired filter with a new one with a simple twist.

Economical and eco-friendly

Great tasting water at a fraction of the cost and waste of bottled water.

Filter replacement reminder

Timer reminds you when to replace the filter for the best result.

One-click installation

After the correct adaptor is installed, simply attach the filter to the faucet and release, and you are good to go!

X-Guard Ultra filter

By adopting the innovative activated carbon fibre and hollow fibre membrane, this X-Guard Ultra filter effectively reduces chlorine, lead, pesticides, microplastics and particles down to 0.1 micron. It also filters up to 99.99% of bacteria.

