



Philips Xenium
Xenium

X518
Black

CTX518BLK

Light touch, solid results

Get ahead and stay ahead with the smart and stylish Philips Xenium X518. You're always connected, thanks to dual SIM cards and up to 12 hours of talk time. Plus, its brilliant 2.8" TFT touch screen ensures swift access to cool functions.

Always on, always connected

- Up to 12 hours of talk time
- Dual SIM for 2 groups of contacts
- Up to 40 days standby time

Maximize your Multimedia Experience

- 2 megapixel digital camera for crisp, vivid pictures
- MicroSD memory card slot for extra memory/ data storage
- Enjoy Bluetooth stereo music
- Easy tuning with on-screen display on RDS FM radio stations

One touch, full control

- 7.1 cm (2.8") TFT touch screen
- Customize home screen with default widgets

PHILIPS

Highlights

2 megapixel camera



Use your 2 megapixel digital camera to enhance your photo experience with crisp, vivid pictures. The intuitive design and user interface allow you to easily take high-resolution photos of up to 1600 x 1200 pixels to use as wallpaper for your phone display; send from your phone via MMS, Bluetooth, or infrared; or print and share.

RDS FM Radio

Enjoy quick and easy tuning to your favorite stations with Radio Data System (RDS) display, which shows the name of the station instead of frequency numbers. RDS also allows stations to transmit text messages and information directly to your radio display, so you can keep updated with news updates and radio promotions.

Up to 12 hours talk time



The phone can support up to 12 hours conversation on a single charge.

Bluetooth stereo music

Your Philips mobile phone supports A2DP Bluetooth Profile. It lets you enjoy your favorite tunes wirelessly and in high quality stereo music from your Bluetooth headphones.

MicroSD memory card slot

You can now enjoy extra capacity and storage of multimedia files by inserting a MicroSD memory card into the built-in memory card slot of your phone.

7.1 cm (2.8") TFT touch screen

Enjoy brilliant colors and vibrant images like never before with your phone's large 7.1 cm (2.8") TFT display. Revel in intuitive navigation and discover a world of mobile possibilities - with just a touch.

Dual SIM



Organize your life better and keep your contacts separate by using 2 different phone numbers. With Dual SIM, you don't need to carry 2 phones around.

Preset widgets for home screen

With widgets, you can customize your mobile phone's home screen and instantly access features, information and media content that's most important to you. With just a click, you can conveniently access your calendar, messages, photos and music - and more! Simply drag and drop to organize your widgets... and your life.

Up to 40 days of standby time



Better than ever battery life! The phone can be on and in standby mode continuously for 40 days on a single charge.



Specifications

Picture/Display

- Diagonal screen size (inch): 2.8 inch
- Main Display Resolution: 240x320 pixels
- Main Display Technology: TFT
- Main Display Colors: 262K
- Touch-sensitive screen: Touch Screen

Still Picture Capturing

- Camera: Integrated
- Picture resolution: VGA (640x480), QVGA (320x240), SVGA (800x600), 2M (1600x1200), SXGA (1280x1024)
- Flash: built-in
- Picture file format: JPEG
- Picture Mode: Night mode, Self-timer mode, Multi-shot
- Picture quality: Normal, High, Low
- Special effects preview mode: Grey scale, Sepia, Blue effect, Green effect, Color invert, Normal
- Image sensor type: CMOS

Still Picture Playback

- Picture Compression Format: BMP, GIF, JPEG
- Rotation: 90 degree steps
- Slide show

Storage Media

- Memory Card Types: Micro SD
- Maximum memory card capacity: 16 GB
- Memory management: Memory status, Dynamic memory allocation
- User memory: 1 MB

Connectivity

- Bluetooth: Bluetooth V2.0
- Bluetooth profiles: A2DP, Handsfree, Headset, File transfer profile
- Modem Capabilities: GPRS
- Headset: Via mini USB connector
- PC Link: USB 2.0
- Serial connections: USB-miniUSB data cable

Network Features

- GPRS (Rx+Tx): Class 12, class B and C, Class 10 (4+2), Class B
- Messaging: Concatenated SMS (Long SMS), MMS, Multimedia Message Service, Predefined messages (SMS, MMS), SMS CB (Cell Broadcast), SMS (Short Message Service), SMS multi-target
- Services: OTA provisioning (WAP, MMS), SIM Toolkit / Release 99, WAP 2.0
- Voice Codec: FR/EFR/AMR/HR
- GSM band: 900, 1800, 1900 MHz

Power

- Battery Capacity: 1530mAh
- Battery Type: Lithium-ion
- Standby time: Dual SIM up to 1000hrs
- Talk time: Up to 12 hours
- Battery saving manager: Auto switch on/off

Convenience

- Language available: UI: English, Russian
- Ease of Use: Hands free mode, Hot Keys, In-flight mode, Keypad Lock, Softkeys, Vibra Alert
- Call Management: Call Forwarding, Call on Hold, Call Time, Call Waiting*, Caller ID*, Conference Call, Emergency Call, Microphone mute, Missed Calls, Multi-party call, Received Calls, Firewall
- Buttons and controls: Side keys, Soft keys
- Volume control
- Clock/Version: Analogue, Digital, International clock
- Multimedia: FM Radio
- Vibrator
- Games and applications: Agenda, Alarm Clock, Calculator, Calendar, Java MIDP 2.0, Lunar Calendar, Stopwatch, Countdown timer, International converter, Currency converter
- Ease of Navigation: Touch panel
- Text input: T9
- Language available: T9 input: English, Russian
- Personal Info Management: Daylight saving, Time

- Zone, Smart Phonebook, Safeguard, International clock, SD card back-up
- Personalisation/Customization: Downloadable Animated GIF, Downloadable Java Applications, Downloadable Picture, Downloadable Ringtones, Wallpaper, Ringtones

Sound

- Ringers: MP3 ringer, Polyphonic (64 tones), Voice memo ringer, AMR ringer
- Equalizer settings: Classical, Dance, Pop, Rock, Bass, Normal, Party

Audio Capturing

- Voice recording: Yes, AMR, AWB, WAV

Audio Playback

- Audio supported formats: AMR, Midi, MP3, AAC, WAV, AAC+

Audio Recording

- Record your own voice

Video Capturing

- Video format: MPEG4
- Video resolution: CIF
- Digital zoom: 8x
- Frame rate: 15 fps
- Video mode: Auto, Night

Video Playback

- Resolution (pxl): 176x144
- Compression formats: MPEG4, H.263, 3GP

Video Recording

- Resolution (pxl): 176x144
- Compression formats: MPEG4, 3GP, H.263

Dimensions

- Form Factor: Candy bar
- Antenna: Integrated

Specifications

- Handset color: black
- Handset dimensions: 104*57*14.3 mm
- Handset weight: 108g

Green Specifications

- Lead-free soldered product
- Packaging material: Carton

Accessories

- Standard Package Includes: Battery, CD ROM (Mobile Phone Tools), Charger, Handset, User Manual, USB data cable



Issue date 2024-01-03

Version: 4.0.1

EAN: 87 12581 60650 3

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Specification indicated based on initial full battery charge tested in laboratories with Bluetooth switched off. Actual performance is dependent on network service provider and usage.